

SPERRY  UNIVAC

UNISCOPÉ 100
DISPLAY TERMINAL
TYPE 3536-06 SERVICING

MR6001

UNIVAC
TERMINAL
MULTIPLEXER
TYPE 8538

**SERVICING
GUIDE**

MARCH, 1973
CUSTOMER SERVICES

SPERRY UNIVAC
TECHNICAL LIBRARY
VANDENBERG AFB

RESTRICTED DISTRIBUTION

The information contained in this publication is the property of Sperry Univac. It is submitted in confidence and must not be disclosed to others except in confidence with the written permission of an officer of Sperry Univac. This copy is not to be reproduced or duplicated without permission in writing from a duly authorized representative of Sperry Univac. This publication is subject to recall.

HB 2303

VOLUME 1

SPERRY  UNIVAC
COMPUTER SYSTEMS

HR 2303

UNISCOPE 100

DISPLAY TERMINAL TYPE 3536-06

SERVICING

CONTENTS

Volume I

- | | |
|---------|---|
| MR 6001 | UNIVAC Terminal Multiplexer
Type 8530
Servicing Guide |
| MR 6002 | UNIVAC Terminal Multiplexer
Type 8530
Illustrated Parts Breakdown |
| MR 6014 | UNISCOPE 100
Display Terminal
Type 3536-06
Installation Procedures |
| MR 6015 | UNIVAC UNISCOPE 100
Display Terminal
Type 3536-06
Servicing Data and Adjustments |
| MR 6032 | UNIVAC UNISCOPE 100
Display Terminal
Type 3536-06
Illustrated Parts Breakdown |

SPERRY UNIVAC
TECHNICAL LIBRARY
VANDENBERG AFB

REVISION: 8CD-2

HANDBOOK CHANGE BULLETIN

BOOK: MR6001, UNIVAC TERMINAL
MULTIPLEXER, TYPE 8538,
SERVICING GUIDE

JUNE 25, 1973

Contained in the following handbooks:

HCB 1

HB1891 UNIVAC UNISCOPE 100 Display Terminal Type 3536
and Terminal Multiplexer Type 8538, Servicing

HB1598 UNIVAC Data Communications Terminal Type 8539-00, -01
and Terminal Multiplexer Type 8538, Servicing

DESCRIPTION OF CHANGES

Table 3-2. Interface Strapping Selections

Direct Connection 2400 bps, Bend Pins 1-3-4-5-6-7-8

9-10-11-12-13-14

is changed to 1-3-4-5-6-7-8

9-10-11-12-14

Data supplied originally is in error.

INSTRUCTIONS

All revised pages are labeled "REVISION: HCB-1".

REMOVE PAGES	INSERT ENCLOSED NEW PAGES
3-1 and 3-2	3-1 and 3-2

INSERT THIS HCB COVER SHEET IN MR6001 DIRECTLY FOLLOWING THE TITLE PAGE

CONTENTS

Heading	Title	Page
SECTION 1. INTRODUCTION		
1-1.	General.	1-1
1-2.	Reference Documentation.	1-1
SECTION 2. GENERAL DESCRIPTION		
2-1.	Introduction	2-1
2-2.	Equipment Description.	2-1
2-3.	Configurations, Features, and Options.	2-1
SECTION 3. INSTALLATION		
3-1.	Introduction	3-1
3-2.	Unpacking.	3-1
3-3.	Configuration Description Record	3-1
3-4.	Strapping.	3-1
3-5.	Interface Strapping.	3-2
3-6.	Timeout Strapping.	3-3
3-7.	Cabling Requirements	3-4
3-8.	Cable Connections.	3-4
3-9.	Cabling Configurations	3-5
3-10.	Power-On	3-8
3-11.	Repacking.	3-8
SECTION 4. FUNCTIONAL DESCRIPTION		
4-1.	General.	4-1
4-2.	Terminal Addressing.	4-1
4-3.	Contention Resolving	4-1
4-4.	Logical Multiplexing	4-2
4-5.	Modem Sharing.	4-2
4-6.	Univac Control Philosophy.	4-2
4-7.	Response to Polls.	4-2
4-8.	Cascaded Multiplexers.	4-3
4-9.	Polling Considerations	4-4
SECTION 5. SERVICING PROCEDURES		
5-1.	Introduction	5-1
5-2.	General Precautions.	5-1
5-3.	Special Tools.	5-1
5-4.	Disassembly.	5-1
5-5.	Module Identification.	5-1
5-6.	Servicing.	5-1
SECTION 6. ILLUSTRATED PARTS BREAKDOWN (To be Supplied)		
SECTION 7. ILLUSTRATIONS		
7-1.	General.	7-1

ILLUSTRATIONS

Figure	Title	Page
1-1.	Terminal Multiplexer Type 8538.	7-2
2-1.	Multiplexer Configurations.	7-3
3-1.	Multiplexer Disassembly	7-4
3-2.	Multiplexer Strapping	7-5
3-3.	Rear Panel Connectors	7-6
3-4.	Single-Station Cabling Configuration.	7-7
3-5.	Multiple-Station Cabling Configuration.	7-8
3-6.	Single-Station Cabling - CDM.	7-9
3-7.	Single-Station Cabling - CTMC or DCS.	7-10
3-8.	Special Build Cables - Multiple-Station (Sheet 1)	7-11
3-8.	Special Build Cables - Multiple-Station (Sheet 2)	7-12
3-9.	Junction Box Wiring	7-13
3-10.	Multiplexer Repecking	7-14
5-1.	Voltage Bus Locations	7-15

TABLES

Table	Title	Page
2-1.	Features and Selections	2-1
3-1.	Inspection Procedures	3-1
3-2.	Interface Strapping Selections.	3-2
3-3.	Timeout Values.	3-3
3-4.	Timeout Strapping Selections.	3-4
3-5.	Channel Expander Location Versus System Operating Speed	3-4
3-6.	Multiplexer Cable Descriptions.	3-5
3-7.	Cable Length Versus System Operating Speed.	3-7
4-1.	Terminal-to-Multiplexer Status Indications.	4-3
4-2.	Multiplexer-to-Terminal Status Indications.	4-3

SECTION 1
INTRODUCTION

1-1. GENERAL

This book contains servicing and maintenance information for the UNIVAC[®] Terminal Multiplexer Type 8538. Included are installation procedures, servicing information, and an illustrated parts breakdown (to be supplied).

This book is intended to provide comprehensive data to be used in a module replacement mode of servicing the Multiplexer. This book is not necessarily intended to provide a detailed operational analysis, nor to be a guide for more detailed troubleshooting than to the module level.

1-2. REFERENCE DOCUMENTATION

The following publications are applicable as aids in installing and servicing the Multiplexer:

- SD 12001 Servicing Diagrams for Terminal Multiplexer, Type 8538
- SP 2012 UNISCOPE[®] 100 Display Terminal Preinstallation Planning Guide
- UP 7807 UNISCOPE 100 Display Terminal Programmers Reference
- MH 2349 Guide for Planning the Installation of a UNIVAC DCT 1000 Data Communications Terminal
- UP 7859 UNIVAC DCT 1000 Data Communications Terminal Programmers Reference

[®] UNIVAC is a registered trademark of the Sperry Rand Corporation. Another trademark of the Sperry Rand Corporation appearing in this publication is: UNISCOPE.

SECTION 2

GENERAL DESCRIPTION

2-1. INTRODUCTION

This section provides a brief description of the UNIVAC Terminal Multiplexer Type 8538, and lists the interface features and equipment options available for use with the Multiplexer.

2-2. EQUIPMENT DESCRIPTION

The Multiplexer is a general-purpose device designed primarily for use in data communications systems that use the UNIVAC UNISCOPE 100 Display Terminal and the UNIVAC DCT 1000 Data Communications Terminal. The Multiplexer permits synchronous or asynchronous full-duplex communications through common carrier modems, or full-duplex synchronous operation directly with a central processor equipped with a suitable communications terminal adapter.

The basic Multiplexer provides line connections for 8 terminal channels, with an optional expansion feature providing capability for an additional four or eight terminals. A cascaded Multiplexer may be connected into any terminal channel, theoretically allowing a maximum of 256 channels to be connected into a system at one interface point. However, system performance considerations generally dictate that no more than 31 channels should be connected into a system at any one point.

2-3. CONFIGURATIONS, FEATURES, AND OPTIONS

The Multiplexer is available in two basic configurations: a 60-Hz model (Type 8538-99), and a 50-Hz model (Type 8538-98). Each configuration consists of the basic unit with power supply circuitry, provision for eight channels, and either of two communications interface features. Each configuration can also be expanded to include provision for either 12 or 16 channels by the addition of one or two channel expander boards, 2807734 (F1264-00).

Table 2-1 lists the unit features, together with all available options, and figure 2-1 provides a graphic representation of the selections available. Interface selection, unit strapping, and system cabling information are provided in Section 3, and a functional description of unit operation is given in Section 4.

Table 2-1. Features and Selections

Feature	Part Number	Description
Communications Channel Expander (F1264-00)	2807734	Increases capacity of Multiplexer in increments of four terminals; two channel expander features may be added to each Multiplexer.

Table 2-1. Features and Selection Options - Continued

Feature	Part Number	Description
Communications/ Multiplexer Interface Adapter (F1266-00)	2807758	<p>Provides a synchronous or asynchronous interface to a communications modem or another Multiplexer, according to the selection option.</p> <p>Mode and interface compatibility selections can be changed at the operating site by Customer Engineering personnel.</p> <p>Interface selections:</p> <p>C1463-00 EIA RS-232-C/CCITT V.24 synchronous</p> <p>C1463-01 EIA RS-232-C/CCITT V.24 asynchronous</p> <p>C1463-02 Terminal Multiplexer synchronous</p> <p>C1463-03 Terminal Multiplexer asynchronous</p> <p>C1463-04 MIL-STD-188B/C synchronous</p> <p>C1463-05 MIL-STD-188B/C asynchronous</p>
Direct Connection, Synchronous with Clock (F1266-02)	2807736	<p>Provides a synchronous interface to a central processor equipped with a compatible communications terminal adapter such as the UNIVAC Communications Terminal Module Controller (CTMC), UNIVAC Data Communications Subsystem (DCS) (or equivalent).</p> <p>Operating speed selection can be changed at the operating site by Customer Engineering personnel.</p> <p>Interface selections:</p> <p>C1464-00 2400 bps</p> <p>C1464-01 4800 bps</p> <p>C1464-02 9600 bps</p>

SECTION 3
INSTALLATION

3-1. INTRODUCTION

This section contains the information required for unpacking and installing the UNIVAC Terminal Multiplexer Type 8538. It also contains a description of cabling requirements, and information on repacking.

3-2. UNPACKING

Because of the simplicity of design of the Multiplexer, detailed unpacking instructions are unnecessary. One set of packing materials should be saved, however, should the unit require shipment to a new location.

Before installing the Multiplexer, the inspection procedures listed in table 3-1 should be performed. In the event that damage is discovered, notify the branch office immediately.

Table 3-1. Inspection Procedures

Step	Procedure
1	Inspect the cover, sides, and connector panels for visible damage and/or missing parts such as connector fastener nuts, rubber feet, or panel screws.
2	Disassemble the unit as shown in figure 3-1 and inspect for mechanical damage.
3	Remove all component boards and check the unit for cracked or broken cable connectors, loose or broken wires and solder connections, bent or shorted wire-wrap pins, and loose or unconnected terminal lugs or wire connectors.
4	Inspect for metal chips, wire cuttings, solder drippings, and other loose particles or foreign material.
5	If control board 2807758 or 2807736, A01, is already strapped for a particular interface option and timeout delay, verify that the strapping is correct as described in this section and as defined by the user system configurations. If the control board is not strapped, follow the procedures described in paragraph 3-4.
6	Replace the component boards; ensure that each component board is firmly seated in the connector.

3-3. CONFIGURATION DESCRIPTION RECORD

Complete the three Configuration Description Record forms that accompanied the Multiplexer from the factory. Ensure that all information requested on the form is provided. File one copy at the operating site, and return the remaining two copies to the local Customer Services office.

3-4. STRAPPING

Strapping options for the Multiplexer are used to select the desired interface and the duration of the timeout delay.

3-5. INTERFACE STRAPPING

Multiplexer interface options are selected by installing the appropriate strapping connector into control board 2807758 or 2807736 (A01). Strapping connectors are formed by bending up unused pins from connectors 2805281-17 or 2805281-18, as listed in table 3-2, for the particular interface option desired. Figure 3-2 illustrates the connector socket location on the control board.

Synchronous strapping described for noninverted clock signal as specified in MIL-STD-188C. Either a noninverted or an inverted clock signal was permitted under MIL-STD-188B, and modems contain provisions which allow either configuration. The Multiplexer should be strapped for MIL-STD-188C, as listed in table 3-2, and the modem modified (if necessary) to conform to the noninverted clock signal.

Strapping connectors 2805281-03 or 2805281-13 (six-lead) may be available at the site rather than 14-lead connectors 2805281-07 or 2805281-17. The six-lead connectors may be used in strapping control board 2807736 (F1266-02, Direct Connection). However, exercise care when installing the connector to ensure strapping equivalent to that specified in table 3-2. Note that early Multiplexers shipped from the factory may be supplied with connectors 2805281-07 or 2805281-08 rather than with connectors 2805281-17 or 2805281-18.

NOTE

Strapping connectors 2805281-03, 2805281-07, and 2805281-18 should have approximately 1/16-inch clipped from all leads before use.

Table 3-2. Interface Strapping Selections

System Operation	Primary Multiplexer		Cascaded Multiplexer	
	Connector	Bend Pins	Connector	Bend Pins
RS-232C, Synchronous	Z19	None	Z19	None
	Z29	None	Z38	1-2-3-4-5-8
	Z38	4-5-8	Z39	4-5-6-7-8
RS-232C, Asynchronous	Z19	None	Z19	None
	Z29	None	Z39	4-5-8
	Z38	4-5-6-7-8		
	Z39	1-2-3-4-5-7-8		
MIL-STD-188C, Synchronous	Z18	6-7	Z19	None
	Z19	1-2-3-4-5-8	Z38	1-2-3-4-5-8
	Z38	4-5-8	Z39	4-5-6-7-8
MIL-STD-188C, Asynchronous	Z18	None	Z19	None
	Z38	4-5-6-7-8	Z39	4-5-8
	Z39	1-2-3-4-5-7-8		
Direct Connection 2400 bps	Z71	1-3-4-5-6-7-8		
		9-10-11-12-14		
Direct Connection 4800 bps	Z71	1-2-3-4-5-7-8		
		10-11-12-13-14		
Direct Connection 9600 bps	Z71	1-2-3-5-6-7-8-9		
		10-12-13-14		

3-6. TIMEOUT STRAPPING

The timeout circuitry in the Multiplexer prevents an attached terminal from holding an entire line unuseable by not releasing control of the line. If the timeout delay value is too long, system performance in high speed operations can be degraded.

Considerations in selecting a strapping option include both the software and the hardware of the system. From the software standpoint, only one terminal at a time can transmit to the processor from any given Multiplexer. When a terminal is transmitting, the timeout clock is running and the scanner in the Multiplexer is functionally locked on that terminal channel. Responses by any other terminals on the Multiplexer to polls from the processor are not possible since other channels are not accessed by the scanner during the timeout period. For this reason, the software must ensure that the amount of time provided for "N" poll retries for error recovery exceeds the nominal timeout value plus the 20 percent tolerance. If this is not done, the software will unnecessarily "down" the line because of the lack of responses during error recovery.

From the hardware standpoint, the nominal timeout value minus the 20 percent tolerance must exceed the maximum time required for a terminal to send the longest possible message at the given bit rate. If this is not so, the time could elapse before a valid transmission from the terminal is completed.

The nominal maximum time required for a transmission can be calculated by dividing the nominal bit transmission rate into the number of bits in each character, and multiplying the resulting figure by the maximum number of characters in a message.

Table 3-3 provides a listing of timeout values, in seconds, for a UNISCOPE 100 Display Terminal and a DCT 1000 Data Communications Terminal.

Note that bit transmission rates are nominal values, each having a tolerance based on the modems (or modem replacement devices) used in the system. While the information in the tabulation should suffice for most modem applications, special modems or modem replacements such as the UNIVAC Type 8538 Direct Connection Module (DCM), may have clock tolerances as high as plus or minus 10 percent. These tolerances must be considered when determining appropriate timeout strapping.

Table 3-3. Timeout Values

Nominal Bit Rate	Transmission Mode	Display Terminal Timeout	DCT 1000 Timeout
9600	Synchronous	0.882	0.145
4800	Synchronous	1.764	0.29
2400	Synchronous	3.528	0.58
2000	Synchronous	4.236	0.696
2400	Asynchronous	4.41	0.725
1200	Asynchronous	8.82	1.45
600	Asynchronous	17.64	2.9
300	Asynchronous	35.28	5.8

Timeout delay options are selected or changed by means of jumpers installed on the control board (AO1). Strapping information is provided in table 3-4. Figure 3-2 is the locating view for the strapping points.

Table 3-4. Timeout Strapping Selections

Control Board Part Number	Timeout Delay (Seconds)	Strapping
2807758-00 to 2807758-02	8 to 12	E1 - E2, E3 - E4
2807736-00 to 2807736-02	30 to 40	E3 - E4
	45 to 55	E1 - E2
	80 (approx)	None
2807758-03 to 2807758-05	4.6 ± 0.92	E1 - E2, E3 - E4
2807736-03 to 2807736-04	6.5 ± 1.30	E1 - E2
	13 ± 2.60	E3 - E4
	70 ± 14	None

3-7. CABLING REQUIREMENTS

The Multiplexer, designed for tabletop or shelf installations, may be installed in any location compatible with operational requirements and specifications and the cabling limitations described in table 3-7. When installing the Multiplexer, ensure that there is adequate space behind the connector panel for cable access and that conditions provide effective cooling of the equipment.

Site cabling and modems or modem replacements are normally installed before Multiplexers and their associated terminals arrive at the operating site from the factory. At new equipment locations, the Customer Engineering representative normally needs only to make the necessary cable connections between equipment items. However, the expansion or modification of existing site configurations may require his involvement in planning new Multiplexer cabling configurations.

Information required either to integrate the Multiplexer into a communications system or to support the planning of new Multiplexer cabling configurations is provided in this section.

3-8. CABLE CONNECTIONS

The Multiplexer connector panel, shown in figure 3-3, provides 17 signal connectors identified solely by reference designations. Connectors J1 through J16 are branch connectors; that is, connectors which provide the signal interfaces to the associated terminals or cascaded Multiplexers. Connector J17 is a trunk connector which provides a signal interface from a cascaded Multiplexer to a primary Multiplexer, or from a primary Multiplexer to either a modem or a modem replacement device such as the DCM.

The Multiplexer is shipped from the factory equipped with from two to four F1264-00 communications channel expander features (component board 2807734). These component boards are installed in slots A02 through A05 of card module A06, and are related to the signal connectors as listed in table 3-5.

Table 3-5. Channel Expander Location Versus Signal Connections

Card Slot	Branch Connector
A02	J1 thru J4
A03	J5 thru J8
A04	J9 thru J12
A05	J13 thru J16

The Multiplexer is designed to sequentially select channels 1 through 16 (J1-J16), thereby providing a built-in priority system. Although not electronically necessary, it is recommended that terminals be connected to the Multiplexer in ascending RID and SID order. For example, with a group of terminals having a RID of 42 and SID's of 142 through 157, SID 142 should be connected to J1, 143 to J2, and so on. This procedure reduces system transmission times and greatly simplifies servicing.

Similarly, if only 8 channels are to be utilized on a given Multiplexer, card slots A02 and A03 should be used.

A complete description of message formats, including RID and SID considerations, is provided in UP-7807, UNISCOPE 100 Display Terminal Programmers Reference.

3-9. CABLING CONFIGURATIONS

Recommended Multiplexer cabling configurations are illustrated in Figures 3-4 through 3-9. Figure 3-10 is a detail drawing of the wiring of the junction box used in joining two segments of cable together. Table 3-6 provides part numbers and descriptions of the cables and cable components identified in the figures by index numbers.

Factors that must be considered in a Multiplexer cabling configuration include system operating speed, the cable length required, cable routing, ambient noise environment, and the possible use of non-Univac cables.

With UNIVAC systems, operating speed is only a factor in system configurations which include a CTMC. All other configurations will operate satisfactorily at 9600 bps to the maximum cable lengths shown in the figures. Cable length restrictions versus system operating speeds for configurations with the CTMC are provided in table 3-7.

Table 3-6. Multiplexer Cable Descriptions

Item	Part Number	Description
1	2805096	<p>Cable Assembly: Unshielded cable with male and female connectors.</p> <p>Available cable lengths: 3 feet 5 to 100 feet in 5-foot increments 110 to 210 feet in 10-foot increments 220 to 300 feet in 20-foot increments</p> <p>Function: Connects terminal or Multiplexer to DCM or modem (50 feet maximum), terminal or cascaded Multiplexer to Multiplexer, or cascaded terminal to cascaded Multiplexer.</p>
2	2807723	<p>Cable semi-assembly: Unshielded cable with one end open and one female connector</p> <p>Available cable lengths: 3 feet 5 to 100 feet in 5-foot increments 110 to 210 feet in 10-foot increments 220 to 300 feet in 20-foot increments</p> <p>Function: Component for on-site cable fabrication. Connects terminals or Multiplexer to junction box (Item 3).</p>

Table 3-6. Multiplexer Cable Descriptions - Continued

Item	Part Number	Description
3	2807819	<p>Component assembly: Cable-splicing junction box.</p> <p>Function: Component for on-site cable fabrication. Connects (splices) any two of Multiplexer cable assemblies or semi-assemblies (Items 2, 4, 5, 6, 8, and 12).</p>
4	2807724	<p>Cable semi-assembly: Unshielded cable with one end open and one male connector.</p> <p>Available cable lengths: 3 feet 5 to 100 feet in 5-foot increments 110 to 210 feet in 10-increments 220 to 300 feet in 20-foot increments</p> <p>Function: Component for on-site fabrication. Connects junction box (Item 3) to DCM, modem, Multiplexer, or cascaded Multiplexer.</p>
5	2807725	<p>Component assembly: Shielded cable with both ends open.</p> <p>Available cable lengths: 300 to 3000 feet in 50-foot increments</p> <p>Function: Component for on-site cable fabrication. Designed for serial or duct installation; cable runs between junction boxes (Item 3).</p>
6	2807765	<p>Component assembly: Shielded cable with both ends open.</p> <p>Available cable lengths: 300 to 5000 feet in 50-foot increments.</p> <p>Function: Component for on-site cable fabrication. Designed for underground (direct burial) installation; cable runs between junction boxes (Item 3). (Junction boxes are not buried.)</p>
7	2807748	<p>Cable assembly: Unshielded cable with male and female connectors.</p> <p>Available cable lengths: 3 feet 5 to 100 feet in 5-foot increments 110 to 210 feet in 10-foot increments 220 to 300 feet in 20-foot increments</p> <p>Function: Connects terminal or Multiplexer directly to CTMC.</p>

Table 3-6. Multiplexer Cable Descriptions - Continued

Item	Part Number	Description
8	2807754	<p>Cable semi-assembly: Unshielded cable with one end open and one male connector.</p> <p>Available cable lengths: 3 feet 5 to 100 feet in 5-foot increments 110 to 210 feet in 10-foot increments. 220 to 300 feet in 20-foot increments.</p> <p>Function: Component for on-site cable splicing. Connects junction box (Item 3) to CTMC.</p>
9	2807867	<p>Cable assembly: Unshielded cable with male and female connectors.</p> <p>Available cable lengths: 5 to 50 feet in 5-foot increments</p> <p>Function: Connects terminal or Multiplexer directly to DCS.</p>
10	2807868	<p>Cable semi-assembly: Unshielded cable with one end open and one male connector.</p> <p>Available cable lengths: 5 to 50 feet in 5-foot increments.</p> <p>Function: Component for on-site cable fabrication. Connects junction box (Item 3) to DCS.</p>

Cable length is the plug-to-plug distance between items of equipment. When required cable lengths are being determined for a particular installation, consideration must be given to routing requirements (bends, drops, stress relief, and so on), in addition to excess length to accommodate equipment positioning.

Table 3-7. Cable Length Versus System Operating Speed

Operating Speed (bps)	CTMC to Terminal	CTMC to Terminal Via 1 Multiplexer	CTMC to Terminal Via 2 Multiplexers
0 to 2400	5500 ft	10,000 ft	15,000 ft
2400 to 4800	5000 ft	10,000 ft	15,000 ft
4800 to 9600	2500 ft	7,500 ft	12,500 ft

Cable routing is normally wholly contained within the user's premises. When cable must be routed outside the premises, consult the common carrier or local utility company for applicable regulations.

Ambient electrical noise (interference) produced by equipment such as motor generators, electromechanical devices, radiation equipment or existing wiring and cabling, can cause errors in data transmissions. If such conditions are suspected, shielded cable must be considered for the installation.

The user may desire to use existing non-Univac cabling with the Multiplexer and terminals. Before this can be permitted, the cables must be certified as acceptable for use with Univac equipment.

NOTE

Ownership of non-Univac cabling must be determined before such certification is made. The use of leased cables on other than equipment for which designed may be circumscribed by the policy of the particular equipment manufacturer.

3-10. POWER-ON

Power application for the Multiplexer consists of connecting the power cable to a suitable line power source (paragraph 2-3) and setting the front panel ON-OFF circuit breaker to position ON.

NOTE

50-Hz units are shipped from the factory equipped with a 5-foot line power cord but without a connector. A connector matching the operating site receptacle must be installed on the cord before use.

3-11. REPACKING

One complete set of Multiplexer packing materials (figure 3-11) should be retained at the operating site from unpacking.

- (1) Verify that carton (1) is not damaged and sturdy enough for reshipping the Multiplexer.
- (2) Place foam padding (2) and die-cut cardboard (3) in carton.
- (3) Line carton with four pieces of foam padding (4).
- (4) Place Multiplexer (5) and power cord in plastic bag.
- (5) Place Multiplexer in carton. Match legs and line power cable with holes in die-cut cardboard.
- (6) Place foam padding (6) and top die-cut cardboard (7) in carton.
- (7) Close carton and seal by binding or stapling lid.

SECTION 4
FUNCTIONAL DESCRIPTION

4-1. GENERAL

The UNIVAC Terminal Multiplexer Type 8538 is designed to allow multiple terminal devices to be connected to a single processor input channel, and to resolve contention among these terminals in the event that more than one transmission request is presented to the Multiplexer simultaneously. The Multiplexer is transparent to (does not sense) any messages transmitted from the processor and senses only status indication from any attached terminals through the use of a logical priority system designed into the Multiplexer logic circuitry.

All terminals on the first Multiplexer and on each cascaded Multiplexer will sense either a general poll, a specific poll, or text (received data) at approximately the same time. Cable propagation time between Multiplexers and terminals makes a slight difference in reception time.

The primary purpose of the Multiplexer is to select, one at a time, those terminals and cascaded Multiplexers having a valid request-to-transmit to the processor. Multiplexer logic can detect the following status indications from a terminal:

- (1) Busy
- (2) Acknowledge (to a previously sent processor message)
- (3) Traffic to send
- (4) No traffic
- (5) Null

Any duplication of status contention from terminals attached to the Multiplexer is resolved by means of the previously mentioned priority system.

4-2. TERMINAL ADDRESSING

Addressing is the method whereby the processor selects the terminal which is to receive a message. The Multiplexer, as mentioned in paragraph 4-1, is transparent to all transmission except status indications from an attached terminal. Therefore, address sensing is performed by the terminal through a strapping or hard-wired provision in the logic circuitry of each unit. The address positions of a message are determined by system software requirements.

4-3. CONTENTION RESOLVING

All polls from the central processor contain RID and SID address codes as part of the standard message format. Terminals with corresponding RID and SID address codes will respond to these polls. Responses are in the form of signals on the request-to-send lines of the terminal. If there is a response from multiple terminals, one terminal is selected for transmission and a not-selected signal is sent to the remaining terminals; the request-to-send signals are then removed from the request-to-send lines of the terminals that have not been selected. These terminals are serviced in sequence during subsequent polls. Terminal selection is performed in a priority sequence. The terminal that last transmitted, that is, the terminal having a potential reply request, is initially selected to transmit. If this terminal does not have a traffic condition, the remaining terminals are selected in sequence until a traffic condition is detected or until it has been determined that no terminal has a traffic condition, in which case the last terminal

which responded is selected. That terminal transmits a no-traffic-without-acknowledge response. Not-selected signals are transmitted to the remaining terminals.

As each terminal is selected, a check is made to determine whether there is an outstanding acknowledge or busy response at that terminal. If either of these conditions is detected, the appropriate control signals are transmitted to the terminal which is selected to transmit so that the outstanding acknowledge or busy response is included with the traffic from that terminal.

4-4. LOGICAL MULTIPLEXING

Logical multiplexing, which is the assignment of different remote identifier addresses to terminals operating through one Multiplexer, is possible because address recognition is performed by the terminal. Logical multiplexing has two advantages: (1) it allows multiple use of the same SID address through the one Multiplexer and, (2) it allows the establishment of terminal priorities for use by the processor during polling.

4-5. MODEM SHARING

Use of the Multiplexer is not restricted to UNIVAC terminals. Other terminals can use the Multiplexer as a modem-sharing device if the interface complies with EIA RS-232-C, which includes the request-to-send, clear-to-send, transmit-dets, transmit-clock, receive-dets, and receive-clock signals. If these terminals are unable to pass the acknowledge and busy responses to other terminals for transmission, each terminal must have a unique address and be polled specifically.

4-6. UNIVAC CONTROL PHILOSOPHY

The Multiplexer is designed to function with terminals operating in accordance with the Univac control philosophy of three-level addressing. All three characters are detected by the terminal, even though the first character, RID, defines a unique remote configuration which may be either a single station terminal or a combination of terminals on a Multiplexer. In systems using more than one primary Multiplexer on the same line, the RID should always be specific; otherwise, more than one terminal might respond to a general RID with indeterminate results.

It is possible to assign the same RID to all terminals on one Multiplexer. A general poll in such a configuration would then consist of the specific RID or a general RID (if the line is single drop), a general station identifier (SID), and a general device identifier (DID).

Terminals may be assigned different RID's and still use a common Multiplexer. A general poll in this type of configuration solicits traffic only from that subset of terminals assigned the RID used for that poll. All other terminals do not respond. Thus, one Multiplexer may be divided into two or more logical Multiplexers and retain all of the features of the general poll. This has two advantages: (1) it allows more than 31 terminals to be used with cascaded Multiplexers, thereby avoiding the address limit of 31 specific SID codes and, (2) it allows the programmer to assign priorities to terminals serviced by a common Multiplexer.

4-7. RESPONSE TO POLLS

If a poll is specific, the terminal that has the specific RID-SID of the poll is the only terminal that issues a request-to-send signal, and this terminal is selected to transmit. The terminal can be on either a primary or a cascaded Multiplexer.

Terminals can present a no-traffic, traffic, ACK, or WABT response to both general and specific polls. Terminal status is indicated on three lines (Request-to-Send A, Request-to-Send B, and Send-Dets). The logic levels present on these lines define terminal status as listed in table 4-1. The X's in table 4-1 indicate that the line is not sensed by the Multiplexer in the particular condition.

Table 4-1. Terminal-to-Multiplexer Status Indications

Request-to-Send A Line	Request-to-Send B Line	Send-Data Line	Meaning
0	0	X	Null
0	1	X	No Traffic
1	0	X	Traffic
1	1	0	ACK
1	1	1	WABT

Table 4-2 lists the Multiplexer selection codes presented to attached terminals. These codes are present on three lines (Clear-to-Send A, Clear-to-Send B, and Send-Clock) as listed in the table. The X's in table 4-2 indicate that the line is not sensed by the terminal in that particular condition.

Table 4-2. Multiplexer to Terminal Status Indications

Clear-to-Send A Line	Clear-to-Send B Line	Send-Clock Line	Meaning
0	0	X	Null
0	1	X	Not selected
1	0	X	Selected for traffic
1	1	0	Selected and send ACK
1	1	1	Selected and send WABT

4-8. CASCADED MULTIPLEXERS

Cascaded Multiplexers can be connected to any or all of the 16 branch connectors on a primary Multiplexer. (Connecting Multiplexers to cascaded Multiplexers is not permissible.) In cascaded configurations (see figure 3-6), the cascaded Multiplexer is treated essentially as a terminal. What is actually presented to the primary Multiplexer on a given branch is the priority composite of up to 16 terminals on the cascaded Multiplexer, which selects terminals for transmission using the same priority sequence as the primary Multiplexer. The branch with the cascaded Multiplexer is selected by the primary Multiplexer in the same priority sequence as is used for terminal selection. If a terminal on the cascaded Multiplexer has a traffic condition, the terminal is selected (by the cascaded Multiplexer) in accordance with the priority sequence previously described. Various conditions can be pending on the primary and cascaded Multiplexers which could dictate selection of a given terminal. These conditions, with the resultant selections, are as follows:

- (1) If there is a traffic condition on one of the terminals connected to the cascaded Multiplexer (with no outstanding ACK or WABT present on the cascaded Multiplexer) and the primary Multiplexer has selected the cascaded branch, the traffic condition will hold the primary selection on the cascaded branch.
- (2) If any of the terminals on the cascaded Multiplexer responds with an ACK or WABT in response to output text from the processor, and a terminal, or terminals, on the primary Multiplexer responds with traffic, the primary Multiplexer deselects the branch with the cascaded Multiplexer and selects for transmit the first terminal with traffic in ascending order on the primary Multiplexer. The ACK or WABT from the cascaded Multiplexer is passed to the selected terminal on the primary Multiplexer for transmission with its traffic.
- (3) If any of the terminals on the cascaded Multiplexer responds with an ACK or WABT in response to output text from the central processor, and if another terminal, or terminals, on the cascaded Multiplexer responds with traffic, the first terminal in the ascending priority sequence with traffic on the cascaded Multiplexer is selected to transmit. The outstanding ACK or WABT is transmitted with the traffic from the selected terminal.

4-8. CASCADED MULTIPLEXERS - Continued

The key to cascaded Multiplexer operation is the ACK or WABT signal from a cascaded terminal in response to reception of a processor message. When this happens in any one of the cascaded terminals and a traffic response is present on a primary terminal, the primary Multiplexer deselects the cascaded branch. It can be seen that a certain priority structure can be established by software in that by sending text to a cascaded terminal, deselection of that branch occurs if there is traffic response on a primary branch. Conversely, if the cascaded terminals provided input only, the cascaded terminals could dominate the Multiplexer select priority.

4-9. POLLING CONSIDERATIONS

It should be noted that if a specific poll is used, the priority scanning sequence can be overridden. The Multiplexer selection can be directed to any terminal on any branch of either the primary or cascaded Multiplexer that has the address of the specific poll. When using the specific polling technique, care must be taken in the software to satisfy potential reply-request conditions.

SECTION 5

SERVICING PROCEDURES

5-1. INTRODUCTION

Servicing of the UNIVAC Type 8538 Terminal Multiplexer in the field, based on module level replacement, is minimal. This section contains the information required to service the equipment to this level.

5-2. GENERAL PRECAUTIONS

The Multiplexer, consisting of relatively simple circuitry, presents no more electrical hazard to servicing personnel than does any device operating on 120/240 VAC line power. The observance of care in taking voltage measurements with the interlock switch of the unit manually activated is cautioned.

5-3. SPECIAL TOOLS

The only special tool required to service the Multiplexer to the authorized level of field repair is card extractor 2807722 or 2808033.

5-4. DISASSEMBLY

The Multiplexer cover is secured by two hinges at the upper rear edge of the cabinet and two magnetic catches at the bottom of the front panel. The cover is removed by lifting the bottom of the front panel and swinging the cover upward. The connector panel is hinged at the bottom and held by two machine screws. The panel is removed by removing the two machine screws and swinging the panel back. Logic cards are removed from the card module connectors by means of card lever (puller) 2807722 or 2808033.

5-5. MODULE IDENTIFICATION

Figure 3-1 provides a locating view of the cards and modules of the Multiplexer. Descriptions of each feature shown on the figure are provided in paragraph 2-3.

5-6. SERVICING

Field repair of Multiplexer component boards is not recommended. Servicing board failures consists of replacing the failed boards. Figure 5-1 shows the location of the voltage busses on the wire-wrap side of the backboard assembly and provides the voltage level of each bus. These voltages are not adjustable. Use the information provided on this figure and in SD 12001-00 in servicing the power supply of the Multiplexer.

NOTE

The plunger of interlock switch S01 (figure 3-1) must be pulled out past the detent to apply power to the Multiplexer with the cover raised.


SECTION 6
ILLUSTRATED PARTS BREAKDOWN

(To be Supplied)

SECTION 7
ILLUSTRATIONS


7-1. GENERAL

This section contains all of the illustrations for this book. The figures are numbered according to section and sequence of their first reference. A complete list of illustrations is given in the table of contents of this book.




UI02

Figure 1-1. Terminal Multiplexer





UI01

Figure 2-1. Terminal Multiplexer Configurations




U100

Figure 3-1. Terminal Multiplexer Disassembly




U117

Figure 3-2. Terminal Multiplexer Strapping



U118

Figure 3-3. Rear Panel Connectors



UI03

Figure 3-4. Single-Station Cabling Configuration






Figure 3-5. Multiple-Station Cabling Configuration



U105


Figure 3-6. Single-Station Cabling - DCM



MULTIPLEXER TO CTMC TRANSMISSION OF MORE THAN 2500 FEET IS LIMITED TO A MAXIMUM OF 4800 BAUD.

U107

Figure 3-7. Single-Station Cabling - CTMC or DCS



UI06

Figure 3-8. Special Build Cables - Multiple-Station




Figure 3-9. Special Build Cables - Multiple-Station

8.00" STRIP OFF INSULATION COVERING




1.00" CUT SHIELD HERE WHEN EXISTING



3/16" STRIP BACK FROM CONDUCTOR WIRES

SIGNAL	COLOR	PAIR	PIN
RECEIVE DATA (REF)	WHITE	1	1
RECEIVE DATA	BLUE	1	2
SIGNAL GROUND	WHITE	2	3
CLEAR TO SEND	ORANGE	2	4
XMT CLOCK (REF)	WHITE	3	5
XMT CLOCK	GREEN	3	6
RECEIVE CLOCK (REF)	WHITE	4	7
RECEIVE CLOCK	BROWN	4	8
CLR TO SEND (B) REF	WHITE	5	9
CLR TO SEND (B)	SLATE	5	10
FRAME GROUND	RED	6	11+12
RING IND	BLUE	6	12
XMT DATA (REF)	RED	7	13
XMT DATA	ORANGE	7	14
REQ TO SEND (REF)	RED	8	15
REQ TO SEND	GREEN	8	16
DATA TERM READY	RED	9	17
DATA SET READY	BROWN	9	18
REQ TO SEND (B) REF	RED	10	19
REQ TO SEND (B)	SLATE	10	20
SPARE	BLACK	11	21
SPARE	BLUE	11	22
SPARE	BLACK	12	23
SPARE	ORANGE	12	24




CAUTION:

CARE MUST BE EXERCISED TO PREVENT UNRAVELING OF TWISTED PAIRS. IF THIS OCCURS PAIR IDENTITY WILL BE LOST. PAIR IDENTITY MUST BE MAINTAINED.


U111

Figure 3-10. Junction Box Wiring



U109

Figure 3-11. Terminal Multiplexer Repacking



U119

Figure 5-1. Voltage Bus Locations

MR6002

**UNIVAC
TERMINAL
MULTIPLEXER
TYPE 8538**


**ILLUSTRATED
PARTS BREAKDOWN**

SEPTEMBER, 1973

RESTRICTED DISTRIBUTION

The information contained in this publication is the property of Sperry Univac. It is submitted in confidence and must not be disclosed to others except in confidence with the written permission of an officer of Sperry Univac. This copy is not to be reproduced or duplicated without permission in writing from a duly authorized representative of Sperry Univac. This publication is subject to recall.

**SPERRY UNIVAC
TECHNICAL LIBRARY
VANDENBERG AFB**

SPERRY  UNIVAC

CONTENTS

Heading	Title	Page
SECTION 1. INTRODUCTION		
1-1.	General.	1-1
1-2.	Group Assembly Parts List, Section 2	1-1
1-3.	General.	1-1
1-4.	Figure and Index Column.	1-1
1-5.	Part Number Column	1-1
1-6.	Reference Designation Column	1-1
1-7.	Description Column	1-2
1-8.	Units Per Assembly Column.	1-2
1-9.	Used On Code Column.	1-2
1-10.	Reference Designation Index, Section 3	1-2
1-11.	Numerical Index, Section 4	1-2
1-12.	How to Use the Illustrated Parts Breakdown	1-3
1-13.	When the Part Location is Known.	1-3
1-14.	When the Reference Designation is Known.	1-3
1-15.	When the Part Number is Known.	1-3

SECTION 2. GROUP ASSEMBLY PARTS LIST

Terminal Multiplexer, Type 8538.	2-2
Cabinet Assy, Wired, 50/60 Hz.	2-4
Connector Panel and Backboard Assemblies, Wired.	2-6
Power Supply Assy, 50/60 Hz.	2-8
Voltage Regulator Assy	2-10
Backboard Frame Assy	2-11

SECTION 3. REFERENCE DESIGNATION INDEX

SECTION 4. NUMERICAL INDEX

ILLUSTRATIONS

Figure	Title	Page
1.	Terminal Multiplexer, Type 8538.	2-3
2.	Cabinet Assy, Wired, 50/60 Hz.	2-5
3.	Connector Panel and Backboard.	2-6
4.	Power Supply Assy, 50/60 Hz.	2-9
5.	Voltage Regulator Assembly	2-10
6.	Backboard Frame Assembly	2-11

SECTION 1

INTRODUCTION

1-1. GENERAL

This Illustrated Parts Breakdown lists and illustrates the field-replaceable parts for the UNIVAC® Terminal Multiplexer Type 8538. This breakdown is divided into four sections as described in the following paragraphs. The information contained in these sections is used for requisitioning, storing, issuing, and identifying parts.

1-2. GROUP ASSEMBLY PARTS LIST, SECTION 2

1-3. GENERAL

The Group Assembly Parts List consists of a breakdown of the Terminal Multiplexer into assemblies, subassemblies, and detail parts as shown on the related illustrations. The lowest order of disassembly is dictated by current field practices, and field personnel should not replace or disassemble parts below the order that is presented. Each assembly is followed immediately by a list of its component parts, properly indented below it to show their relationship to the assembly. Attaching parts are listed immediately following the parts which they attach. Items which are made from raw stock, such as cut lengths of wire and insulating materials, are not included in the Group Assembly Parts List.

1-4. FIGURE AND INDEX NUMBER COLUMN

Index numbers on the illustrations correspond to the index numbers in the Group Assembly Parts List. A circled index number indicates an assembly whose component parts are indexed. Assemblies or subassemblies whose component parts are shown exploded are indexed in disassembly sequence.

Some illustrations are contained on foldout sheets. When the sheets are unfolded, illustrations are fully visible and can be used concurrently with the parts list.

The digits preceding the hyphen refer to the figure in which a part or assembly is illustrated. The digits following the hyphen are the index numbers of procurable and nonprocurable parts and assemblies illustrated on the figure.

1-5. PART NUMBER COLUMN

This column contains the Univac part number for the field-replaceable parts of the unit. "No Number" indicates a group of parts for which no overall assembly number has been assigned.

1-6. REFERENCE DESIGNATION COLUMN

This column lists the reference designation of each part as it appears on the schematic diagrams for this particular unit. Mechanical parts are not identified in this type of listing.

® UNIVAC is a registered trademark of the Sperry Rand Corporation.

1-7. DESCRIPTION COLUMN

This column contains the names and descriptions of the replaceable assemblies, sub-assemblies, and detail parts of the unit. The indentation system used in presenting the descriptions shows the relationship between assemblies, subassemblies, and detail parts. For example, an item listed under indentation 3 is a component of the assembly or subassembly listed in the preceding second indentation.

Parts which attach other parts of assemblies are preceded and followed by an asterisk (*), and are listed immediately after the parts or assemblies they attach.

1-8. UNITS PER ASSEMBLY COLUMN

The quantities shown in this column for indexed items are the quantities used at the indicated location(s) or similar locations on the assembly. The quantities shown for items listed between asterisks are the quantities required to mount the specified number of assemblies, subassemblies, or parts which they attach.

The letters AR denote "as required" and are used to indicate parts of which an indeterminate number may be required. The letters REF indicate that an assembly is shown completely assembled in a preceding illustration, and is now shown exploded in the illustration where the reference appears. In this case the description has a notation that refers to the illustration in which the assembly is shown completely assembled and indexed. The entry NP indicates that the part or assembly is non-procurable.

1-9. USED ON CODE COLUMN

Part variations within the Multiplexer are indicated by numeric symbols in this column. In cases where the used On Code column has been left blank, parts listed apply to all Multiplexer configurations covered in this book.

Used On Code	Description
0	60 Hz (8538-00)
1	50 Hz (8538-01)

1-10. REFERENCE DESIGNATION INDEX, SECTION 3

The Reference Designation Index is a list of parts for which a reference designation is given in the Group Assembly Parts List. The parts are listed in alphanumeric order by reference designation; figure and index numbers are given to aid in location of the part in the Group Assembly Parts List.

1-11. NUMERICAL INDEX, SECTION 4

The Numerical Index provides a parts list in numerical order by part number. The figure and index number are given for each part to aid in location of the part in the Group Assembly Parts List.

1-12. HOW TO USE THE ILLUSTRATED PARTS BREAKDOWN

1-13. WHEN THE PART LOCATION IS KNOWN

To obtain information about a part when its location is known, the following steps should be taken:

- (a) Refer to the applicable illustration.
- (b) Compare the part with the illustration until the part is located.
- (c) Note the index number for the part.
- (d) Locate the index number in the corresponding Group Assembly Parts List.
- (e) Find the part number, reference designation (where applicable) and description opposite the index number.

1-14. WHEN THE REFERENCE DESIGNATION IS KNOWN

To locate a part when the reference designation is known, the following steps should be taken:

- (a) Locate the reference designation in the Reference Designation Index (Section 3).
- (b) Note the figure and index number shown opposite the reference designation.
- (c) Locate the figure and index number in the Group Assembly Parts List (Section 2).

1-15. WHEN THE PART NUMBER IS KNOWN

To locate a part when the part number is known, the following steps should be taken:

- (a) Locate the part number in the numerical index (Section 4).
- (b) Note the figure and index number shown opposite the part number.
- (c) Locate the figure and index number in the Group Assembly Parts List (Section 2).

SECTION 2
GROUP ASSEMBLY PARTS LIST

TERMINAL MULTIPLEXER
TYPE 8538

FIG & INDEX NO.	PART NUMBER	REF. DESIG.	1	2	3	4	5	6	7.	DESCRIPTION	NO. PER ASSY	USED ON CODE
1-	NO NUMBER									TERMINAL MULTIPLEXER, TYPE 8538	NP	
-1	2804250	00								* CABINET ASSY, WIRED, 40 HZ (SEE FIG 2 FOR DETAIL BREAKDOWN)	1	0
-1	2804255	00								* CABINET ASSY, WIRED, 50 HZ (SEE FIG 2 FOR DETAIL BREAKDOWN)	1	1
-2	2804291	00								* PANEL, COVER, TOP	1	
-3	2804248	00	A09,	A06						* CONNECTOR PANEL AND BACKBOARD ASSY, WIRED (SEE FIG 3 FOR DETAIL BREAKDOWN)	1	
										*	1	
-4	4912524	02								* SCREW, MACH, PAN HD, NO.6-32, D.375 LG	2	
-5	905818	03								* NUT, SHEET SPRING, U-TYPE, NO.6 SCREW	2	
										*		
-6	2807734	02	A02							* EXPANSION, MULTIPLEXER (PROVISION FOR FOUR)	2	
-7	2807758		A01							* INTERFACE ADAPTER	1	
-8	2807736		A01							* DIRECT CONNECTION (OPTION)	1	





FIGURE 1. TERMINAL MULTIPLEXER, TYPE RS3B

TERMINAL MULTIPLEXER
TYPE 8538

FIG & INDEX NO.	PART NUMBER 987654321AANN	REF. DESIG.	1	2	3	4	5	6	7	DESCRIPTION	NO. USED PER ON ASSY CODE
2-	2804250	00								CABINET ASSY, WIRED, 60 HZ (SEE FIG 1 FOR NEXT HIGHER ASSY)	REF 0
2-	2804255	00								CABINET ASSY, WIRED, 50 HZ (SEE FIG 1 FOR NEXT HIGHER ASSY)	REF 1
-1	2804290	00								. FRAME, CABINET, FINISHED	1
-2	2899235	00								. CATCH, MAGNETIC, SNAP-IN MOUNTED	2
-3	2804238	00								. CIRCUIT BREAKER ASSY, 60 HZ	1 0
-3	2804238	01								. CIRCUIT BREAKER ASSY, 50 HZ	1 1
-4	4912548	01								. WASHER, FLAT, ROUND, NO.6	2
-5	4912550	01								. LOCKWASHER, SPRING, HELICAL, NO.6	7
-6	4912540	01								. NUT, MACH, HEX, NO.6-32	7
-7	2899182	00								. SWITCH, INTERLOCK, SPDT, WITH CIRCUIT HOLD FEATURE	1
-8	2804288	01								. BRACKET, MOUNTING, INTERLOCK SWITCH	1
-9	4912548	00								. WASHER, FLAT, ROUND, NO.4	4
-10	4912550	00								. LOCKWASHER, SPRING, HELICAL, NO.4	4
-11	905822	02								. SCREW, TAPPING, THD FMG, PAN HD, NO.4-40NC-2A	4
-12	2804279	00								. POWER SUPPLY ASSY, 60 HZ (SEE FIG 4 FOR DETAIL BREAKDOWN)	1 0
-12	2804259	00								. POWER SUPPLY ASSY, 50 HZ (SEE FIG 4 FOR DETAIL BREAKDOWN)	1 1
-13	2899380	01								. NUT, SHEET SPRING, STEEL, NO.8-32	6
-14	4912551	02								. LOCKWASHER, EXT TOOTH, BRONZE, NO.8	1
-15	4912525	02								. SCREW, MACH, PAN HD, NO.8-32, 0.375 LG	6
-16	2804305	00								. VOLTAGE REGULATOR ASSY (SEE FIG 5 FOR DETAIL BREAKDOWN)	1
-17	4915125	02								. SPACER, SLEEVE, 0.250 LG, 0.199 ID, 0.391 OD	4
-18	4912550	03								. LOCKWASHER, SPRING, HELICAL, NO.10	4
-19	4912540	03								. NUT, MACH, HEX, NO.10-24	4
-20	2804323	00								. CABLE ASSY, VOLTAGE REGULATOR AND BACKBOARD	1
-21	2016785	00								. CLAMP, CABLE	1
-22	4912525	03								. SCREW, MACH, PAN HD, NO.8-32, 0.438 LG	1
-23	2804292	00								. BACKBOARD FRAME ASSY (SEE FIG 6 FOR DETAIL BREAKDOWN)	1
-24	4912524	02								. SCREW, MACH, PAN HD, NO.6-32, 0.375 LG	8
-5	4912550	01								. LOCKWASHER, SPRING, HELICAL, NO.6	REF
-6	4912540	01								. NUT, MACH, HEX, NO.6-32	REF
-13	2899380	01								. NUT, SHEET SPRING, STEEL, NO.8-32	REF
-15	4912525	02								. SCREW, MACH, PAN HD, NO.8-32, 0.375 LG	REF
-25	4912524	01								. SCREW, MACH, PAN HD, NO.6-32, 0.312 LG	8
-26	2899380	03								. NUT, SHEET SPRING, STEEL, NO.10-32	4
-27	2899377	01								. BUMPER, RUBBER, SCREW-ON, 3/4 INCH	4
-28	4912527	04								. SCREW, MACH, PAN HD, NO.10-32UNF-2A, 0.750 LG	4



KK102

FIGURE 2. CABINET ASSY, WIRED, 50/60 HZ

TERMINAL MULTIPLEXER
TYPE 8538

FIG & INDEX NO.	PART NUMBER	REF. DESIG.	1	2	3	4	5	6	7	DESCRIPTION	NO. USED PER ON ASSY CODE
3-	2806268	00								CONNECTOR PANEL AND BACKBOARD ASSEMBLIES, WIRED (SEE FIG 1 FOR HIGHER ASSY)	REF
-1	2806266	00	AD6							BACKBOARD, WIRED	1
-2	2806269	00								CONNECTOR PANEL, BACK	1
-3	4915135	00	J01 THRU J16							CONNECTOR, RECEPTACLE, ELECT, 25 CONTACT, FEMALE	16
-4	2899513	00								CONTACT, ELECT. CONNECTOR, FEMALE	208
-5	4915136	00	J17							CONNECTOR, RECEPTACLE, ELECT, 25 CONTACT, MALE	1
-6	2899514	00								CONTACT, ELECT. CONNECTOR, MALE	16
-7	3011815	00								SCREW ASSY, CONNECTOR CPLG, NO.4-40	34





FIGURE 3. CONNECTOR PANEL AND BACKBOARD

This page intentionally left blank.

TERMINAL MULTIPLEXER
TYPE 8538

FIG & INDEX NO.	PART NUMBER	REF. DESIG.	1	2	3	4	5	6	7	DESCRIPTION	NO. USED PER ON ASSY CODE
4-	2806279	00 A02								POWER SUPPLY ASSY, 60 HZ (SEE FIG 2 FOR NEXT HIGHER ASSY)	REF 0
4-	2806259	00 A02								POWER SUPPLY ASSY, 50 HZ (SEE FIG 2 FOR NEXT HIGHER ASSY)	REF 1
-1	2806278	00								BASE, POWER SUPPLY	1
-2	4913516	00 FLO1,FLO2								CAPACITOR, FIXED, PAPER, 100K PF, 600 VDC, +20,-10 %	2
-3	3155737	00								LINK, TERMINAL CONNECTOR, BRASS, BOARD CURRENT RATING 15 AMPS	2
-4	4912525	04								SCREW, MACH, PAN HD, NO.8-32, 0.500 LG	1
-5	4912551	02								LOCKWASHER, EXT TOOTH, BRONZE, NO.8	1
-6	4912550	02								LOCKWASHER, SPRING, HELICAL, NO.8	1
-7	4912540	02								NUT, MACH, HEX, NO.8-32	1
-8	4912552	03								LOCKWASHER, INT TOOTH, BRONZE, NO.10	4
-9	908634	01								SCREW, MACH, PAN HD, BRASS, NO.10-32UNF-2A	4
-10	2899095	01								TERMINAL, QUICK-DISCONNECT, DOUBLE-MALE, .187 SERIES	2
-11	2806312	00								CABLE ASSY, CAPACITOR	1
	2899068	00								TERMINAL, QUICK-DISCONNECT, FEMALE, .187 SERIES	1
	4914901	00								TERMINAL LUG, CRIMPING, 6 SPD, SLOTTED, 22 - 18 AWG	1
-12	2804270	00								CAPACITOR ASSY	1
-13	2899067	02	CO1, CO2, CO3							CAPACITOR, ELECT, 8200 UF, 25 VDC, +75 -10 %	3
-14	2804237	00								RETAINER, CAPACITOR	1
-15	911651	02								NUT, SHEET SPRING, U-TYPE, NO.6 SCREW	4
-16	4912524	09								SCREW, MACH, PAN HD, NO.6-32, 0.875 LG	1
-17	4912524	02								SCREW, MACH, PAN HD, NO.6-32, 0.375 LG	3
-18	3155736	34 TBO1								TERMINAL BOARD, BARRIER, 4 TERMINALS, 2.156 LG	1
-19	4912524	08								SCREW, MACH, PAN HD, NO.6-32, 0.562 LG	2
-20	4912550	01								LOCKWASHER, SPRING, HELICAL, NO.6	2
-21	4912540	01								NUT, MACH, HEX, NO.6-32	2
-22	2806280	00								COVER, TERMINAL BOARD	1
-23	4912524	09								SCREW, MACH, PAN HD, NO.6-32, 0.875 LG	2
-24	4912550	01								LOCKWASHER, SPRING, HELICAL, NO.6	2
-25	4915127	02								SPACER, SLEEVE, 5/16 ROUND, PHENOLIC, 0.171 ID	2
-26	2806316	00 T01								TRANSFORMER	1
-27	2899172	00								WASHER, FLAT, STEEL, ROUGH-CUT, 0.250 ID, 0.562 OD	12
-28	2899050	02								PIN, RETAINING, PLASTIC	12

FIG 6 INDEX NO.	PART NUMBER	REF. DESIG.	1	2	3	4	5	6	7	DESCRIPTION	NO. USED PER ON ASSY CODE
4-29	2806315	00 L03	*							CHOKE SUB-ASSY	1
-30	1915380	04	*							WASHER, FLAT, ROUND	2
-31	2899050	01	*							PIN, RETAINING, PLASTIC	2
-32	2806261	00 L02	*							CHOKE SUB-ASSY	1
-27	2899172	00	*							WASHER, FLAT, STEEL, ROUGH-CUT, 0.250 ID., 0.562 OD.	REF
-28	2899050	02	*							PIN, RETAINING, PLASTIC	REF
-33	2806261	01 L01	*							CHOKE SUB-ASSY	1
-27	2899172	00	*							WASHER, FLAT, STEEL, ROUGH-CUT, 0.250 ID., 0.562 OD.	REF
-28	2899050	02	*							PIN, RETAINING, PLASTIC	REF
-34	2806310	00	*							POWER CORD, A-C, 1, 60 HZ	1
-34	2806245	00	*							POWER CORD, A-C, 1, 50 HZ	1
-35	2899100	01	*							BUSHING, STRAIN RELIEF, RIGHT-ANGLE	1



KK 100


FIGURE 4. POWER SUPPLY ASSY, 50/60 HZ

MH4002

TERMINAL MULTIPLEXER
TYPE 8528

FIG 6
INDEX
NO. 987A5422IAHN DESIG. REF. NO. 407

FIG 6 INDEX NO.	PART NUMBER	REF. DESIG.	DESCRIPTION	NO. USED PER ASSY CODE	REF
5	2806305 00	407	VOLTAGE REGULATOR ASSY (SEE FIG 2 FOR NEXT HIGHER ASSY)	1	1
-1	2806301 00		HEAT SINK	1	1
-2	2805444 00		LOW VOLTAGE REGULATOR ASSY	1	1
-3	2804302 00		BRACKET, HEAT SINK	1	1
-4	2806294 00		SPACER, LONG, HEAT SINK	1	1
-5	2806298 00		SPACER, SHORT, HEAT SINK	1	1
-6	4912523 05		SCREW, MACH, PAN HD, NO.4-40, 0.938 LG	4	4
-7	4912524 00		SCREW, MACH, PAN HD, NO.4-32, 0.250 LG	2	2
-8	4912523 06		SCREW, MACH, PAN HD, NO.4-40, 0.500 LG	3	3
-9	4914072 05		WASHER, PHENOLIC, 0.031 THK, 0.120 ID, 0.250 OD	3	3




KK104

FIGURE 5. VOLTAGE REGULATOR ASSEMBLY

GROUP ASSEMBLY PARTS LIST

FIG & INDEX NO.	PART NUMBER	REF. DESIG.	1	2	3	4	5	6	7	DESCRIPTION	NO. USED PER ON ASSY CODE
6-	2806292	00								BACKBOARD FRAME ASSY (SEE FIG 2 FOR NEXT HIGHER ASSY)	REF
-1	2806284	00								• BRACKET PLATE, BACKBOARD	1
-2	2806293	00								• PANEL, RIGHT SIDE	1
-3	2806294	00								• PANEL, LEFT SIDE	1
-4	2806304	00								• CARD GUIDE ASSY	3
										•	
-5	4912524	02								• SCREW, MACH, PAN HD, NO.6-32, 0.375 LG	10
-6	905818	04								• NUT, SHEET SPRING, U-TYPE, NO.6 SCREW	2
-7	905818	03								• NUT, SHEET SPRING, U-TYPE, NO.6 SCREW	8
-8	3004054	00								• NUT, SHEET SPRING	8
										•	



KKIOS

FIGURE 6. BACKBOARD FRAME ASSEMBLY

SECTION 3

REFERENCE DESIGNATION INDEX

REF DESIG	FIG & INDEX NO.	REF DESIG	FIG & INDEX NO.	REF DESIG	FIG & INDEX NO.	REF DESIG	FIG & INDEX NO.
A1.....	1-7	A7.....	5-35	FLO1,FL2.	4-2	L3.....	4-29
A1.....	1-8	A8.....	2-12	J18.....	3-3	S1.....	2-7
A2.....	1-6	AD9.,A6.	1-3	J17.....	3-5	T1.....	4-26
A2.....	4-7	C3.....	4-13	J01,THRU	3-3	T81.....	4-18
A6.....	3-1	CB1.....	2-3	L1.....	4-33		
A7.....	2-14	CO1.,CO2.	4-13	L2.....	4-32		

SECTION 4
NUMERICAL INDEX

PART NUMBER	FIG & INDEX NO.	PART NUMBER	FIG & INDEX NO.	PART NUMBER	FIG & INDEX NO.			
905818	03	1-5	2806296	00	5-4	4912524	02	1-4
905818	03	6-7	2806298	00	5-5	4912524	02	2-24
905818	04	6-6	2806301	00	5-1	4912524	02	4-17
905822	02	2-11	2806302	00	5-3	4912524	02	6-5
908634	01	4-9	2806304	00	6-4	4912524	08	4-19
911651	02	4-15	2806305	00	2-16	4912524	09	4-16
2016785	00	2-21	2806305	00	5-35	4912524	09	4-23
2805444	00	5-2	2806310	00	4-34	4912525	02	2-15
2806237	00	4-14	2806312	00	4-11	4912525	03	2-22
2806238	00	2-3	2806315	00	4-29	4912525	04	4-4
2806238	01	2-3	2806316	00	4-26	4912527	04	2-28
2806245	00	4-34	2806323	00	2-20	4912540	01	2-6
2806250	00	1-1	2807734	02	1-6	4912540	01	4-21
2806250	00	2-8	2807736		1-8	4912540	02	4-7
2806255	00	1-1	2807758		1-7	4912540	03	2-19
2806255	00	2-8	2899050	01	4-31	4912548	00	2-9
2806259	00	2-12	2899050	02	4-28	4912548	01	2-4
2806259	00	4-7	2899067	02	4-13	4912550	00	2-10
2806261	00	4-32	2899068	00	4-11	4912550	01	2-5
2806261	01	4-33	2899095	01	4-10	4912550	01	4-20
2806266	00	3-1	2899100	01	4-35	4912550	01	4-24
2806268	00	1-3	2899172	00	4-27	4912550	02	4-6
2806268	00	3-28	2899182	00	2-7	4912550	03	2-18
2806269	00	3-2	2899235	00	2-2	4912551	02	2-14
2806270	00	4-12	2899377	01	2-27	4912551	02	4-5
2806278	00	4-1	2899380	01	2-13	4912552	03	4-8
2806279	00	2-12	2899380	03	2-26	4913516	00	4-2
2806279	00	4-7	2899513	00	3-4	4914901	00	4-11
2806280	00	4-22	2899514	00	3-6	4915125	02	2-17
2806284	00	6-1	3006054	00	6-8	4915127	02	4-25
2806288	01	2-8	3011815	00	3-7	4915135	00	3-3
2806290	00	2-1	3155736	34	4-18	4915136	00	3-5
2806291	00	1-2	3155737	00	4-3	4915360	04	4-30
2806292	00	2-23	4912523	05	5-4	4916072	05	5-9
2806292	00	6-9	4912523	06	5-8	NO NUMBER		1-
2806293	00	6-2	4912524	00	5-7			
2806294	00	6-3	4912524	01	2-25			

MR6014

**UNIVAC
UNISCOPE 100
DISPLAY
TERMINAL
TYPE 3536 -06**

**INSTALLATION
PROCEDURES**

JULY, 1973

RESTRICTED DISTRIBUTION

The information contained in this publication is the property of Sperry Univac. It is submitted in confidence and must not be disclosed to others except in confidence with the written permission of an officer of Sperry Univac. This copy is not to be reproduced or duplicated without permission in writing from a duly authorized representative of Sperry Univac. This publication is subject to recall.

**SPERRY UNIVAC
TECHNICAL LIBRARY
VANDENBERG AFB**

SPERRY  UNIVAC

CONTENTS

Heading	Title	Page
SECTION 1. INTRODUCTION		
1-1.	Scope	1-1
1-2.	Maintenance Aids	1-1
1-3.	Reference Documentation	1-1
1-4.	Display Terminal Description	1-1
1-5.	Mounting Considerations	1-2
1-6.	Signal Cable Wiring	1-2

SECTION 2. INSTALLATION

2-1.	Introduction	2-1
2-2.	Equipment Placement	2-1
2-3.	Unpacking	2-1
2-4.	Installation Procedure	2-4

SECTION 3. PRINTED CIRCUIT BOARD STRAPPING

3-1.	General	3-1
3-2.	Printed Circuit Board Interchangeability	3-9

SECTION 4. REPACKING

4-1.	General	4-1
------	-------------------	-----

ILLUSTRATIONS

Figure	Title	Page
1-1.	Sample System Configurations	1-5
2-1.	UNISCOPE 100 Display Terminal Cover Removal	2-7
2-2.	UNISCOPE 100 Display Terminal Rear View	2-9
2-3.	UNISCOPE 100 Display Terminal Bottom View	2-11
2-4.	Voltage Selector Strapping	2-13
2-5.	Voltage Bus Locations	2-15
2-6.	UNISCOPE 100 Display Terminal Keyboard	2-17
3-1.	Synchronous Interface Selection	3-11
3-2.	Asynchronous Interface Selection	3-13
3-3.	Direct Interface Board Strapping	3-15
3-4.	Regulator/Control Strapping	3-15
3-5.	Control Board Strapping	3-17
4-1.	UNISCOPE 100 Display Terminal Cover Removal	4-3
4-2.	UNISCOPE 100 Display Terminal Rear View	4-5
4-3.	UNISCOPE 100 Display Terminal Bottom View	4-7

TABLES

Table	Title	Page
1-1.	UNIVAC System Cables	1-2
2-1.	Unpacking Procedure.	2-2
2-2.	Installation Procedure	2-4
2-3.	Power Supply Voltage Ranges.	2-6
3-1.	Display Terminal Strapping - By Printed Circuit Board	3-1
3-2.	Strapping Procedure for Synchronous Operation	3-3
3-3.	Strapping Procedure for Asynchronous Operation	3-3
3-4.	RID Address Codes.	3-4
3-5.	SID Address Codes.	3-6
3-6.	Synchronous Interface Selection.	3-7
3-7.	Direct Interface Baud Rate Selection	3-8
3-8.	IEM Synchronous Interface Connection	3-8
3-9.	Asynchronous Interface Selection	3-8
3-10.	Asynchronous Baud Rate Selection	3-8
3-11.	IEM Asynchronous Interface Connection.	3-9
3-12.	Interchangeable Board Pairs.	3-9
4-1.	Cleaning Materials and Equipment	4-1
4-2.	Repacking Procedure.	4-1

SECTION 1
INTRODUCTION

1-1. SCOPE

This book contains information for installing the UNIVAC[®] UNISCOPE[®] 100 Display Terminal Type 3536-06 (Display Terminal). The contents of each section are as follows:

- Section 2. Installation
- Section 3. Printed Circuit Board Strapping
- Section 4. Repacking

1-2. MAINTENANCE AIDS

The following special equipment is required for installation of a Display Terminal:

- Volt-ohmmeter 3001444-00 (or equivalent)
- Card extender assembly 2806444-00
- Card extractor 2808033-00
- Strapping connector 2805281-17 (8 each)

1-3. REFERENCE DOCUMENTATION

SP 2012 Guide for Planning the Installation of a UNISCOPE 100 Display Terminal

1-4. DISPLAY TERMINAL DESCRIPTION

The Display Terminal is an input/output terminal device used to receive data from and transmit data to a centrally located processor, or another terminal. If the processor is at a remote location this data is transmitted and received over telephone lines via a modem.

The Display Terminal cabinet, together with the attached keyboard, houses all of the electronics required for Display Terminal operation.

The Display Terminal is capable of operating other input/output devices. Available optional auxiliary devices for the Display Terminal include:

- Type 0866 Tape Cassette System
- Type 8541-06, -07 Communications Output Printer

[®] UNIVAC is a registered trademark of the Sperry Rand Corporation. Another Sperry Rand trademark appearing in this book is: UNISCOPE.

UNISCOPE 100 Display Terminal

1-5. MOUNTING CONSIDERATIONS

The Display Terminal is designed to mount on any flat, smooth surface (such as a desk top) which affords an operator comfortable access to the keyboard controls and visibility of the display screen. A minimum of four inches clearance should be allowed for the right and left sides and rear of the Display Terminal. Operator clearance to the front of the unit should be sufficient for comfortable operation of the keyboard controls.

1-6. SIGNAL CABLE WIRING

The Display Terminal is connected within a system by means of signal cables. The cables used are dependent upon system configuration. A sample system configuration is shown in figure 1-1, sheets 1 and 2, and more detailed system cabling requirements are given in SP 2012, "Guide for Planning the Installation of a UNISCOPE 100 Display Terminal". Table 1-1 lists the standard UNIVAC cables, with available lengths, used for connections between devices. Item numbers correspond to reference designations on figure 1-1.

CAUTION

Finger-tighten the jackscrews on all signal connectors to ensure even contact between mating parts. Over-tightening makes the connectors difficult to remove for servicing at a later time and may cause damage to connector pins.

Table 1-1. UNIVAC System Cables

Item	Part Number	Description
1	2805096-XX	Standard unshielded cable used to connect Display Terminal with Multiplexer, modem, or DCM. Male end female ends. Maximum length to modem is 50 feet. Available lengths: 3 feet 5 feet to 100 feet in 5-foot increments 100 feet to 200 feet in 10-foot increments 200 feet to 300 feet in 20-foot increments
2	2807723-XX	Unshielded cable used to connect Display Terminal or Multiplexer with junction box assembly 2807819. One end open and one female end. Available lengths: 3 feet 5 feet to 100 feet in 5-foot increments 100 feet to 200 feet in 10-foot increments 200 feet to 300 feet in 20-foot increments
3	2807819-00	Junction box assembly, used for onsite cable fabrication.

Table 1-1. UNIVAC System Cables (Cont)

Item	Part Number	Description
4	2807724-XX	<p>Unshielded cable used to connect junction box assembly with modem, Multiplexer, or DCM. One end open and one male end.</p> <p>Available lengths:</p> <p>3 feet 5 feet to 100 feet in 5-foot increments 100 feet to 200 feet in 10-foot increments 200 feet to 300 feet in 20-foot increments</p>
5	2807725-XX	<p>Shielded cable used for long distance runs between junction box assemblies. Designed for aerial or duct installation. Both ends open.</p> <p>Available lengths:</p> <p>300 feet to 5000 feet in 50-foot increments</p>
6	2807765-XX	<p>Shielded cable used for direct burial long distance runs between junction box assemblies. (Junction boxes are not buried.) Both ends open.</p> <p>Available lengths:</p> <p>300 feet to 5000 feet in 50-foot increments</p>
7	2807748-XX	<p>Unshielded cable used to connect Display Terminal or Multiplexer directly to a CTMC. Male and female ends.</p> <p>Available lengths:</p> <p>3 feet 5 feet to 100 feet in 5-foot increments 100 feet to 200 feet in 10-foot increments 200 feet to 300 feet in 20-foot increments</p>
8	2807754-XX	<p>Unshielded cable used to connect junction box assembly to CTMC. One end open and one male connector.</p> <p>Available lengths:</p> <p>3 feet 5 feet to 100 feet in 5-foot increments 100 feet to 200 feet in 10-foot increments 200 feet to 300 feet in 20-foot increments</p>
9	2807867-XX	<p>Unshielded cable used to connect Display Terminal or Multiplexer directly to DCS. Male and female ends.</p> <p>Available lengths:</p> <p>5 feet to 50 feet in 5-foot increments.</p>
10	2807868-XX	<p>Unshielded cable used to connect junction box assembly to DCS. One end open and one male connector.</p> <p>Available lengths:</p> <p>5 feet to 50 feet in 5-foot increments</p>

UNISCOPE 100 Display Terminal

Table 1-1. UNIVAC System Cables (Cont)

Item	Part Number	Description
11	2807716-XX	Unshielded cable used to connect Display Terminal with an auxiliary device. Male and female ends. Available lengths: 5 feet 10 feet to 200 feet in 10-foot increments




Figure 1-1. Sample System Configurations

SECTION 2

INSTALLATION

2-1. INTRODUCTION

This section contains instructions for unpacking, installing, and checking the UNISCOPE 100 Display Terminal Type 3536-06. The procedures outlined are designed to allow the Customer Engineer to install and set-up the Display Terminal in a minimum amount of time.

2-2. EQUIPMENT PLACEMENT

The carrier is responsible for moving the equipment to its approximate location in the prescribed area. The customer should be present while the carrier is unloading and spotting the equipment to ensure that it is not handled roughly and that improper lifting devices are not used.

CAUTION

Do not use a fork-lift to move equipment containers. The Display Terminal is packed in a polystyrene container which should be handled with care.

The customer should instruct the carrier as to initial unit placement at the operating location. Correct placement at this time will avoid problems in unpacking later. After the unit is unloaded and placed in the approximate operating location, inspect the container for signs of damage that may have occurred during shipment.

If damage is found, or a portion of the shipment is missing, this must be noted on the bill of lading. Also any equipment which was handled roughly or dropped during unloading or placement should be so noted on the bill of lading, even though no damage may be apparent. This aids in filing a claim if damage is discovered during unpacking.

2-3. UNPACKING

It is recommended that two men be available for lifting the Display Terminal during unpacking to avoid possible damage to the unit.

The procedure for unpacking the unit is listed in table 2-1.

Detailed procedures for removal and replacement of the major component assemblies of the Display Terminal are described in MR6015 UNISCOPE 100 Display Terminal Type 3536-06 Servicing Data and Adjustments.

NOTE

Be sure to save packing material, shipping bags, and the two container halves removed in table 2-1, in the event that the Display Terminal should require shipment to a new location. The number of sets of shipping material to be retained should be determined in consultation with the customer. The procedure for repacking the unit is provided in Section 4.

UNISCOPE 100 Display Terminal

Table 2-1. Unpacking Procedure

Step	Procedure	Reference
1	Place Display Terminal container on floor.	
2	Cut bands holding container halves together and remove top half of container.	
3	Remove bagged communications cable (if present) from top of Display Terminal.	
4	Remove and unpack Display Terminal and keyboard. Check for visible damage to the units.	
5	Remove tape securing power cord and faceplate to Display Terminal.	Figure 2-1 Page 2-7
6	Remove faceplate by releasing four tension fasteners located near corners of CRT face. Apply pressure at these points and pull straight away until faceplate clears front panel WAIT, INTENSITY, and POWER controls and indicators.	Figure 2-1
7	Release top cover by rotating fastener screws counterclockwise until spring clips release.	Figure 2-1
8	Lift top cover and swing back until cover clears two hinge slots at bottom rear of unit.	
9	Slide side panel back approximately 1/2 inch to release front clip, lift up and slightly outward to release bottom clips and remove.	Figure 2-1
	NOTE	
	Make certain that side panels are on the outside of the top cover lip when assembling.	
10	If front panel WAIT, INTENSITY, and POWER knobs, and WAIT, POWER, MESSAGE WAITING, and MESSAGE INCOMPL lights are not installed, they will be found in a separate shipping bag in a cavity at rear of container.	Figure 2-1
11	Install knobs and lights described in step 10.	Figure 2-1
12	Remove foam packing from top of chimney assembly and rear of component board housing assembly.	Figure 2-2 Page 2-9
13	Press chimney retainers at front and rear of chimney assembly and lift chimney assembly vertically.	Figure 2-2
14	Remove foam packing from inside of chimney assembly.	Figure 2-1
15	With one hand under large deflection coil on CRT, gently lift tube and remove foam packing from under CRT (top of power supply housing).	Figure 2-2
16	Pull keyboard cable from Display Terminal housing and attach to connector strip at rear of keyboard.	Figure 2-1

Table 2-1. Unpacking Procedure (Cont)

Step	Procedure	Reference
17	Place keyboard in approximate mounting position and rotate thumbscrews clockwise into retaining nuts on Display Terminal chassis until keyboard is firmly attached to Display Terminal cabinet.	Figure 2-1
18	Inventory equipment and fill in appropriate sections of Inventory and Inspection Report shipped with each unit. Notify branch office of any damage or shortage.	
19	If installation is to be done at this time perform the procedure provided in table 2-2. If installation is not to be done at this time perform step 15.	
20	Replace faceplate and cover assembly.	Figure 2-1

2-4. INSTALLATION PROCEDURE

The procedure for installing the Display Terminal is provided in table 2-2.

Table 2-2. Installation Procedure

Step	Procedure	Reference
1	Remove faceplate, top cover, and side panels, if in place.	Figure 2-1
2	Check for broken or cracked connectors or terminal boards, and bent or shorted connector or wire-wrap pins. Pay particular attention to areas near circuit breakers and bus bars.	
3	Verify that all push-on terminals are securely attached to deflection coil terminals, switches, potentiometers, indicators, and so on.	
4	Verify that high voltage lead is connected to CRT.	Figure 2-2
5	Inspect for metal chips, wire cuttings, solder drippings, or other loose particles of foreign material.	
6	Verify that all cables are securely plugged into the appropriate connectors.	
7	Remove all printed circuit boards from Display Terminal (except power supply).	
8	Place Display Terminal on right side.	Figure 2-3 Page 2-11
	NOTE	
	Line voltages may vary over a period of time. The nominal operating voltage at the site should be determined before strapping as described in step 9. The lowest range which contains the nominal operating voltage should be selected.	
9	Determine voltage level at operating location and strap voltage selector appropriately.	Figure 2-4 Page 2-13
10	Fill out the Configuration Description Record shipped with each unit. Follow instructions contained on form. When future field change orders (FCO's) are installed, a record should be kept on the reverse side of form.	
11	Set circuit breaker CBO1 to OFF.	Figure 2-1
12	Set enable/disable switch SO1 to "disable" (forward) position.	Figure 2-1
	NOTE	
	Units are shipped from the factory strapped for 115 VAC, with an H. Hubbell 5251, 5252, or equivalent 60 Hz power plug. On units to be used with 230 VAC, a 50 Hz primary power plug must first be installed. Wires are color coded as follows:	
	BLACK - "Hot"; WHITE - Neutral; GREEN - Ground.	

Table 2-2. Installation Procedure (Cont)

Step	Procedure	Reference
13	Connect power cord to primary power source.	
14	Set circuit breaker CBO1 to ON.	Figure 2-1
	<div style="border: 1px solid black; padding: 2px; display: inline-block;">WARNING</div>	
	When step 15 is performed primary power is applied to the Display Terminal. Use caution in performing the remainder of this procedure.	
15	Press and release front panel POWER pushbutton S03. Note indicator lamp in S03 lights as power is applied to Display Terminal.	Figure 2-1
16	Verify that fan B01 is operating and airflow is unobstructed.	
17	Verify that power supply voltages are within "no load" values.	Table 2-3
18	Perform required Display Terminal strapping.	Section 3
19	Set circuit breaker CBO1 to OFF and insert component boards in correct positions. If boards do not insert easily with finger pressure check connectors for foreign particles or bent contacts.	Figure 2-1 Figure 2-2
20	Set circuit breaker CBO1 to ON.	Figure 2-1
21	With all component boards installed, verify operating range power supply voltages.	Table 2-3 Figure 2-5 Page 2-15
22	Set enable/disable switch S01 to "enable" (rear) position.	Figure 2-1
	NOTE	
	Perform steps 24 through 29 and omit step 23 for units with protect format. For units without protect format perform step 23, omit steps 24 through 27, and perform steps 28 and 29.	
23	Press and release CURSOR TO HOME and ERASE TO END OF DISPL keys. After a warm-up of approximately 30 seconds, cursor should appear at upper left hand corner of display screen. If cursor does not appear, rotate front panel INTENSITY control R01 clockwise until cursor appears.	Figure 2-1 Figure 2-6 Page 2-17
	NOTE	
	Steps 24 through 27 are performed to clear all data, both protected and unprotected, from the Display Terminal memory.	
24	Press and release CURSOR TO HOME and ERASE DISPL keys.	Figure 2-6

This space reserved for notes.




Figure 2-1. UNISCOPE 100 Display Terminal Cover Removal

UNISCOPE 100 Display Terminal

Installation

This page intentionally left blank.

This space reserved for notes.

Installation




Figure 2-2. UNISCOPE 100 Display Terminal Rear View

UNISCOPE 100 Display Terminal

This page intentionally left blank.

This space reserved for notes.

Installation




Figure 2-3. UNISCOPE 100 Display Terminal Bottom View

M66014

2-11

UNISCOPE 100 Display Terminal

This page intentionally left blank.

This space reserved for notes.

Installation




Figure 2-4. Voltage Selector Strapping

UNISCOPE 100 Display Terminal

This page intentionally left blank.

This space reserved for notes.

Installation




Figure 2-5. Voltage Bus Locations

MS6014

2-15

UNISCOPE 100 Display Terminal

This page intentionally left blank.




Figure 2-6. UNISCOPE 100 Display Terminal Keyboard

SECTION 3

PRINTED CIRCUIT BOARD STRAPPING

3-1. GENERAL

This section contains procedures for strapping the printed circuit boards of the UNISCOPE 100 Display Terminal Type 3536-06. The Display Terminal may be operated in either a synchronous or an asynchronous mode and in a variety of configurations. Table 3-1 provides a list of strapping connections which may be performed in the field and references the tables which provide strapping details.

NOTE

If the unit is to be installed in a 3760 Communications Controller Console only the strapping described in table 3-1 for the power supply board (A2) and the regulator/control board (A3) should be performed.

Table 3-1. Display Terminal Strapping - By Printed Circuit Board

Board	Description	Strapping Function	Reference	
			Figure	Table
A2	Power Supply	Operating voltage and average level	Section 2	
A3	Regulator/ Control	Use with 64 or 96 character A8 board	3-4 Page 3-15	----
A9	Control	Protect Format	3-5 Page 3-17	----
A11	I/O-1	RID/SID Selection	3-1,3-2 Page 3-11,3-13	3-4,3-5
		System use (UNIVAC/IBM)	3-1,3-2	3-8,3-11
A12	I/O-2	Interface mode selection	3-1,3-2	3-6,3-9
		Baud rate (direct-synchronous)	3-3 Page 3-15	3-7
		Baud rate (asynchronous)	3-1,3-2	3-10
		System use (UNIVAC/IBM)	3-1,3-2	3-8,3-11

Table 3-2 provides a step-by-step procedure for strapping the Display Terminal for synchronous operation, and table 3-3 provides a step-by-step procedure for strapping the Display Terminal for asynchronous operation.

The Display Terminal may already be strapped to any one of a variety of configurations. Therefore, check carefully to ensure that each strap conforms to the requirements for the system in which the unit is being installed.

It should be noted that the strapping connectors resemble IC packs; however, each pin on one side of a strapping connector feeds through the body of the connector and is electrically common with the corresponding pin of the other side of the connector. Thus, the pins on either side of the strapping connector may be lifted for strapping.

UNISCOPE 100 Display Terminal

The strapping connectors are usually installed with the pins slightly compressed to fit the strapping socket. Lifting too many pins on one side of the strapping connector may cause the remaining pins on that side to become disengaged from the socket. It is recommended that not more than four pins be lifted on one side of a strapping connector.

Three identifier codes used by the processor to address units in a system -- a Remote Identifier (RID), Station Identifier (SID), and Device Identifier (DID) -- are discussed briefly here and more completely in UP-7807, "UNISCOPE 100 Display Terminal Programmers Reference." Each identifier corresponds to an addressing "level" as follows:

- (a) RID is the first level of addressing. In a system using the UNIVAC Type 8538 Terminal Multiplexer, the RID code is normally used to address a group of Display Terminals connected to a single line or data channel. However, all units operating through a given Multiplexer do not have to respond to the same RID.
- (b) SID is the second level of addressing and is normally used to address a specific Display Terminal within a group which responds to a given RID.
- (c) DID is the third level of addressing and is used to identify an auxiliary device connected to a specific Display Terminal. DID codes are selected at the auxiliary device rather than at the Display Terminal.

RID and SID codes are selected at the Display Terminal by means of strapping connectors which plug into input/output (I/O) board no. 1 (A11). Note that in tables 3-4 and 3-5 one character from each group (40, RID and 120, SID) has been selected as a General Identifier (GID). General identifiers can be used in any or all of the identifier positions of a message. For example if a GID is used in the RID address position of a computer message, all groups and any connected displays will recognize that GID as the RID portion of their address. All UNIVAC terminal devices are hard-wired to respond to the GID selection codes.

Strapping connector 2805281-17 is used to make the connector described in this section. Pins are bent up on 2805281-17 as listed in the tables to make connector part numbers 2807774-00 through 2807774-70.

The Display Terminal can be connected directly to a central processor equipped with a Communication Terminal Module Controller (CTMC) or Data Communication Subsystem (DCS) by installing direct interface board 2808063 (A12). The CTMC provides interface to a UNIVAC 400 or 1100 Series computer and the DCS provides interface to a UNIVAC 9000 Series computer. An appropriate baud rate must be selected by connecting straps on 2808063 as listed in table 3-7. The direct interface board can be used in conjunction with any synchronous I/O no. 1 board (A11).

Synchronous strapping is described for a noninverted clock signal as specified in MIL-STD-188C. MIL-STD-188B specified either an inverted or noninverted clock signal, and modems contain a provision which allows either configuration.

The modem configuration present in the system in which the Display Terminal is being installed should be determined and changed to conform to the MIL-STD-188C (noninverted) clock signal if necessary.

Table 3-2. Strapping Procedure for Synchronous Operation

Step	Procedure	Figure	Table
1	Strap RID selection on input/output (I/O) board no. 1 (A11), location Z72.	3-1	3-4
2	Strap SID selection on I/O board no. 1 (A11), location Z60.	3-1	3-5
3	Strap interface selection on I/O board no. 2 (A12).	3-1	3-6
4	Strap baud rate selection on direct interface board 2808063 (A12) if applicable.	3-1	3-7
5	Strap for IBM system operation (if applicable) on I/O board no. 1 (A11) and I/O board no. 2 (A12).	3-1	3-8

Table 3-3. Strapping Procedure for Asynchronous Operation

Step	Procedure	Figure	Table
1	Strap RID selection on I/O board no. 1 (A11), location Z72.	3-2	3-4
2	Strap SID selection on I/O board no. 1 (A11), location Z60.	3-2	3-5
3	Strap interface selection on I/O board no. 2 (A12).	3-2	3-9
4	Strap baud rate selection on I/O board no. 2 (A12), location Z133.	3-2	3-10
5	Strap for IBM system operation (if applicable) on I/O board no. 1 (A11) and I/O board no. 2 (A12).	3-2	3-11

Table 3-4. RID Address Codes

RID Code (Octal)	Connector Part Number	Bend Pins
40 (GID)	2807774-01	3-5-7-9-11-13
41	2807774-02	3-5-7-9-13
42	2807774-03	3-7-9-11-13
43	2807774-04	3-7-9-13
44	2807774-05	5-7-9-11-13
45	2807774-06	5-7-9-13
46	2807774-07	7-9-11-13
47	2807774-08	7-9-13
50	2807774-09	3-5-7-9-11
51	2807774-10	3-5-7-9
52	2807774-11	3-7-9-11
53	2807774-12	3-7-9
54	2807774-13	5-7-9-11
55	2807774-14	5-7-9
56	2807774-15	7-9-11
57	2807774-16	7-9
60	2807774-17	3-5-9-11-13
61	2807774-18	3-5-9-13
62	2807774-19	3-9-11-13
63	2807774-20	3-9-13
64	2807774-21	5-9-11-13
65	2807774-22	5-9-13
66	2807774-23	9-11-13

Table 3-4. RID Address Codes (Cont)

RID Code (Octal)	Connector Part Number	Bend Pins
67	2807774-24	9-13
70	2807774-25	3-5-9-11
71	2807774-26	3-5-9
72	2807774-27	3-9-11
73	2807774-28	3-9
74	2807774-29	5-9-11
75	2807774-30	5-9
76	2807774-31	9-11
77	2807774-32	9
100	2807774-33	1-3-5-7-11-13
101	2807774-34	1-3-5-7-13
102	2807774-35	1-3-7-11-13
103	2807774-36	1-3-7-13
104	2807774-37	1-5-7-11-13
105	2807774-38	1-5-7-13
106	2807774-39	1-7-11-13
107	2807774-40	1-7-13
110	2807774-41	1-3-5-7-11
111	2807774-42	1-3-5-7
112	2807774-43	1-3-7-11
113	2807774-44	1-3-7
114	2807774-45	1-5-7-11
115	2807774-46	1-5-7
116	2807774-47	1-7-11
117	2807774-48	1-7

Table 3-5. SID Address Codes

SID Code (Octal)	Connector Part Number	Bend Pins
120 (GID)	2807774-17	3-5-9-11-13
121	2807774-21	5-9-11-13
122	2807774-25	3-5-9-11
123	2807774-29	5-9-11
124	2807774-18	3-5-9-13
125	2807774-22	5-9-13
126	2807774-26	3-5-9
127	2807774-30	5-9
130	2807774-19	3-9-11-13
131	2807774-23	9-11-13
132	2807774-27	3-9-11
133	2807774-31	9-11
134	2807774-20	3-9-13
135	2807774-24	9-13
136	2807774-28	3-9
137	2807774-32	9
140	2807774-49	1-3-5-11-13
141	2807774-50	1-5-11-13
142	2807774-51	1-3-5-11
143	2807774-52	1-5-11
144	2807774-53	1-3-5-13
145	2807774-54	1-5-13
146	2807774-55	1-3-5
147	2807774-56	1-5
150	2807774-57	1-3-11-13
151	2807774-58	1-11-13
152	2807774-59	1-3-11
153	2807774-60	1-11
154	2807774-61	1-3-13

Table 3-5. SID Address Codes (Cont)

SID Code (Octal)	Connector Part Number	Bend Pins
155	2807714-62	1-13
156	2807714-63	1-3
157	2807714-64	1

Table 3-6. Synchronous Interface Selection

System Operation	Connector Location on A12	Connector Part Number	Bend Pins
RS232C/V.24	Z24	2807714-00	None
	Z48	2807714-40	1-7-13
Display Terminal to Modem	Z60	2807714-00	None
	Z72	2807714-14	5-7-9
	Z84	2807714-00	None
MIL-STD-188C	Z36	2807714-69	4-7
	Z48	2807714-09	3-5-7-9-11
Display Terminal to Modem	Z60	2807714-70	2-3-4-6-7-8
	Z72	2807714-14	5-7-9
	Z96	2807714-00	None
Multiplexer	Z48	2807714-09	3-5-7-9-11
	Z60	2807714-00	None
Display Terminal to Multiplexer	Z72	2807714-33	1-3-5-7-11-13
	Z84	2807714-00	None
Modem	Z48	2807714-09	3-5-7-9-11
	Z60	2807714-00	None
Long Distance Interface	Z72	2807714-14	5-7-9
	Z84	2807714-00	None

Table 3-7. Direct Interface Baud Rate Selection

Baud Rate	Strapping Connection at Location X284
2400 bps	Pin 3 to Pin 12
4800 bps	Pin 1 to Pin 14
9600 bps	Pin 2 to Pin 13

Table 3-8. IEM Synchronous Interface Connection

I/O Board No. 1 (A11)	I/O Board No. 2 (A12)
Strap:	Strap:
E1 to E2	A to B
E3 to E4	C to D

Table 3-9. Asynchronous Interface Selection

System Operation	Connector Location on A12	Connector Part Number	Bend Pins	
RS232C/V.24	Z24	2807714-00	None	
	Z48	2807714-65	3-7-13	
	Z60	2807714-64	1	
Display Terminal to Modem	Z72	2807714-15	7-9-11	
	Z84	2807714-00	None	
	MIL-STD-188C	Z36	2807714-00	None
		Z48	2807714-66	1-5-7-9-11
Display Terminal to Modem	Z72	2807714-15	7-9-11	
	Z96	2897714-00	None	
	Multiplexer	Z48	2807714-66	1-5-7-9-11
Z60		2807714-00	None	
Display Terminal to Multiplexer	Z72	2807714-33	1-3-5-7-11-13	
	Z84	2807714-00	None	
	Modem	Z48	2807714-66	1-5-7-9-11
Z60		2807714-64	1	
Long Distance Interface	Z72	2807714-15	7-9-11	
	Z84	2807714-15	7-9-11	

Table 3-10. Asynchronous Baud Rate Selection

Baud Rate	Connector Part Number	Bend Pins
300 bps	2807714-67	1-3-9-11-13
600 bps	2807714-34	1-3-5-7-13
1200 bps	2807714-19	3-9-11-13
1600 bps	2807714-42	1-3-5-7
1800 bps	2807714-38	1-5-7-13
2400 bps	2807714-68	3-5-7-13

Table 3-11. IBM Asynchronous Interface Connection

I/O Board No. 1 (A11)	I/O Board No. 2 (A12)
Strap:	Strap:
E1 to E2	E1 to E2
E3 to E4	

3-2. PRINTED CIRCUIT BOARD INTERCHANGEABILITY

Several printed circuit boards within the Display Terminal are assigned part numbers as a result of strapping provisions contained on the boards. For, example; input/output board no. 1 (A11), synchronous - UNIVAC, is the same board as input/output board no. 1, synchronous IBM except for the connection of the IBM straps listed in table 3-8. Interchangeable boards are listed in table 3-12.

Table 3-12. Interchangeable Board Pairs

Board	Description	Part Number	Strapping	Reference		Remarks
				Figure	Table	
A11	I/O-1 Sync-UNIVAC	2808054	E1-E2, E3-E4 OUT	3-1	---	
A11	I/O-1 Sync-IBM	2808056	E1, E2 E3-E4 IN	3-1	3-8	
A12	I/O-2 Sync-UNIVAC	2808055	A-B C-D OUT	3-1	---	
A12	I/O-2 Sync-IBM	2808057	A-B C-D IN	3-1	3-8	
A11	I/O-1 Async-UNIVAC	2808059	E1-E2 E3-E4 OUT	3-2	---	
A11	I/O-1 Async-IBM	2808061	E1-E2 E3-E4 IN	3-2	3-11	
A12	I/O-2 Async-UNIVAC	2808060	E1-E2 OUT	3-2	---	
A12	I/O-2 Async-IBM	2808062	E1-E2 IN	3-2	3-11	
A3	Regulator/ Control	2807934	E1-E2 IN	3-4	---	Used with A8 board 2807786 (64C)
A3	Regulator/ Control	2807934	E1-E2 OUT	3-4	---	Used with A8 board 2807816 (96C)
A9	Control, with Protect Format	2808052	E20- E23 IN	3-5	---	A8, A17, must be Protect Format
A9	Control, without Protect Format	2808053	E20- E23 OUT	3-5	---	A8, A17, must not be Protect Format

UNISCOPE 100 Display Terminal

This page intentionally left blank.

This space reserved for notes.

Printed Circuit Board Strapping




Figure 3-1. Synchronous Interface Selection

UNISCOPE 100 Display Terminal

This page intentionally left blank.




Figure 3-2. Asynchronous Interface Selection

UNISCOPE 100 Display Terminal

This page intentionally left blank.

This space reserved for notes.

Printed Circuit Board Strapping




Figure 3-3. Direct Interface Board Strapping




Figure 3-4. Regulator/Control Strapping

MS6014

UNISCOPE 100 Display Terminal

This page intentionally left blank.

This space reserved for notes.

Printed Circuit Board Strapping




Figure 3-5. Control Board Strapping

M66014

3-17

SECTION 4

REPACKING

4-1. GENERAL

This section contains instructions for disconnecting and repacking the UNISCOPE 100 Display Terminal Type 3536 in preparation for shipment. Table 4-1 lists the cleaning materials and equipment needed to prepare the Display Terminal for shipment. Table 4-2 provides a step-by-step procedure for repacking the Display Terminal.

Table 4-1. Cleaning Materials and Equipment

Quantity	Description
1 qt.	Detergent, mild household
1	Cloth, clean, dry, lint free

Table 4-2. Repacking Procedure

Step	Procedure	Reference
1	Remove primary power from Display Terminal.	
2	Remove keyboard, disconnect cable, and replace cable in Display Terminal housing.	Figure 4-1 Page 4-3
3	Remove faceplate and cover assembly.	Figure 4-1
4	Remove WAIT, INTENSITY, and POWER control knobs, place in padded shipping bag, and place in cavity at rear of lower container.	Figure 4-1
5	Place one hand under major deflection coil, gently lift, and insert foam packing on top of power supply housing.	Figure 4-2 Page 4-5
6	Replace side panels.	Figure 4-1
7	Replace foam packing at rear of component board assembly.	Figure 4-2
8	Remove chimney assembly and replace foam packing.	Figure 4-2
9	Replace chimney assembly.	Figure 4-2
10	Replace foam packing in cutout on underside of top cover.	
11	Close top cover. Make sure both front panel fasteners are engaged.	Figure 4-1
12	Replace faceplate and secure to front panel with a piece of tape on each side.	Figure 4-1
13	Coil and tape power cable.	Figure 4-3 Page 4-7
14	Place Display Terminal in shipping bag.	
15	Fold shipping bag over Display Terminal and place unit in lower styrofoam container so that display screen is toward front of container and coiled power cable lies in cavity at rear center of container.	


UNISCOPE 100 Display Terminal

Table 4-2. Repacking Procedure (Cont)

Step	Procedure	Reference
14	Place Display Terminal in shipping bag.	
15	Fold shipping bag over Display Terminal and place unit in lower styrofoam container so that display screen is toward front of container and coiled power cable lies in cavity at rear center of container.	
16	Place keyboard in shipping bag.	
17	Place bagged keyboard, front end down and keys facing forward, into cutout at front of lower styrofoam container.	
18	Coil, tape, and place the communications cable (50 feet maximum) in a padded shipping bag and place on top of Display Terminal so that cable fits in cutout in upper styrofoam container.	
19	Place upper styrofoam container over Display Terminal, and gently pull keyboard forward while pressing upper container into place. This is to ensure that keyboard does not wedge against CRT.	
20	Strap or tape container halves together and place in shipping box.	
21	Seal box for shipment.	

This space reserved for notes.

Repacking



Z100

Figure 4-1. UNISCOPE 100 Display Terminal
Cover Removal

MR6014


4-3

UNISCOPE 100 Display Terminal

This page intentionally left blank.

This space reserved for notes.

Repacking



Z101

Figure 4-2. UNISCOPE 100 Display Terminal Rear View

NR6014


4-5

UNISCOPE 100 Display Terminal

This page intentionally left blank.

This space reserved for notes.

Repacking



Z102

Figure 4-3. UNISCOPE 100 Display Terminal
Bottom View

NR6014

4-7

MR6015

UNIVAC
UNISCOPE 100
DISPLAY
TERMINAL
TYPE 3536-06

**SERVICING DATA
AND ADJUSTMENTS**

AUGUST, 1973

RESTRICTED DISTRIBUTION

The information contained in this publication is the property of Sperry Univac. It is submitted in confidence and must not be disclosed to others except in confidence with the written permission of an officer of Sperry Univac. This copy is not to be reproduced or duplicated without permission in writing from a duly authorized representative of Sperry Univac. This publication is subject to recall.

SPERRY UNIVAC
TECHNICAL LIBRARY
VANDENBERG AFB

SPERRY  UNIVAC

CONTENTS

Heading	Title	Page
SECTION 1. INTRODUCTION		
1-1.	Scope	1-1
1-2.	Reference Documentation	1-1
1-3.	Display Terminal Description	1-1
1-4.	Special Equipment Required	1-1
SECTION 2. GENERAL DESCRIPTION		
2-1.	Introduction	2-1
2-2.	Protected Format Feature	2-1
2-3.	Features and Selections	2-2
2-4.	Interchangeable Printed Circuit Boards	2-7
SECTION 3. OPERATION		
3-1.	Introduction	3-1
3-2.	Operating Controls and Indicators	3-1
3-3.	Cursor	3-1
3-4.	Keyboard	3-1
3-5.	Audible Alarm	3-1
3-6.	Blink Marker Characters	3-6
3-7.	Operating Procedure	3-6
3-8.	Fault Check List	3-7
SECTION 4. ADJUSTMENTS AND PROCEDURES		
4-1.	Introduction	4-1
4-2.	General Precautions	4-1
4-3.	Preventive Maintenance	4-1
4-4.	Display Terminal Electrical Adjustments	4-2
4-5.	Display Terminal Mechanical Procedures	4-2
ILLUSTRATIONS		
Figure	Title	Page
3-1.	UNISCOPE 100 Display Terminal Keyboard	3-11
3-2.	UNISCOPE 100 Display Terminal Control Locations	3-13
4-1.	Image Area Adjustment (Sheet 1)	4-4
	Image Area Adjustment (Sheet 2)	4-5
4-2.	Major Deflection Coil Adjustment (Sheet 1)	4-6
	Major Deflection Coil Adjustment (Sheet 2)	4-7
4-3.	Minor Deflection Coil Adjustment (Sheet 1)	4-8
	Minor Deflection Coil Adjustment (Sheet 2)	4-9
4-4.	Antipincushion Magnet Adjustment (Sheet 1)	4-10
	Antipincushion Magnet Adjustment (Sheet 2)	4-11
4-5.	Display Centering Magnet Tab Adjustment (Sheet 1)	4-12
	Display Centering Magnet Tab Adjustment (Sheet 2)	4-13
4-6.	Intensity Control Adjustment (Sheet 1)	4-14
	Intensity Control Adjustment (Sheet 2)	4-15
4-7.	Clock Adjustment (Sheet 1)	4-16
	Clock Adjustment (Sheet 2)	4-17
4-8.	Character Symmetry Adjustment (Sheet 1)	4-18
	Character Symmetry Adjustment (Sheet 2)	4-19

ILLUSTRATIONS (Cont)

Figure	Title	Page
4-9.	Line Spacing Adjustment (Sheet 1)	4-20
	Line Spacing Adjustment (Sheet 2)	4-21
4-10.	UNISCOPE 100 Display Terminal Cover Removal.	4-23
4-11.	UNISCOPE 100 Display Terminal Rear View.	4-25
4-12.	UNISCOPE 100 Display Terminal Bottom View.	4-27
4-13.	UNISCOPE 100 Display Terminal Cabinet Disassembly.	4-29
4-14.	Keyboard Disassembly	4-31
4-15.	Voltage Bus Locations.	4-33
4-16.	Interconnection Wiring Diagram (Sheet 1)	4-35
	Interconnection Wiring Diagram (Sheet 2)	4-37
4-17.	Functional Block Diagram	4-39

TABLES

Table	Title	Page
2-1.	Features and Selections.	2-2
2-2.	Interchangeable Printed Circuit Boards	2-7
3-1.	Controls and Indicators.	3-2
3-2.	Turn-On Procedure.	3-6
3-3.	Turn-Off Procedure	3-7
3-4.	Display Terminal Fault Check List.	3-7
4-1.	Preventive Maintenance Procedure	4-1
4-2.	Faceplate and Cover Assembly Removal and Replacement	4-22
4-3.	Keyboard Removal and Replacement	4-22
4-4.	Chimney Removal and Replacement.	4-24
4-5.	Filter Removal and Replacement	4-26
4-6.	Power Supply Removal and Replacement	4-26
4-7.	Fan Removal and Replacement.	4-28
4-8.	CRT Removal and Replacement.	4-28

SECTION 1
INTRODUCTION

1-1. SCOPE

This book is divided into three sections that contain servicing data for the UNIVAC® UNISCOPE® 100 Display Terminal Type 3536-06 (Display Terminal). These sections contain the following:

Section 2 provides a description of unit features, with listings of available and interchangeable printed circuit boards.

Section 3 describes the operation of the controls and indicators for the Display Terminal.

Section 4 contains electrical and mechanical procedures required for servicing the Display Terminal.

1-2. REFERENCE DOCUMENTATION

SD 12002-00	<u>Servicing Diagrams for UNISCOPE 100, Types 3536-04, -05, -06</u>
UP-7788	<u>UNISCOPE 100 Display Terminal Operators Reference</u>
UP-7807	<u>UNISCOPE 100 Display Terminal Programmers Reference</u>

1-3. DISPLAY TERMINAL DESCRIPTION

The Display Terminal is an input/output terminal device used to receive data from and transmit data to a centrally located processor, or another terminal. If the processor is at a remote location, this data is transmitted and received over telephone lines via a modem.

The Display Terminal cabinet, together with the attached keyboard, houses all of the electronics required for Display Terminal operation.

The Display Terminal is capable of operating other input/output devices. Available optional auxiliary devices for the Display Terminal include:

Type 0866 Tape Cassette System

Type 8541-06, -07 Communications Output Printer

1-4. SPECIAL EQUIPMENT REQUIRED

The following special equipment is required for servicing and adjusting a Display Terminal:

- (1) Crimp tool (2805788-00/UPC # 921013)
- (2) Locator tool (2805789-00)
- (3) Pin extractor (2805790-00)
- (4) Integrated Circuit (IC) test clip, 14-pin dual in-line (4916149-01)

® UNIVAC is a registered trademark of the Sperry Rand Corporation. Another Sperry Rand trademark appearing in this book is: UNISCOPE.

UNISCOPE 100 Display Terminal

- (5) IC test clip, 16-pin dual in-line (4916149-00)
- (6) Degaussing coil, suitable for commercial television servicing
- (7) Volt-ohmmeter, Triplett Model 310 or equivalent (3001444-00)

SECTION 2
GENERAL DESCRIPTION

2-1. INTRODUCTION

This section provides brief descriptions of the equipment, features, and selections that comprise the UNISCOPE 100 Display Terminal Type 3536-06. For more detailed descriptions of the Display Terminal, software, and system considerations involved in using the unit, refer to the reference documents listed in Section 1.

2-2. PROTECTED FORMAT FEATURE

The protected format feature in the Display Terminal provides protection of specified data fields as defined by computer programs. The "form" defining the protected and unprotected data fields of individual files is established by the computer program.

The protected format logic of the Display Terminal recognizes the control characters SO and SI (when received from the processor) as start and stop signals, respectively, for protected fields. The logic prevents an operator from overwriting or modifying these fields in normal operation.

With protected format logic, communication line and processor interrupt time are reduced because of space suppression at the end of unprotected fields and because of the transmission of only unprotected data. The single character code SUB in place of each protected field, a carriage return at the end of each line, and all unprotected data are transmitted. Spaces are suppressed within each field and at the end of each line.

The transmission of both protected and unprotected characters in one message is permitted. Any number of protected characters, within memory limits, may be included in a protected area or field. Any number of protected areas (fields) may be included in a single message from the processor.

When keyboards with protected format logic are used, extended operator control is offered. The requirement for this additional control is determined by system and application requirements. These keyboards offer the following protected format capabilities:

Erase Field - gives specified erase of unprotected data within one field, with the field location defined by cursor position.

Erase Display - gives the operator the ability to erase all data, protected and unprotected, from the cursor to the end of the display.

Transmit Display - gives the operator the capability of transmitting all data, protected and unprotected, to the processor.

The protected format feature permits the processor to transmit a "form" which may be filled in by the operator without the operator being able to alter the form itself. Either the contents of the complete screen, including the form, or just the data inserted by the operator can be transmitted to the processor. The second type of transmission permits a reduction of the quantity of data transferred. The protected format feature affects many of the editing functions in a standard Display Terminal, as listed in table 3-1.

Each protected data character in memory is marked by a ZERO in the eighth bit position. A ONE in the eighth bit position indicates an unprotected character. The processor defines the beginning of a series of protected characters by means of an SO character. All characters sent in a message after the SO character will be

marked by the absence of an extra bit. This is true even of functions such as CR and space, which result in characters not being sequentially distributed through memory. The end of a protected field is marked by an SI character.

It should be noted that SI is also used with the cursor address sequence. The SI character is a character specified by the ASCII code to end a sequence started by the ESC and VT codes. For example, if an SO starts a protected field, and a cursor address sequence is subsequently inserted in the data stream, the cursor is repositioned and the protected field is terminated. If an SO is placed directly after the SI in the cursor address sequence, the data will continue to be protected after the cursor is repositioned.

Whenever the cursor is positioned over a protected character by use of any cursor control key, the cursor will advance to the next unprotected character as soon as the key is released. Thus, the cursor cannot be positioned over a protected character by the operator. If, at the end of a transmission, the processor leaves the cursor positioned over a protected character, the cursor will remain in that position.

If a key is pressed with the cursor positioned over a protected character at the end of a transmission, the character under the cursor is changed to an unprotected character and the cursor advances to the next unprotected character. If, in normal typing, the cursor is moved over a protected character, the cursor advances to the next unprotected character when the key is released.

2-3. FEATURES AND SELECTIONS

Features and selections available with the Display Terminal are listed in table 2-1. Note that type, feature, and selection numbers used here do not necessarily reflect marketing (price-book) listings, but rather reflect manufacturing configurations corresponding to those given on the Configuration Description Record shipped with each unit.

Table 2-1. Features and Selections

Feature, Selection, or Type Number	Description	Feature Contains
C1240-00	Deflection Format, 12 x 80 with Protect Format Logic	2805338 (A10) 2808052 (A9) 2807918/2805290 (A7) 2807988 (A5)
C1240-06	Deflection Format, 16 x 64 with Protect Format Logic	2805353 (A10) 2808052 (A9) 2807918/2805290 (A7) 2807992 (A5)
C1240-07	Deflection Format, 12 x 80, without Protect Format Logic	2805338 (A10) 2808053 (A9) 2807918/2805290 (A7) 2807988 (A5)
C1240-08	Deflection Format, 16 x 64, without Protect Format Logic	2805353 (A10) 2808053 (9) 2807918/2805290 (A7) 2807992 (A5)
F1241-03	64 Character Generator	2807786 (A8)
F1241-04	96 Character Generator	2807816 (A8)

Table 2-1. Features and Selections (Cont)

Feature, Selection, or Type Number	Description	Feature Contains
<u>STANDARD KEYBOARD</u>		
F1242-00	Numeric Keyboard, modified with: Keyset A, F1465 Keyset B, F1466 F1241-03 is required (64C)	2805251-10 2805251-20
F1242-01	Alpha Keyboard, modified with: Keyset A, F1465 Keyset B, F1466 F1241-03 is required (64C)	2805251-11 2805251-21
F1242-02	Alpha Keyboard, modified with: Keyset A, F1465 Keyset B, F1466 F1241-04 is required (96C)	2805251-12 2805251-22
F1242-03	Alphamumeric Keyboard, modified with: Keyset A, F1465 Keyset B, F1466 F1241-03 is required (64C)	2805251-13 2805251-23
F1242-04	Alphamumeric Keyboard, modified with: Keyset A, F1465 Keyset B, F1466 F1241-04 is required (96C)	2805251-14 2805251-24
F1242-05	Alpha Keyboard, modified with: Keyset A, F1465 Keyset B, F1466 F1241-03 is required (64C) Protected Format	2805251-15 2805251-25
F1242-06	Alpha Keyboard, modified with: Keyset A, F1465 Keyset B, F1466 F1241-04 is required (96C) Protected Format	2805251-16 2805251-26
F1242-07	Alphamumeric Keyboard, modified with: Keyset A, F1465 Keyset B, F1466 F1241-03 is required (64C) Protected Format	2805251-17 2805251-27
F1242-08	Alphamumeric Keyboard, modified with: Keyset A, F1465 Keyset B, F1466 F1241-04 is required (96C) Protected Format	2805251-18 2805251-28

Table 2-1. Features and Selections (Cont)

Feature, Selection, or Type Number	Description	Feature Contains
	<u>ENHANCED KEYBOARD</u>	
F1844-00	Numeric Keyboard, modified with: Keyset A, F1465 Keyset B, F1466 F1241-03 is required (64C)	2808039-00 2808039-01
F1844-01	Alpha Keyboard, modified with: Keyset A, F1465 Keyset B, F1466 F1241-03 is required (64C)	2808038-00 2808038-02
F1844-02	Alpha Keyboard, modified with: Keyset A, F1465 Keyset B, F1466 F1241-04 is required (96C)	2808038-01 2808038-03
F1844-03	Alphanumeric Keyboard, modified with: Keyset A, F1465 Keyset B, F1466 F1241-03 is required (64C)	2808036-00 2808036-04
F1844-04	Alphanumeric Keyboard, modified with: Keyset A, F1465 Keyset B, F1466 F1241-04 is required (96C)	2808036-01 2808036-05
F1844-05	Alpha Keyboard, modified with: Keyset A, F1465 Keyset B, F1466 F1241-03 is required (64C) Protect Format	2808037-00 2808037-02
F1844-06	Alpha Keyboard, modified with: Keyset A, F1465 Keyset B, F1466 F1241-04 is required (96C) Protected Format	2808037-01 2808037-03
F1844-07	Alphanumeric Keyboard, modified with: Keyset A, F1465 Keyset B, F1466 F1241-03 is required (64C) Protected Format	2808036-02 2808036-06
F1844-08	Alphanumeric Keyboard, modified with: Keyset A, F1465 Keyset B, F1466 F1241-04 is required (96C) Protected Format	2808036-03 2808036-07

Table 2-1. Features and Selections (Cont)

Feature, Selection, or Type Number	Description	Feature Contains
<u>KEYBOARD HARDWARE</u>		
C1900-00	Keyboard Support Hardware, for use on Type 3536-06 with no keyboard installed. Cover plate 2807714 is required.	2808088-00
C1900-01	Keyboard Support Hardware, for use on Type 3536-06 with an F1844 keyboard installed.	2808088-01
C1900-02	Keyboard Support Hardware, for use on Type 3536-06 with an F1242 keyboard installed.	2808088-02
F1245-00	Direct Interface, Synchronous Interface to CTMC or DCS.	2808063 (A12) Any synchronous A11
<u>Speed Selections</u>		
C1467-00	2400 bps	
C1467-01	4800 bps	
C1467-02	9600 bps	
F1245-01	Synchronous Interface, UNIVAC	2808055 (A12) 2808054 (A11)
<u>Mode Selections</u>		
C1468-00	RS232C/V.24	
C1468-01	UNIVAC Terminal Multiplexer Type 8538	
C1468-02	MIL-STD-188C	
F1245-02	Asynchronous Interface, UNIVAC	2808060 (A12) 2808059 (A11)
C1468-00	Mode Selection - RS232C/V.24	
<u>Speed Selections</u>		
C1469-00	300 bps	
C1469-01	600 bps	
C1469-02	1200 bps	
C1469-03	1600 bps	
C1469-04	1800 bps	
C1469-05	2400 bps	
C1468-01	Mode Selection - Terminal Multiplexer	
<u>Speed Selections</u>		
C1469-06	300 bps	
C1469-07	600 bps	
C1469-08	1200 bps	
C1469-09	1600 bps	
C1469-10	1800 bps	
C1469-11	2400 bps	

Table 2-1. Features and Selections (Cont)

Feature, Selection, or Type Number	Description	Feature Contains
C1468-02	Mode Selection - MIL-STD-188C	
	<u>Speed Selections</u>	
C1469-12	1200 bps	
C1469-13	1600 bps	
C1469-14	1800 bps	
C1469-15	2400 bps	
F1245-13	Synchronous Interface - IBM* (For mode selections see F1245-01)	2808057 (A12) 2808056 (A11)
F1245-14	Asynchronous Interface - IBM (For mode and speed selections see F1245-02)	2808062 (A12) 2808061 (A11)
F1247-00**	Auxiliary Interface	2808058 (A13) 2807716 (W4)

*Registered trademark of International Business Machines Corporation.

**Auxiliary interface feature is required when a UNIVAC Communications Output Printer Type 8541-06, -07 or UNIVAC Series 600 Tape Cassette System Type 0866 is used with the Display Terminal.

2-4. INTERCHANGEABLE PRINTED CIRCUIT BOARDS

Several printed circuit boards within the Display Terminal are assigned part numbers as a result of strapping provisions contained on the boards. For example; input/output board no. 1 (A11), synchronous - UNIVAC, is the same board as input/output board no. 1, synchronous-IBM except for the connection of the appropriate straps. Interchangeable boards are listed in table 2-2. Refer to MR6014, "UNISCOPE 100 Display Terminal Installation Procedures" for strapping information.

Table 2-2. Interchangeable Printed Circuit Boards

Board	Description	Part Number	Strapping	Remarks
A11	I/O-1 Sync-UNIVAC	2808054	E1-E2, E3-E4 OUT	I/O-1 and I/O-2 boards must be compatible: sync/async, UNIVAC/IBM
A11	I/O-1 Sync-IBM	2808056	E1-E2 E3-E4 IN	
A12	I/O-2 Sync-UNIVAC	2808055	A-B C-D OUT	
A12	I/O-2 Sync-IBM	2808057	A-B C-D IN	
A11	I/O-1 Async-UNIVAC	2808059	E1-E2 E3-E4 OUT	
A11	I/O-1 Async-IBM	2808061	E1-E2 E3-E4 IN	
A12	I/O-2 Async-UNIVAC	2808060	E1-E2 OUT	
A12	I/O-2 Async-IBM	2808062	E1-E2 IN	
A3	Regulator/ Control	2807934	E1-E2 IN	Used with A8 board 2807786 (64C)
A3	Regulator/ Control	2807934	E1-E2 OUT	Used with A8 board 2807816 (96C)
A9	Control, with Protect Format	2808052	E20- E23 IN	A8, A17, must be Protect Format
A9	Control, with- out Protect Format	2808053	E20 E23 OUT	A8, A17, must not be Protect Format

SECTION 3

OPERATION

3-1. INTRODUCTION

Section 3 contains a description of UNISCOPE 100 Display Terminal Type 3536-06 operating controls and indicators, basic operating procedures, and a fault check list.

3-2. OPERATING CONTROLS AND INDICATORS

Unit operation is discussed briefly in this Section. For a more complete description, refer to the latest version of UF-7788, "UNISCOPE 100 Display Terminal Operators Reference". Table 3-1 lists the controls and indicators provided with the Display Terminal.

3-3. CURSOR

The cursor ($\bar{_}$) is a unique character that is displayed on the CRT at all times, except during message transmission. The cursor is used to indicate the position at which the next data character will be entered on the display screen, and also the last data character to be transmitted to the processor. When located in a position containing a character other than a space, the cursor and the character are displayed alternately, thus creating a blinking effect, and providing easy location by the operator of the cursor position. A blinking cursor which occupies a space in the display is an indication that a nondisplayable character, such as a tab stop, is located in that position.

The "home" position for the cursor is the first character position of the first line (upper left hand corner) on the display screen.

All cursor control keys are nondestructive; that is, they do not affect the character located at the cursor position. The cursor has its own control circuitry and does not occupy a memory location, thereby allowing positioning anywhere on the display screen without affecting the existing display.

3-4. KEYBOARD

In addition to providing the cursor control keys, the keyboard also provides message control keys, editing keys, special function keys, and a conventional typewriter keyboard. Figure 3-1 illustrates a fully equipped keyboard, and table 3-1 lists the operation of the control keys provided on this keyboard.

3-5. AUDIBLE ALARM

The Display Terminal contains an audible alarm which is used to indicate the following conditions:

- (a) The alarm sounds once when the cursor reaches the eighth character position from the end of any line in the display.
- (b) The alarm sounds once when the cursor reaches the last line of the display at any character position.
- (c) The alarm sounds continuously at brief, regular intervals when the MESSAGE WAIT indicator is lit. The alarm is turned off when the MESSAGE WAIT key is pressed.

Table 3-1. Controls and Indicators









Key, Control, or Indicator	Description
	<p>This key is used to enter the start-of-entry (SOE) symbol (␣) on the display screen at the position indicated by the cursor. The SOE nearest the left side of the cursor indicates the starting point of the message to be transmitted to the processor. All characters <u>between</u> this SOE and the cursor will be transmitted when the appropriate transmit key is pressed (after being polled by the processor).</p>
	<p>When pressed, the unprotected format message contained between the SOE symbol and the cursor will be transmitted to the processor after the next poll to the Display Terminal.</p> <p>If no SOE symbol is in the display, transmission will begin at the home position.</p> <p>On units with protected format, this key is labeled TRANSMIT UNPROT DISPLAY.</p>
	<p>This key is used to initiate a data transfer between the Display Terminal and an auxiliary device. The key is only functional when an auxiliary device is connected to the Display Terminal.</p>
	<p>This key is used to send a special message to the processor (at the next poll from the processor). The message indicates that the Display Terminal can accept a message from the processor.</p>
	<p>This key is used to position the cursor in the home position on the display screen.</p> <p>On units with protected format, pressing this key causes the cursor to be positioned at the first unprotected character location in the display. If all display screen positions are protected, the cursor will be returned to the home position and the keyboard <u>functionally disabled</u> (keys <u>will</u> still depress).</p>
	<p>This key is the equivalent of the carriage return key on a standard typewriter keyboard. When pressed, the cursor is positioned in the first character location of the next line.</p> <p>If the first character location of the next line is protected, the cursor advances to the first unprotected character.</p> <p>When the cursor reaches the last character position of any line, the next positioning to the right automatically generates a cursor return without use of the return key.</p>
	<p>The space bar is in the position normally occupied by the space bar on a typewriter keyboard. The cursor moves to the right one space each time the space bar is pressed.</p>
	<p>A redundant space bar (→) is provided to the right of the main space bar on numeric keyboards so that the controls normally used with a numeric keyboard (space, tab, return) are available immediately adjacent to the numeric keyboard.</p>

Table 3-1. Controls and Indicators (Cont)



Key, Control, or Indicator	Description
	<p>Each scan key, when pressed, causes the cursor to move one space at a time in the direction of the arrow. Each key provides this action repeatedly, so long as the key is held pressed.</p> <p>When the cursor is in the last character position of the bottom line in the display and the scan right (→) key is pressed, the cursor will "wrap around"; that is, the cursor will advance to the home position. Wrap around also occurs with the cursor in the home position if the scan left (←) key is pressed.</p>
<div style="border: 1px solid black; padding: 2px; display: inline-block;">TAB SET</div>	<p>This key is used to place tab stop codes in the Display Terminal memory for use with the TAB key. The cursor is used to indicate the position for setting a tab stop.</p> <p>Tab stops must be individually set for each line, and for every new set of display screen data (unless program provision is made to retain them). Tab stops are transmitted to the processor, along with display screen data.</p>
<div style="border: 1px solid black; padding: 2px; display: inline-block;">TAB</div>	<p>This is a special cursor positioning key which, when pressed, causes the cursor to scan right until a tab stop character is located. The cursor stops one character to the right of the tab stop, or, if no tab stops are found, returns to the home position.</p>
	<p>This key, when pressed, causes the cursor to move one space to the left. The function is non-repetitive; that is, the key must be pressed once for each movement left.</p> <p>When the cursor reaches the first character position of any line, the cursor will move to the last position of the previous (above) line the next time this key is pressed. When the cursor reaches the home position this key, when pressed, causes the cursor to wrap around to the last character position in the bottom line of the display.</p>
<div style="border: 1px solid black; padding: 2px; display: inline-block;">CHAR ERASE</div>	<p>This key, when pressed, causes the character in the cursor position to be erased and a space entered in that position. The cursor then moves automatically one space to the right.</p>
<div style="border: 1px solid black; padding: 2px; display: inline-block;">ERASE TO END OF LINE</div>	<p>This key, when pressed, causes all characters between the cursor and either the end of the unprotected field in which the cursor is positioned, or the end of the line in which the cursor is positioned (whichever occurs first), to be erased.</p> <p>This key will not function when pressed with the cursor in a protected field.</p>
<div style="border: 1px solid black; padding: 2px; display: inline-block;">ERASE TO END OF DISPL</div>	<p>This key, when pressed, causes all characters from the cursor position to the end of the display to be erased. The cursor remains in the same position.</p> <p>With protected format, only unprotected characters are affected when this key is pressed.</p>

Table 3-1. Controls and Indicators (Cont)

Key, Control, or Indicator	Description
<div style="border: 1px solid black; padding: 2px; width: fit-content;">IN DISPL INSERT IN LINE</div>	<p><u>Upper case operation:</u> In this mode, the INSERT IN DISPL function is activated when this key is pressed. Those characters from the cursor position to the end of the display are shifted one space to the right. A space is inserted in the cursor position and characters in the last character position of each line, except the last display line, are shifted to the first position of the next line. If a character is present in the last screen position, that character is lost.</p> <p>With protected format, only the display within the unprotected field in which the cursor is positioned is affected when this key is pressed.</p> <p><u>Lower case operation:</u> In this mode, the INSERT IN LINE function is activated when this key is pressed. Those characters from the cursor position to the end of the line in which the cursor is located are shifted right one space. If a character is present in the last screen position, that character is lost.</p> <p>With protected format, the function is limited to one unprotected field or one unprotected line, and the shifting will stop at the end of whichever occurs first.</p>
<div style="border: 1px solid black; padding: 2px; width: fit-content;">IN DISPL DELETE IN LINE</div>	<p><u>Upper case operation:</u> In this mode, the DELETE IN DISPL function is activated when this key is pressed. The character in the cursor position is deleted, and all characters are shifted left one space. A space is inserted in the last character position of the display. The cursor position remains unchanged. A character in the first position of any display line shifts to the last position of the previous line each time the key is pressed.</p> <p><u>Lower case operation:</u> In this mode, the DELETE IN LINE key function is activated when this key is pressed. The character in the cursor position is deleted, and all characters from the cursor position to the end of the line in which the cursor is located are shifted left one space. A space is inserted in the last character position of the line. The cursor position remains unchanged.</p> <p>With protected format, the function is limited to one unprotected field, rather than to the end of the line or of the display. This permits the operator to shift several lines within one unprotected field, but does not allow the shifting of more than one unprotected field at a time.</p>
<div style="border: 1px solid black; padding: 2px; width: fit-content;">CYCLE</div>	<p>Pressing this key causes the next character or function chosen by the operator to be repeated as long as both the CYCLE key and the other key are pressed. This key operates with all keys except the ERASE, DELETE, INSERT, SHIFT, SHIFT-LOCK, PRINT, RETURN, MESSAGE WAITING, TRANSMIT, CURSOR TO HOME, and special function keys.</p>
<div style="display: flex; flex-wrap: wrap; gap: 5px;"> <div style="border: 1px solid black; padding: 2px; width: 30px; text-align: center;">F1</div> <div style="border: 1px solid black; padding: 2px; width: 30px; text-align: center;">F2</div> <div style="border: 1px solid black; padding: 2px; width: 30px; text-align: center;">F3</div> <div style="border: 1px solid black; padding: 2px; width: 30px; text-align: center;">F4</div> </div>	<p>Pressing one of the special function keys causes a special message to be transmitted in response to the next poll. The meaning of each special message depends on local programming provisions.</p>

Table 3-1. Controls and Indicators (Cont)

Key, Control, or Indicator	Description
<div style="border: 1px solid black; padding: 2px; width: fit-content;">ERASE UNPROT DISPL</div>	<p>This key, when pressed, causes all unprotected data from the cursor position to the end of the display to be erased. For units without protected format, this key is labeled ERASE TO END OF DISPLAY.</p>
<div style="border: 1px solid black; padding: 2px; width: fit-content;">TRANSMIT UNPROT DISPL</div>	<p>When this key is pressed, the data within the unprotected areas on the screen are transmitted to the processor. No protected areas can be transmitted. The area to be transmitted is defined by an SOE symbol and the cursor. All unprotected data between the cursor and the first preceding SOE symbol are transmitted. If no SOE symbol is used, all unprotected data from the beginning of the screen display to the cursor are transmitted. For units without protected format, this key is labeled TRANSMIT.</p>
<div style="border: 1px solid black; padding: 2px; width: fit-content;">ERASE FIELD</div>	<p>This key, when pressed, causes all characters from the cursor position to the end of the field or to the end of the display (whichever occurs first) to be erased within the unprotected field in which the cursor is positioned.</p> <p>This key function can be activated by the processor, an auxiliary device, or the operator.</p> <p>If, at the end of a transmission, the processor leaves the cursor positioned within a protected field, the cursor does not move, and the erase-to-end-of-field cannot be performed. The cursor first must be moved into an unprotected field either by the software, or by pressing a cursor control key before the ERASE FIELD key will function.</p>
<div style="border: 1px solid black; padding: 2px; width: fit-content;">ERASE DISPL</div>	<p>This key, when pressed, causes all characters between the cursor and the end of the display (protected and unprotected) to be erased.</p>
<div style="border: 1px solid black; padding: 2px; width: fit-content;">TRANSMIT DISPL</div>	<p>This key, when pressed, provides for the transmission of all characters on the display screen between the SOE symbol nearest the left of the cursor and the cursor at the next processor poll.</p>
<div style="text-align: center;">○ WAIT</div>	<p>This switch/indicator lights when the transmit key is pressed by the operator, or when a message is received from the processor, and is extinguished when transmission is completed, or when the switch is pressed by the operator. When the WAIT indicator is lit the keyboard is functionally disabled.</p> <p>When this switch/indicator is pressed, the keyboard is enabled, and the transmit or print function that caused the indicator to light is cancelled. It is not advisable to use this switch when in on-line operation. Actuation of the switch may interfere with processor polling activity and interrupt transmission or print activities, thus causing loss of data.</p>
<div style="text-align: center;">○ INTENSITY</div>	<p>This control is used to adjust display brightness. Intensity should be set to provide a clear image, but not for maximum brightness; high intensity settings can cause damage to the display screen.</p>

Table 3-1. Controls and Indicators (Cont)

Key, Control, or Indicator	Description
<p style="text-align: center;">○</p> <p style="text-align: center;">POWER</p>	This switch/indicator is used to apply power to the Display Terminal. The switch is pressed to apply and pressed to remove primary power and lights when power is applied.
<div style="border: 1px solid black; padding: 2px; width: fit-content;">MESSAGE WAITING</div>	This indicator lights when the processor has a conditional, unsolicited message for display. The indicator remains on until the MESSAGE WAITING key is pressed. The indicator also lights and remains on from the time an unconditional unsolicited message is received until the MESSAGE WAITING key is pressed after the message is displayed.
<div style="border: 1px solid black; padding: 2px; width: fit-content;">MESSAGE INCOMPL</div>	This indicator lights when a message is received by the Display Terminal and goes out when communication error checks are satisfied.

3-6. BLINK MARKER CHARACTERS

Blink marker characters (Ⓟ) are special characters which can be sent by the processor to call operator attention to selected display data. They are not a part of the displayable keyboard characters. Use of these characters is described in UF-7807, UNISCOPE 100 Display Terminal Programmers Reference.

3-7. OPERATING PROCEDURE

Table 3-2 contains the turn-on procedure and table 3-3 the turn-off procedure for the Display Terminal.

Table 3-2. Turn-On Procedure

Step	Procedure	Reference
1	Press and release front panel POWER switch (S03). Note indicator lamp in S03 lights as power is applied to Display Terminal.	Figure 3-2 Page 3-13
2	Set enable/disable switch (S01) to "enable" (rear) position.	Figure 3-2
	NOTE	
	For units without protect format, perform step 3 (which completes the procedure). For units with protect format, omit step 3.	
3	Press and release CURSOR TO HOME and ERASE TO END OF DISPL keys. After a warm-up of approximately 30 seconds, cursor should appear at upper left-hand corner of display screen. If cursor does not appear, rotate front panel INTENSITY control R01 clockwise until cursor appears. Display Terminal is now ready for operation.	Figure 3-1 Page 3-11
	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin: 0 auto;">CAUTION</div> <p style="text-align: center;">High intensity control settings can cause damage to the CRT screen. Use the lowest intensity setting that provides a clear, readable display.</p>	

Table 3-2. Turn-On Procedure (Cont)

Step	Procedure
4	Press and release CURSOR TO HOME and ERASE DISPL keys.
5	Position cursor in last line on display screen.
6	Simultaneously press WAIT pushbutton, CYCLE key and any displayable character key. Allow cursor to cycle through home position.
7	Press and release CURSOR TO HOME and ERASE DISPL keys.

Table 3-3. Turn-Off Procedure

Step	Procedure	Reference
1	To functionally disable keyboard and remove high voltage from CRT, and to keep Display Terminal in an active status relative to the processor, set enable/disable switch S01 to "disable" (forward) position. The POWER indicator will remain lit.	Figure 3-2
2	To remove all power from the Display Terminal, press POWER pushbutton and note that indicator lamp goes out.	Figure 3-2

3-8. FAULT CHECK LIST

The Fault Check List shown in table 3-4 is provided to aid the Customer Engineer in obtaining information from the customer prior to making a service call. In addition, the following questions are useful in diagnosing many Display Terminal malfunctions:

- (a) Which keys do not operate correctly, if any?
- (b) Does the audible alarm function for the conditions outlined in paragraph 3-5? Ensure that the volume control is adjusted properly.
- (c) Does the cursor disappear when the TRANSMIT key is pressed and reappear shortly after the WAIT key is pressed?
- (d) Does other equipment on the same communications line operate properly?

Table 3-4. Display Terminal Fault Check List

Step	Indication	Probable Cause	Operator Action
1	WAIT indicator lit and keyboard locked for an excessive amount of time.	Processor did not send a keyboard-unlock code to Display Terminal after receiving a message or acknowledgment. Also, the Display Terminal detected a parity error in message from processor.	Unlock keyboard by pressing WAIT pushbutton and try retransmitting message to processor (TRANSMIT key).

Table 3-4. Display Terminal Fault Check List (Cont)

Step	Indication	Probable Cause	Operator Action
2	Equipment inoperative and POWER switch/indicator does not light when pressed.	1. Power cord not plugged into AC outlet receptacle. 2. Circuit breaker CBO1 trips to OFF position from an AC line surge or a short circuit overload.	1. Plug cord into AC outlet receptacle 2. Remove Display Terminal faceplate (pull from friction catches in unit panel) and reset circuit breaker. If the circuit breaker trips off again, notify supervisor.
3	Equipment inoperative and POWER switch/indicator lit.	1. Enable/disable switch SO1 is in "disable" (forward) position. 2. INTENSITY control set too far counterclockwise. 3. Logic circuitry defective.	1. Set switch SO1 to "enable" (rear) position. 2. Adjust control clockwise until cursor appears satisfactorily. Intensity should be set to provide a clear image, but not for maximum brightness; high intensity settings can cause damage to the display screen. 3. Notify supervisor.
4	All Display Terminals on a Terminal Multiplexer inoperative.	Terminal Multiplexer inoperative.	Ensure that the switch on the front panel is in position ON (rocker set with top portion pressed in). Ensure that the power cord is plugged into the AC outlet receptacle. If these actions do not remedy the trouble, notify supervisor.
5	Some Display Terminals on a Terminal Multiplexer inoperative.	Cable jacks at rear of unit loose or disconnected.	Ensure that all cables are connected properly.

Table 3-4. Display Terminal Fault Check List (Cont)

Step	Indication	Probable Cause	Operator Action
6	Character entered (as displayed on screen) incorrectly or in wrong screen position; for example, if G key is pressed and another character is displayed, or character not positioned at the cursor position.	Defective keyboard or logic circuits.	Notify supervisor.
7	Unit overheating.	<ol style="list-style-type: none"> 1. Ventilating fan under the unit is inoperative. 2. Obstruction to fan outlet. 3. Object is obstructing air flow through filter located on underside of unit. 4. Clogged air filter. 	<ol style="list-style-type: none"> 1. Press the POWER switch to remove power and notify supervisor. 2. Ensure that the fan is clear and that the air duct under the fan is open to the rear of unit. 3. Lift unit and remove the object. 4. Replace the air filter.
8	MESSAGE WAIT, MESSAGE INCOMPL, and WAIT indicators not lighting under appropriate conditions.	<ol style="list-style-type: none"> 1. Lamp burned out. 2. Logic circuits faulty. 	<ol style="list-style-type: none"> 1. Replace lamp. 2. Notify supervisor.
9	Audible alarm not loud enough.	Volume control not set properly.	Remove the display screen faceplate and use a screwdriver to adjust the volume control (left-most control) for satisfactory sound.
10	Screen images out of focus.	Focus control not set properly.	Remove display screen faceplate and use a screwdriver to adjust the focus control (right-most control) for a clear image.

This page intentionally left blank.





Figure 3-1. UNISCOPE 100 Display Terminal Keyboard

UNISCOPE 100 Display Terminal

This page intentionally left blank.



AA101

Figure 3-2. UNISCOPE 100 Display Terminal Control Locations

This space reserved for notes

SECTION 4
ADJUSTMENTS AND PROCEDURES

4-1. INTRODUCTION

This section contains electrical adjustment procedures, mechanical disassembly procedures, and a recommended preventive maintenance procedure for the UNISCOPE 100 Display Terminal.

4-2. GENERAL PRECAUTIONS

The following precautions should be observed when adjusting or maintaining the Display Terminal:

- (1) Keep hands and tools away from the high voltage power supply and the high voltage connections on the CRT when power is applied to the unit.
- (2) High INTENSITY control settings can cause permanent damage to the CRT screen. The lowest setting that provides a clear, readable display should be used.

WARNING

Handle the CRT with care. Breakage of the CRT, which contains a high vacuum, may result in injury from flying glass. Do not strike or scratch the tube or subject it to any pressure at any time.

4-3. PREVENTIVE MAINTENANCE

A substantial number of servicing problems can be eliminated by a good preventive maintenance program. The procedure listed in table 4-1 will accomplish this and ensure optimum performance from the Display Terminal.

Table 4-1. Preventive Maintenance Procedure

Step	Procedure	Reference
1	Remove AC power from Display Terminal.	
2	Remove faceplate and cover assembly.	Table 4-2 Page 4-22 Figure 4-10 Page 4-23
3	Remove keyboard.	Table 4-3 Page 4-22
4	Remove all printed circuit boards (except power supply) from Display Terminal.	
5	Clean contacts on all printed circuit boards with soft rubber eraser (pink pearl type).	
6	Disassemble keyboard.	Figure 4-14 Page 4-31
7	Remove rubber plungers and space bar key shaft and push keys down.	Figure 4-14

Table 4-1. Preventive Maintenance Procedure (Cont)

Step	Procedure	Reference
8	Check key shafts for dirt or other foreign material. Wipe clean with soft cloth.	
9	Spray key shafts generously with silicone spray.	
10	Shake keys up and down and repeat step 9.	
11	Check foil for bumps, dents, wrinkles, and so on. Replace if necessary.	Figure 4-14
12	Clean foil and printed circuit board contacts with Freon and soft, lint-free cloth.	
13	Re-assemble and replace keyboard.	Figure 4-14
14	Clean all dust and foreign material from Display Terminal with brush and/or vacuum and soft lint-free cloth.	
15	Clean mother board pins with brush and Freon.	
16	Check all connectors for bent or broken contacts and replace if necessary.	
17	Clean or replace air filter.	Figure 4-12 Page 4-27
18	Re-insert all printed circuit boards.	
19	Apply AC power to Display Terminal and verify power supply voltages.	Figure 4-15 Page 4-33
20	Perform initial power-on procedure.	Section 3
21	Return Display Terminal to service.	

4-4. DISPLAY TERMINAL ELECTRICAL ADJUSTMENTS

Figures 4-1 through 4-9 described the electrical adjustments for the Display Terminal.

Figures 4-16 and 4-17 are included as aids in servicing the Display Terminal. Figure 4-16 illustrates an interconnection wiring diagram and figure 4-17 illustrates a functional block diagram of the unit.

4-5. DISPLAY TERMINAL MECHANICAL PROCEDURES

Tables 4-2 through 4-8 provide removal and replacement procedures for the major mechanical assemblies of the Display Terminal.

This space reserved for notes.

SPECIAL EQUIPMENT REQUIRED (None)	
PURPOSE OF ADJUSTMENT	
Provide a display area of proper height and width dimensions for deflection format used.	
RELATED ADJUSTMENTS	
Major deflection coil adjustment (figure 4-2)	
Minor deflection coil adjustment (figure 4-3)	
Line spacing adjustment (figure 4-9)	
PROCEDURE	
NOTE	
Perform this adjustment after any field change requiring installation of variations of position address board (A10) or deflection board (A5).	
This adjustment may affect display quality as well as image size and should be performed before any other display adjustments.	
1. Remove faceplate and cover assembly (table 4-2).	
2. Apply primary power to Display Terminal and fill screen with characters.	
3. Measure size of image area.	
FORMAT	IMAGE AREA
12 x 60	9.5 x 3.75
16 x 64	9.5 x 3.5
NOTE	
The two dimensions are not separately adjustable; when width is adjusted to 9.5 inches, height should be approximately as listed.	
4. If required, adjust R48 to produce a display of proper dimensions for Display Terminal deflection format.	
5. Replace faceplate and cover assembly.	

Figure 4-1. Image Area Adjustment (Sheet 1)




Figure 4-1. Image Area Adjustment (Sheet 2)

SPECIAL EQUIPMENT REQUIRED (None)
PURPOSE OF ADJUSTMENT Provide overall horizontal display alignment.
RELATED ADJUSTMENTS Antipincushion magnet adjustment (figure 4-4) Minor deflection coil adjustment (figure 4-3) Character symmetry adjustment (figure 4-8) Line spacing adjustment (figure 4-9)
PROCEDURE 1. Remove faceplate and cover assembly (table 4-2). 2. Apply primary power to Display Terminal and fill screen with uppercase E or H characters. 3. Rotate major deflection coil clockwise or counterclockwise as required to align characters horizontally on display screen. 4. Adjust antipincushion magnet as described in figure 4-4. NOTE Antipincushion magnet must be adjusted after this adjustment is performed.

Figure 4-2. Major Deflection Coil Adjustment (Sheet 1)




Figure 4-2. Major Deflection Coil Adjustment (Sheet 2)

SPECIAL EQUIPMENT REQUIRED (None)
PURPOSE OF ADJUSTMENT Provide a display with proper horizontal and vertical alignment relative to display screen.
RELATED ADJUSTMENTS Major deflection coil adjustment (figure 4-2) Antipincushion magnet adjustment (figure 4-4) Character symmetry adjustment (figure 4-8) Line spacing adjustment (figure 4-9)
PROCEDURE <ol style="list-style-type: none">1. Remove faceplate and cover assembly (table 4-2).2. Loosen minor deflection coil clamp and slide coil as far forward as possible.3. Apply primary power to Display Terminal and fill screen with characters.4. Rotate coil clockwise or counterclockwise until characters are aligned with vertical axis of display screen.5. Turn power off, tighten minor deflection coil clamp, and close top cover.6. Replace faceplate.7. Reapply power to Display Terminal.8. Recenter display as described in figure 4-5. <p style="text-align: center;">NOTE</p> <p style="text-align: center;">This adjustment should be performed whenever the CRT is replaced.</p>

Figure 4-3. Minor Deflection Coil Adjustment (Sheet 1)




Figure 4-3. Minor Deflection Coil Adjustment (Sheet 2)

SPECIAL EQUIPMENT REQUIRED (None)
PURPOSE OF ADJUSTMENT Provide even character spacing and alignment of the display.
RELATED ADJUSTMENTS Major deflection coil adjustment (figure 4-2) Minor deflection coil adjustment (figure 4-3) Line spacing adjustment (figure 4-9) Character symmetry adjustment (figure 4-8)
PROCEDURE <ol style="list-style-type: none">1. Remove faceplate and cover assembly (table 4-2).2. Apply primary power to Display Terminal and fill screen with characters.3. Loosen antipincushion magnet setscrews.4. Slide antipincushion magnet as far forward on major deflection coil as possible.5. Rotate antipincushion magnet clockwise or counterclockwise until characters are evenly spaced and aligned horizontally.6. Turn power off and tighten antipincushion magnet setscrews.7. Apply primary power and recheck adjustment.8. Replace faceplate and cover assembly. <p style="text-align: center;">NOTE</p> <p>This adjustment should be performed after the major deflection coil is adjusted.</p> <p>When the antipincushion magnet is as far forward as possible on the major deflection coil the greatest effect on the display screen is produced.</p>

Figure 4-4. Antipincushion Magnet Adjustment (Sheet 1)




Figure 4-4. Antipincushion Magnet Adjustment (Sheet 2)

SPECIAL EQUIPMENT REQUIRED (None)
PURPOSE OF ADJUSTMENT Provide a character display that is centered on the display screen.
RELATED ADJUSTMENTS Image area adjustment (figure 4-1)
PROCEDURE
<ol style="list-style-type: none">1. Remove faceplate and cover assembly (table 4-2).2. Apply primary power to Display Terminal and fill screen with characters.3. Replace faceplate.4. Alternately adjust display centering magnet tabs clockwise or counterclockwise until display is centered in faceplate cutout and no shadows are present at display corners.5. Write a few asterisks (*) near the center of the display.6. Adjust focus control R02 for sharpest display possible.
NOTE
Image area (figure 4-1) should be properly adjusted before attempting this procedure.

Figure 4-5. Display Centering Magnet Tab Adjustment (Sheet 1)





Figure 4-5. Display Centering Magnet Tab Adjustment (Sheet 2)

SPECIAL EQUIPMENT REQUIRED (None)
PURPOSE OF ADJUSTMENT Provide a display of proper intensity.
RELATED ADJUSTMENTS Clock adjustment (figure 4-7)
PROCEDURE
<ol style="list-style-type: none"> 1. Remove faceplate (table 4-2). 2. Apply primary power to Display Terminal. 3. With a blank display screen, adjust control G1 clockwise until center starting dot and retrace lines appear, then counterclockwise until they just disappear. 4. Write some characters at various locations and adjust control G2 until characters are bright and clear but do not "bloom" or defocus. 5. Readjust control G1 as described in step 3. 6. If characters are excessively bright, adjust G1 fully counterclockwise momentarily. Adjust G2 clockwise and then readjust G1 as described in step 3.
NOTE
Conditions (a), (b), and (c), as listed below should now be satisfied.
<ol style="list-style-type: none"> (a) With no display on screen, retrace lines and center starting dot should not be visible. (b) With a full display screen, and front panel INTENSITY control fully counterclockwise, all strokes of all characters should be visible. (c) With a full display screen, and front panel INTENSITY control fully clockwise, characters should be bright and clear but should not "bloom" or defocus.
NOTE
Control G2 should not be set within 1/4 turn of full counterclockwise position. This will cause poor focus and/or too dim a display.

Figure 4-6. Intensity Control Adjustment (Sheet 1)



AA120

Figure 4-6. Intensity Control Adjustment (Sheet 2)

UNISCOPE 100 Display Terminal

SPECIAL EQUIPMENT REQUIRED (None)
PURPOSE OF ADJUSTMENT Provide a stable display, free of jitter.
RELATED ADJUSTMENTS Intensity control adjustment (figure 4-6)
PROCEDURE 1. Remove faceplate and cover assembly (table 4-2). 2. Apply primary power to Display Terminal. 3. Erase any characters near center of display screen. 4. Adjust control G2 clockwise until retrace lines appear and start-of-trace dot is present at center of display screen. 5. Adjust R12 on character generator board (A8) until start-of-trace dot is minimum in size. Retrace lines and any characters displayed should remain stable. 6. Readjust G2 as described in figure 4-6.
NOTE This adjustment should be performed whenever a new position address or deflection board is installed, or if primary is changed from either 50 or 60 Hz.

SPECIFICATIONS

CHARACTER GENERATOR BOARD, A8

CLOCK
ADJUSTMENT



AA105

Figure 4-7. Clock Adjustment (Sheet 2)

SPECIAL EQUIPMENT REQUIRED (None)
PURPOSE OF ADJUSTMENT Provide display characters of proper symmetry.
RELATED ADJUSTMENTS Clock Adjustment (figure 4-7)
PROCEDURE <ol style="list-style-type: none">1. Remove faceplate and cover assembly (table 4-2).2. Apply primary power to Display Terminal, and enter an uppercase letter X near center of display screen.3. Adjust R38 and R41 to full clockwise position.4. Slowly adjust R38 counterclockwise. Initially, a bright spot should be quite evident at upper end of lower left to upper right stroke. As R38 is adjusted spot should dim then disappear. Further adjustment should cause line to shorten in length. Adjust R38 so that spot is barely visible.5. Adjust R41 slowly counterclockwise until lower right to upper left stroke of X is as straight as possible. Both strokes should now be symmetrical and straight.

Figure 4-8. Character Symmetry Adjustment (Sheet 1)




Figure 4-8. Character Symmetry Adjustment (Sheet 2)

SPECIAL EQUIPMENT REQUIRED (None)
PURPOSE OF ADJUSTMENT Provide proper horizontal and vertical character spacing on display screen.
RELATED ADJUSTMENTS Major deflection coil adjustment (figure 4-2) Minor deflection coil adjustment (figure 4-3) Image area adjustment (figure 4-1) Antipincushion magnet adjustment (figure 4-4)
PROCEDURE 1. Remove faceplate and cover assembly (table 4-2). 2. Apply primary power to Display Terminal and fill screen with characters. 3. Adjust R6 on position address board (A10) to full counterclockwise position. 4. Slowly adjust R6 clockwise until equal spacing between horizontal lines and optimum vertical character alignment is obtained.

Figure 4-9. Line Spacing Adjustment (Sheet 1)





Figure 4-9. Line Spacing Adjustment (Sheet 2)

Table 4-2. Faceplate and Cover Assembly Removal and Replacement

Step	Procedure
1	Remove primary power from Display Terminal.
2.	Remove faceplate by releasing four tension fasteners located near corners of CRT face (figure 4-10). Apply pressure at these points and pull straight away until faceplate clears front panel WAIT, INTENSITY, and POWER controls and indicators.
3.	Release top cover by rotating fastener screws clockwise until spring clips release.
4.	Lift top cover and swing back until cover clears two hinge slots at bottom rear of unit.
5	Slide side panel back approximately 1/2 inch to release front clip, lift up and slightly outward to release bottom clips, and remove side panel.
6	To replace cover assembly and faceplate, follow these steps in reverse order.
	NOTE
	Make certain that the side panels are on the outside of the top cover lip when assembling.

Table 4-3. Keyboard Removal and Replacement

Step	Procedure
1	Disconnect primary power from Display Terminal.
2	Turn keyboard thumbscrews counterclockwise until keyboard is released from Display Terminal.
3	Pull keyboard straight away from unit.
4	Disconnect keyboard cable from keyboard and remove keyboard.
5	To replace keyboard follow these steps in reverse order.



AA118

Figure 4-10. UNISCOPE 100 Display Terminal Cover Removal

ME6015


UNISCOPE 100 Display Terminal

Table 4-4. Chimney Removal and Replacement

Step	Procedure
1	Remove primary power from Display Terminal.
2	Remove faceplate and top cover (table 4-2).
	CAUTION
	Be careful not to damage CRT or yoke assemblies when lifting chimney assembly.
3	Press chimney retainers (figure 4-11) at front and rear of chimney assembly and lift chimney assembly vertically.
4	To replace, follow these steps in reverse order.

NOTE

Make certain that cables are routed through cutout in base of chimney assembly and not pinched underneath.



AA108

Figure 4-11. UNISCOPE 100 Display Terminal Rear View

UNISCOPE 100 Display Terminal

Table 4-5. Filter Removal and Replacement

Step	Procedure
1	Locate filter tray handle on bottom of unit (figure 4-12).
2	Slide filter tray and filter out until unit is cleared and remove filter.
3	Clean or replace filter and insert in filter tray.
4	Replace filter tray and filter in retainer under unit.

Table 4-6. Power Supply Removal and Replacement

Step	Procedure
1	Remove primary power from Display Terminal.
2	Remove faceplate and left side panel (table 4-2).
3	Place Display Terminal on right side.
4	Remove high voltage cap from CRT.
5	Rotate two power supply turnlock fasteners on bottom of unit (figure 4-12) counterclockwise until power supply releases (approximately 1/2 turn).
6	Remove plug A2J1 from power supply.
7	Remove power supply assembly from Display Terminal.
8	To replace, follow these steps in reverse order.




Figure 4-12. UNISCOPE 100 Display Terminal Bottom View

Table 4-7. Fan Removal and Replacement

Step	Procedure
1	Unplug power cord from wall outlet.
2	Remove faceplate and cover assembly (table 4-2).
3	Remove chimney assembly (table 4-4).
4	Remove printed circuit boards A3 and A5 from card guides inside chimney assembly.
5	Place Display Terminal on right side.
6	Unplug AC input connectors to fan.
7	Remove card guides mounted on fan by removing four machine screws which hold fan and card guides (figure 4-13).
8	Remove fan from Display Terminal.
9	Install replacement fan by following steps in reverse order.

Table 4-8. CRT Removal and Replacement

Step	Procedure
	<div style="border: 1px solid black; padding: 2px; display: inline-block;">WARNING</div>
	Handle the CRT with care. Breakage of the CRT, which contains a high vacuum, may result in injury from flying glass. Do not scratch the tube or subject it to any pressure at any time.
1	Remove primary power from Display Terminal.
2	Remove faceplate and cover assembly (table 4-2).
3	Remove high voltage plug from CRT.
4	Remove tube socket plug from CRT.
5	Put a temporary reference mark in vertical position on CRT yoke assemblies to aid in alignment during reassembly.
6	Label leads going to major and minor deflection coils to correspond to pin numbers and disconnect them.
	NOTE
	Figure 4-11 illustrates the procedure described in this table.
7	Loosen the four CRT retaining strap screws (figure 4-13).
8	Gently raise base of CRT bell from double backed adhesive strip underneath.

Table 4-8. CRT Removal and Replacement (Cont)

Step	Procedure
9	Carefully remove CRT by lifting up and tilting so that retaining strap is cleared. Set CRT face down on some soft material.
10	Remove screw clamp from neck of CRT.
11	Remove minor deflection coil.
12	Remove plastic retaining ring.
13	Remove major deflection coil.
14	To install replacement tube, follow reverse order of removal procedures but do not replace covers. Make certain that double-backed adhesive strips are correctly placed between base of CRT bell and major deflection coil, CRT and retaining strap, CRT and power supply housing.
15	Make certain that yoke assemblies are properly oriented on CRT.
16	Follow procedures listed in figures 4-1 through 4-5.
17	Replace faceplate and cover assembly (table 4-2) and return unit to service.





Figure 4-13. UNISCOPE 100 Display Terminal CRT Removal and Replacement

UNISCOPE 100 Display Terminal

This page intentionally left blank.



AA123

Figure 4-14. Keyboard Disassembly

UNISCOPE 100 Display Terminal

This page intentionally left blank.





Figure 4-15. Voltage Bus Locations

UNISCOPE 100 Display Terminal

This page intentionally left blank.



AA112

Figure 4-16. Interconnection Wiring Diagram (Sheet 1)

This page intentionally left blank.





Figure 4-16. Interconnection Wiring Diagram (Sheet 2)



* A9 ON THE 3538-04, -05,
 AS ON THE 3538-06.

AA122

Figure 4-17. Functional Block Diagram

MR6032

UNIVAC
UNISCOPE 100
DISPLAY
TERMINAL
TYPE 3536-06

**ILLUSTRATED
PARTS BREAKDOWN**

AUGUST, 1973

RESTRICTED DISTRIBUTION

The information contained in this publication is the property of Sperry Univac. It is submitted in confidence and must not be disclosed to others except in confidence with the written permission of an officer of Sperry Univac. This copy is not to be reproduced or duplicated without permission in writing from a duly authorized representative of Sperry Univac. This publication is subject to recall.

CONTENTS

Heading	Title	Page
SECTION 1. INTRODUCTION		
1-1.	General	1-1
1-2.	Group Assembly Parts List, Section 2	1-1
1-3.	General	1-1
1-4.	Figure and Index Number Column	1-1
1-5.	Part Number Column	1-1
1-6.	Reference Designation Column	1-1
1-7.	Description Column	1-2
1-8.	Units Per Assembly Column	1-2
1-9.	Used On Code Column	1-2
1-10.	Reference Designation Index, Section 3	1-2
1-11.	Numerical Index, Section 4	1-2
1-12.	How to Use the Illustrated Parts Breakdown	1-2
1-13.	When the Part Location is Known	1-2
1-14.	When the Reference Designation is Known	1-3
1-15.	When the Part Number is Known	1-3

SECTION 2. GROUP ASSEMBLY PARTS LIST

UNISCOPE 100, Type 3536-06	2-2
Cabinet Assembly, Wired 50/60 Hz	2-6
Power Supply Assembly	2-12
Keyboard, UNISCOPE 100	2-14
Keycap Descriptions - UNISCOPE 100	2-20
Cable Assembly, Internal Modem	2-24
Wiring Harness Assembly	2-24
Wiring Harness, Power Supply	2-26
Keyboard Cable Assembly	2-27
Cable Assembly, Aux I/F, Internal	2-27
Cable Assembly, Parallel I/F (3760)	2-28

SECTION 3. REFERENCE DESIGNATION INDEX

SECTION 4. NUMERICAL INDEX

ILLUSTRATIONS

Figure	Title	Page
1.	UNISCOPE 100, Type 3536-06 (Sheet 1 of 2)	2-3
2.	Cabinet Assembly (Sheet 1 of 3)	2-7
3.	Power Supply Assembly	2-13
4.	Keyboard, UNISCOPE 100	2-19
5.	Keycaps	2-23
6.	Cable Assembly, Internal Modem	2-24
7.	Wiring Harness Assembly	2-25
8.	Wiring Harness, Power Supply	2-26
9.	Keyboard Cable Assembly	2-27
10.	Cable Assembly, Aux I/F, Internal	2-27
11.	Cable Assembly, Parallel I/F (3760)	2-28

SECTION 1

INTRODUCTION

1-1. GENERAL

This Illustrated Parts Breakdown lists and illustrates the field-replaceable parts for the UNIVAC® UNISCOPE® 100 Display Terminal Type 3536-06.

This breakdown is divided into four sections as described in the following paragraphs. The information contained in these sections is used for requisitioning, storing, issuing, and identifying parts.

1-2. GROUP ASSEMBLY PARTS LIST, SECTION 2

1-3. GENERAL

The Group Assembly Parts List consists of a breakdown of the Display Terminal into assemblies, subassemblies, and detail parts as shown on the related illustrations. The lowest order of disassembly is dictated by current field practices, and field personnel should not replace or disassemble parts below the order that is presented. Each assembly listed in the Group Assembly Parts List is followed immediately by a list of component parts of the assembly. Component parts are indented below the assembly to show their relationship to the assembly. Attaching parts are listed immediately following the parts which they attach. Items which are made from raw stock, such as cut lengths of wire and insulating materials, are not included in the Group Assembly Parts List.

Index numbers on the illustrations correspond to the index numbers in the Group Assembly Parts List. A circled index number indicates an assembly whose component parts are indexed. Assemblies or subassemblies whose component parts are shown exploded are indexed in disassembly sequence.

Some illustrations are contained on foldout sheets. When the sheets are unfolded, illustrations are fully visible and can be used concurrently with the parts list.

1-4. FIGURE AND INDEX NUMBER COLUMN

In this column, the digits preceding the hyphen refer to the figure in which a part or assembly is illustrated. The digits following the hyphen are the index numbers of procurable and non-procurable parts and assemblies illustrated on the figure.

1-5. PART NUMBER COLUMN

This column contains the Univac part number for the field-replaceable parts of the unit. "No Number" indicates a group of parts for which no overall assembly number has been assigned.

1-6. REFERENCE DESIGNATION COLUMN

This column lists the reference designation of each part appearing on the schematic diagram for this particular unit. Mechanical parts are not identified in this type of listing.

® UNIVAC is a registered trademark of the Sperry Rand Corporation. Other Sperry Rand trademarks appearing in this publication are: UNISCOPE.

1-7. DESCRIPTION COLUMN

This column contains the names and descriptions of the replaceable assemblies, subassemblies, and detail parts of the unit. The indentation system used in presenting the descriptions shows the relationship between assemblies, subassemblies, and detail parts. For example, an item listed in the third indentation is a component of the assembly or subassembly listed in the preceding second indentation.

Parts which attach other parts of assemblies are preceded and followed by an asterisk (*), and are listed immediately after the parts or assemblies they attach.

1-8. UNITS PER ASSEMBLY COLUMN

The quantities shown in this column for indexed items are the quantities used at the indicated location(s) or similar locations on the assembly. The quantities shown for items listed between asterisks are the quantities required to mount the specified number of assemblies, subassemblies, or parts which they attach.

The letters AR denote "as required" and are used to indicate parts of which an indeterminate number may be required. The letters REF indicate that an assembly is shown completely assembled in a preceding illustration, and is now shown exploded in the illustration where the reference appears. In this case the description has a notation that refers to the illustration in which the assembly is shown completely assembled and indexed. The entry NP indicates that the part or assembly is non-procurable.

1-9. USED ON CODE COLUMN

Part variations within the Display Terminal are indicated by alpha and numeric symbols in the Used On Code column. In cases where the Used on Code column has been left blank, parts listed apply to all Display Terminals covered in this book.

1-10. REFERENCE DESIGNATION INDEX, SECTION 3

The Reference Designation Index is a list of parts for which a reference designation is given in the Group Assembly Parts List. The parts are listed in alphanumeric order by reference designation; figure and index numbers are given to aid in the location of the part in the Group Assembly Parts List.

1-11. NUMERICAL INDEX, SECTION 4

The Numerical Index provides a parts list in numerical order by part number. The figure and index number are given for each part to aid in the location of the part in the Group Assembly Parts List.

1-12. HOW TO USE THE ILLUSTRATED PARTS BREAKDOWN

1-13. WHEN THE PART LOCATION IS KNOWN

To obtain information about a part when its location is known, the following steps should be taken:

- (a) Refer to the applicable assembly breakdown illustration.
- (b) Compare the part with the illustration until the part is located.

- (c) Note the index number for the part.
- (d) Locate the index number in the corresponding Group Assembly Parts List.
- (e) Find the part number, name and reference designation, where applicable, opposite the index number.

1-14. WHEN THE REFERENCE DESIGNATION IS KNOWN

To locate a part when the reference designation is known, the following steps should be taken:

- (a) Locate the reference designation in the Reference Designation Index (Section 3).
- (b) Note the figure and index number shown opposite the reference designation.
- (c) Locate the figure and index number in the Group Assembly Parts List (Section 3).

1-15. WHEN THE PART NUMBER IS KNOWN.


To locate a part when the part number is known, the following steps should be taken:

- (a) Locate the part number in the Numerical Index (Section 4).
- (b) Note the figure and index number shown opposite the part number.
- (c) Locate the figure and index number in the Group Assembly Parts List (Section 2).

SECTION 2
GROUP ASSEMBLY PARTS LIST

UNISCOPE 100 DISPLAY TERMINAL
TYPE 3536-06

FIG # INDEX NO.	PART NUMBER	REF. DESIG.	1	2	3	4	5	6	7	DESCRIPTION	NO. USED PER ON ASSY CODE
1-	NO NUMBER									UNISCOPE 100, TYPE 3536-06	NP
-1	2807953	00								* CABINET ASSEMBLY, WIRED 50/60 HZ (SEE FIG 2 FOR DETAIL BREAKDOWN)	1
-2	2807490	00								* SIDE PANEL COLOR KIT, GREEN	1
-3	2807416	00								* . . PANEL, LEFT, FINISHED, GREEN	1
-4	2807775	00								* . . PANEL, RIGHT, FINISHED, GREEN	1
-2	2807490	01								* SIDE PANEL COLOR KIT, GOLD	1
-3	2807416	01								* . . PANEL, LEFT, FINISHED, GOLD	1
-4	2807775	01								* . . PANEL, RIGHT, FINISHED, GOLD	1
-2	2807490	02								* SIDE PANEL COLOR KIT, RUSSET	1
-3	2807416	02								* . . PANEL, LEFT, FINISHED, RUSSET	1
-4	2807775	02								* . . PANEL, RIGHT, FINISHED, RUSSET	1
-2	2807490	03								* SIDE PANEL COLOR KIT, ORANGE	1
-3	2807416	03								* . . PANEL, LEFT, FINISHED, ORANGE	1
-4	2807775	03								* . . PANEL, RIGHT, FINISHED, ORANGE	1
-2	2807490	04								* SIDE PANEL COLOR KIT, OLIVE	1
-3	2807416	04								* . . PANEL, LEFT, FINISHED, OLIVE	1
-4	2807775	04								* . . PANEL, RIGHT, FINISHED, OLIVE	1
-5	2805251	XX								* KEYBOARD, UNISCOPE 100 (SEE FIG 4 FOR DETAIL BREAKDOWN)	1
-5	2808036	XX								* KEYBOARD ASSEMBLY, ALPHANUMERIC (SEE FIG 4 FOR DETAIL BREAKDOWN)	1
-5	2808037	XX								* KEYBOARD ASSEMBLY, ALPHA WITH PROTECT (SEE FIG 4 FOR DETAIL BREAKDOWN)	1
-5	2808038	XX								* KEYBOARD ASSEMBLY, ALPHA (SEE FIG 4 FOR DETAIL BREAKDOWN)	1
-5	2808039	XX								* KEYBOARD ASSEMBLY, NUMERIC (SEE FIG 4 FOR DETAIL BREAKDOWN)	1
-6	2807456	00								* FRONT PANEL ASSEMBLY	1
-7	2807918	03 A7								* 1024 I.C. MEMORY	1
-7	2805290	05 A7								* 1024 MEMORY (MAGNETIC CORE)	1
-8	2807786	02 A8								* 64 CHARACTER GENERATOR	1
-8	2807816	02 A8								* 96 CHARACTER GENERATOR	1
-9	2808052	00 A9								* CONTROL, WITH PROTECT FORMAT	1
-9	2808053	00 A9								* CONTROL, WITHOUT PROTECT FORMAT	1
-10	2805338	09 A10								* POSITION ADDRESS, 12 X 80	1
-10	2805352	07 A10								* POSITION ADDRESS, 16 X 64	1
-11	2808054	00 A11								* I/O-1, SYNC-U	1
-11	2808056	00 A11								* I/O-1, SYNC-IBM	1
-11	2808059	00 A11								* I/O-1, ASYNC-U	1
-11	2808061	00 A11								* I/O-1, ASYNC-IBM	1
-12	2808055	00 A12								* I/O-2, SYNC-U	1
-12	2808057	00 A12								* I/O-2, SYNC-IBM	1
-12	2808060	00 A12								* I/O-2, ASYNC-U	1
-12	2808062	00 A12								* I/O-2, ASYNC-IBM	1
-12	2808063	00 A12								* I/O-2, SYNC-DIRECT	1
-13	2808058	00 A13								* AUXILIARY INTEKFACE (OPTIONAL)	1
-14	2807988	01 A5								* DEFLECTION, 12 X 80	1
-14	2807992	01 A5								* DEFLECTION, 16 X 64	1
-15	2807934	02 A3								* REGULATOR/CONTROL	1
-16	2807982	00 W5								* KEYBOARD CABLE ASSEMBLY (SEE FIG 9 FOR DETAIL BREAKDOWN)	1
-17	2805285	00 W4								* CABLE ASSEMBLY, AUX I/F, INTERNAL (PRESENT ONLY IF AUX INTERFACE BOARD A13 IS INSTALLED - SEE FIG 10 FOR DETAIL BREAKDOWN)	1
-18	7099615	00								* CABLE ASSEMBLY, PARALLEL I/F (3760) (PRESENT ONLY IF 3760 INTERFACE BOARDS ARE INSTALLED - SEE FIG 11 FOR DETAIL BREAKDOWN)	1




TTIII

Figure 1. UNISCOPPE 100, Type 3536-06
(Sheet 1 of 2)

UNISCOPE 100 DISPLAY TERMINAL
TYPE 3536-06

This page intentionally left blank.

This space reserved for notes.




TT101

Figure 1. UNISCOPE 100, Type 3536-06
(Sheet 2 of 2)

UNISCOPE 100 DISPLAY TERMINAL
TYPE 3536-06

FIG 4 INDEX NO.	PART NUMBER	REF. DESIG.	DESCRIPTION	NO. USED PER ON ASSY CODE
2-	2807953 00		CABINET ASSEMBLY, WIRED 50/60 HZ	1
-1	2807738 01		CASE, BOTTOM AND FRONT	1
-2	2807759 01		COVER, TOP	1
-3	4913556 03		SCREW, TAPPING, THD FMG, PAN HD, X-REC, NO. 8, 0.625 LG	2
-4	4912548 02		WASHER, FLAT, ROUND, NO. 8	2
-4A	2808079 00		SPACER, TOP COVER LATCH	2
-5	2808019 00		LATCH, TOP COVER	2
-6	2899095 02		TERMINAL, QUICK-DISCONNECT, DOUBLE-MALE, .187 SERIES	1
-7	4912524 01		SCREW, MACH, PAN HD, NO. 6-32, 0.312 LG	1
-8	4912551 01		LOCKWASHER, BRONZE, NO. 6	1
-9	4912540 01		NUT, HEX, NO. 6-32	1
-10	2899194 00	S01	SWITCH, TOGGLE, SPST	1
-11	2899098 01		RETAINER AND NUT ASSY	2
-12	2899316 00		KNOB AND LENS ASSY, POWER IND	1
-13	2807648 00		KNOB, INTENSITY	1
-14	2899509 00		KNOB AND LENS ASSY, WAIT IND	1
-15	2899404 00	CB01	CIRCUIT BREAKER ASSY	1
-16	4912524 07		SCREW, MACH, PAN HD, NO. 6-32, 0.188 LG	2
-17	4912550 01		LOCKWASHER, NO. 6	2
-18	2899103 01		LAMPHOLDER, MIN, SLIDE SOCKET	2
-19	2899110 01	DS03,0504	LAMP, INCAN, MIN, SLIDE BASE	2
-20	2899017 03	V1	TUBE, ELECTRON, CATHODE RAY TUBE	1
-21	2807351 00		MOUNTING ASSY, CRT	1
-22	4950341 16		PLASTIC SHEET AND STRIP, PRES SENS, ADH COATED, CELLULAR	AR
-23	4912524 00		SCREW, MACH, PAN HD, NO. 6-32, 0.250 LG	4
-24	2807950 01		COVER, POWER SUPPLY	1
-25	2899380 03		NUT, SHEET SPRING, NO. 10-32UNF	4
-26	4912551 03		LOCKWASHER, BRONZE, NO. 10	1
-27	2899377 00		BUMPER, RUBBER, SCREW-ON, 1 INCH	4
-28	4912527 04		SCREW, MACH, PAN HD, NO. 10-32UNF, 0.750 LG	4
-29	2807954 00	A2	POWER SUPPLY ASSEMBLY (SEE FIG 3 FOR DETAIL BREAKDOWN)	1
-30	3007287 00		RECEPTACLE, TURNLOCK FASTENER, 0.055 - 0.090 FRAME THK	2
-31	4914485 04	0501	HORN, ELECTRIC, AUDIBLE ALARM	1
-32	2808006 00		CONNECTOR BRACKET, 1/0	1
-33	911651 03		NUT, SHEET SPRING, V-TYPE	2
-34	4912524 01		SCREW, MACH, PAN HD, NO. 6-32, 0.312 LG	2
-35	2807637 01		COVER PLATE, CONNECTOR	1
-36	2899418 01		FASTENER, SPRING TENSION, TRIM	2
-37	3011815 00		SCREW ASSY, CONNECTOR PLUG, NO. 4-40	2
-38	2807976 00	#3	CABLE ASSEMBLY, INTERNAL MODEM (SEE FIG 6 FOR DETAIL BREAKDOWN)	1
-39	2807850 00		AIR DUCT ASSEMBLY	1
-40	2807955 01	#1	WIRING HARNESS ASSEMBLY (SEE FIG 7 FOR DETAIL BREAKDOWN)	1

FIG & INDEX NO.	PART NUMBER	REF. DESIG.	1	2	3	4	5	6	7	DESCRIPTION	NO. USED PER ON ASSY CODE
2-41	2807461 00	A16L2								MINOR DEFLECTION YOKE ASSEMBLY	1
-42	2805493 00	A16L1								COIL CENTERING RING	1
-43	2899305 00	A16L1								TUBE DEFLECTION COIL ASSEMBLY	1
-44	2807366 00									ANTI-PINCHION MAGNET RING, MOLDED, ASSY	1
-45	4912539 00									SETScrew HEXAGON SOCKET 1/4-20	2
-46	2807707 00									BRACKET, CARD GUIDE, WELDED	1
-47	2807803 00									CARD GUIDE	1
-48	2807803 01									CARD GUIDE	1
-49	4912550 01									LOCKWASHER, NO.6	4
-50	4912524 07									SCREW, MACH, PAN HD, NO.6-32, 0.188 LG	4
-51	4912550 02									LOCKWASHER, NO.8	2
-52	4912525 03									SCREW, MACH, PAN HD, NO.8-32, 0.436 LG	2
-53	2808012 00	A14								MOTHER BOARD ASSY, WIRED	1
-54	4912551 02									LOCKWASHER, BRONZE, EXT TOOTH, NO.8	1
-55	4912550 02									LOCKWASHER, NO.8	1
-56	4912525 01									SCREW, MACH, PAN HD, NO.8-32, 0.312 LG	2
-57	2809100 01									BUSHING, STRAIN RELIEF, RT ANGLE	1
-58	2807797 00									CARD GUIDE, REAR	1
-59	2807798 00									BRACKET, CONNECTOR	1
-60	3156579 04									TY WRAP	2
-61	2899351 01	B01								FAN, AXIAL, 50/60 HZ, 100 CFM	1
-62	4912524 14									SCREW, MACH, PAN HD, NO.6-32, 2.00 LG	4
-63	2807802 00									CARD GUIDE, FRONT	1
-64	4912524 04									SCREW, MACH, PAN HD, NO.6-32, 0.500 LG	2
-65	2899395 00									NUT, CLAMPING, NO.6-32	6
-66	2808009 00									AIR DUCT, EXHAUST	1
-67	911651 03									NUT, SHEET SPRING, V-TYPE	1
-68	4912524 02									SCREW, MACH, PAN HD, NO.6-32, 0.375 LG	1
-69	2808041 00									TRAY, FILTER, AIR INLET	1
-70	4956810 05									PLASTIC MATERIAL, CELLULAR, 0.375 THK, 30 PORES/INCH	1
-71	2807772 00									RETAINER, AIR FILTER	1
-72	911651 03									NUT, SHEET SPRING, V-TYPE	1
-73	4912524 01									SCREW, MACH, PAN HD, NO.6-32, 0.312 LG	1
-74	2807981 01									POWER CORD, AC	1
-75	3007700 02									CLAMP, LOOP, POLYPROPYLENE, 0.260 W, 2.085 LG, 0.375 LOOP	1




TT103

Figure 2. Cabinet Assembly (Sheet 1 of 3)

UNISCOPE 100 DISPLAY TERMINAL
TYPE 3536-06

This page intentionally left blank.

This space reserved for notes.



TT104


Figure 2. Cabinet Assembly
(Sheet 2 of 3)

UNISCOPE 100 DISPLAY TERMINAL
TYPE 3536-06

This page intentionally left blank.

This space reserved for notes.

GROUP ASSEMBLY PARTS LIST




TT106

Figure 2. Cabinet Assembly
(Sheet 3 of 3)

UNISCOPE 100 DISPLAY TERMINAL
TYPE 3536-06

FIG 4 INDEX NO.	PART NUMBER 987654321AANN	REF. DESIG.	DESCRIPTION	NO. USED PER ON ASSY CODE
3-	2807954 00 A2		POWER SUPPLY ASSEMBLY (SEE FIG 2 FOR NEXT HIGHER ASSY)	1
-1	2807764 00		HOUSING, POWER SUPPLY	1
-2	2807952 00		CAPACITOR ASSEMBLY	1
-3	2899105 03 C3		CAPACITOR, FIXED, ELECTROLYTIC, 4500 UF, 75 VDC	1
-4	2899105 01 C2		CAPACITOR, FIXED, ELECTROLYTIC, 7400 UF, 35 VDC	1
-5	2899105 02 C4		CAPACITOR, FIXED, ELECTROLYTIC, 890 UF, 75 VDC	1
-6	2899105 00 C1		CAPACITOR, FIXED, ELECTROLYTIC, 17000 UF, 20 VDC	1
-7	2807951 00		RETAINER, CAPACITOR	1
-8	905818 03		NUT, SHEET SPRING, U-TYPE, NO. 6	2
-9	4912524 00		SCREW, MACH, PAN HD, NO. 6-32, 0.875 LG	1
-10	4912524 02		SCREW, MACH, PAN HD, NO. 6-32, 0.375 LG	1
-11	2899262 00 P51		POWER SUPPLY SUBASSEMBLY, VOLTAGE DOUBLER, 15 KV	1
-12	4912551 02		LOCKWASHER, EXT TOOTH, BRONZE, 0.025 THK, 0.176 ID, 0.381 OD	2
-13	4912540 02		NUT, MACH, HEX, NO. 6-32	2
-14	3008599 00		WASHER, PANEL FASTENER SCREW, NO. 2 STUO, 0.206 ID, 0.015 THK	2
-15	3011173 09		STUD, TURNLOCK FASTENER, 0.250 TO 0.269 GRIP RANGE	2
-16	2899012 00 CR2		RECTIFIER, SEMICONDUCTOR, FULL WAVE, SILICON, POWER STACK	1
-17	2899274 00 CR1		RECTIFIER, SEMICONDUCTOR, FULL WAVE, SILICON, BRIDGE	1
-18	2808010 00		HEAT SINK, LOW VOLTAGE PWR SUPPLY	1
-19	4912548 11		WASHER, FLAT, ROUND, 0.065 THK, 0.164 ID, 0.390 OD	4
-20	4912550 01		LOCKWASHER, SPRING, HELICAL, 0.037 THK, 0.151 ID, 0.253 OD	4
-21	4912540 01		NUT, MACH, HEX, NO. 6-32	5
-22	4912524 12		SCREW, MACH, PAN HD, NO. 6-32, 1.500 LG	1
-23	4912524 13		SCREW, MACH, PAN HD, NO. 6-32, 1.750 LG	1
-24	2807939 00		COVER, CONNECTOR, VOLTAGE SELECTOR	1
-25	2899467 00 T1		TRANSFORMER, POWER, STEP DOWN	1
-26	2899050 02		RIVET, BLIND, NYLON, 0.174 GRIP, 0.245 DIA, 0.470 LG	4
-27	2807905 00 A2M1		WIRING HARNESS, POWER SUPPLY (SEE FIG 8 FOR DETAIL BREAKDOWN)	1
-28	2899122 00 T2		TRANSFORMER, RF, HIGH VOLTAGE	1
-29	4912550 00		LOCKWASHER, SPRING, HELICAL, 0.031 THK, 0.124 ID, 0.212 OD	2
-30	4912540 00		NUT, MACH, HEX, NO. 6-40	2

FIG & INDEX NO.	PART NUMBER	REF. DESIG.	1 2 3 4 5 6 7	DESCRIPTION	NO. USED PER ON ASSY CODE
3-31	2899011 00	CR36 CH4	1	RECTIFIER, SEMICONDUCTOR, FULL WAVE, SILICON, POWER STACK	2
	4912540 01			* NUT, MACH, HEX, NO.6-32	REF
	4912548 11			* WASHER, FLAT, ROUND, 0.065 THK, 0.164 ID, 0.390 OD	REF
	4912550 01			* LOCKWASHER, SPRING, HELICAL, 0.037 THK, 0.151 ID, 0.253 OD	REF
	4912524 04			* SCREW, MACH, PAN HD, NO.6-32, 0.500 LG	2
-32	2899095 02			* TERMINAL, QUICK DISCONNECT, DOUBLE MALE, .187 SERIES	1
	4912540 01			* NUT, MACH, HEX, NO.6-32	REF
	4912551 01			* LOCKWASHER, EXT TOOTH, BRONZE, 0.022 THK, 0.150 ID, 0.320 OD	1
	4912524 01			* SCREW, MACH, PAN HD, NO.6-32, 0.512 LG	1



TT105

Figure 3. Power Supply Assembly

UNISCOPÉ 100 DISPLAY TERMINAL
TYPE 3530-06

FIG. & INDEX NO.	PART NUMBER	REF.	DESCRIPTION	NO. USED PER ON ASSY CODE
4-	2805251	XX	KEYBOARD, UNISCOPÉ 100 (SEE FIG 1 FOR NEXT HIGHER ASSY)	REF
-1	2805264	00	INDEX NO'S 17 THRU 33 ARE PECULIAR ITEMS FOR SPECIFIC KEYBOARD VARIATIONS AND ARE LISTED SEPARATELY FOR KEYBOARDS 2805251-10 THRU 2805251-18.	1
-2	2805495	00	PLATE, BUSHING, KEYBOARD	1
-3	2807745	00	SUPPORT, KEYBOARD, DIE CASTING	1
-4	2899152	00	THUMBSCREW, SLOTTED, KNURLED HEAD	2
-5	4912546	01	NUT, SHEET SPRING, PUSH-ON	2
-5A	4912550	01	WASHER, FLAT, ROUND, NO.6	7
-6	2805499	00	WASHER, LOCK (SPRING) HELICAL	7
-7	4912524	04	STANDOFF, CENTER, KEYBOARD	1
-8	2805256	00	SCREW, MACH, PAN HD, NO.6-32, 0.500 LG	9
-9	2805204	00	COVER, PROTECTIVE, KEYBOARD	1
-10	2807694	00	SPACER, KEYBOARD	1
-12	4914061	00	SPRING CLIP, KEYBOARD	2
-13	4912551	02	SCREW, TAPPING, THREAD-FORMING, PAN HD, NO.6-32	1
-14	2805268	05	LOCKWASHER, EXT TOOTH, BRONZE, NO.8	1
-15	2805022	05	STANDOFF, KEYBOARD	6
-16	4912796	01	SPACER, KEYBOARD	8
4-	2805251	10	NUT, SELF-LOCKING, HEX, NO.6-32	2
-17	2805202	01	KEYBOARD ASSY, PECULIAR ITEMS (NUMERIC PAD - INCLUDES NUMERIC KEYS 0 - 9, 3 SYMBOLS - PLUS (+), MINUS (-), PERCENT (%), EDITING KEYS, CURSOR CONTROL KEYS, SPACE, TAB, AND CARRIAGE RETURN)	1
-18	2807946	01	SPECIAL FUNCTION KEYS - SET A	1
-19	4912504	00	PANEL, KEYBOARD, DECORATIVE	1
-20	2805269	02	KEYSWITCHING ASSY, KEYBOARD	1
-21	2805235	00	SCREW, MACH, FLT HD, NO.6-32, 0.312 LG	1
-22	2805026	00	KEY PLUNGER RETURN	39
-23	2805458	10	BUSHING, PLUNGER	39
4-	2805243	10	PLUNGER, KEYSWITCH, MOLDED (SEE FIG 5 FOR DETAIL BREAKDOWN)	39
-17	2805202	04	KEYCAP KIT	1
-18	2807946	01	PLACEMENT CHART, KEYCAPS	NP
-19	4912504	00	KEYBOARD ASSY, PECULIAR ITEMS (UPPERCASE KEYBOARD - INCLUDES 26 ALPHA, 10 NUMERIC, AND 27 SPECIAL SYMBOL KEYS, PLUS SPACE, TAB, CARRIAGE RETURN, EDITING KEYS, AND CURSOR CONTROL KEYS)	REF
-20	2805269	02	SPECIAL FUNCTION KEYS - SET A	1
-21	2805235	00	PANEL, KEYBOARD, DECORATIVE	1
-22	2805026	00	KEYSWITCHING ASSY, KEYBOARD	1
-23	2805458	11	SCREW, MACH, FLT HD, NO.6-32, 0.312 LG	3
-24	2805253	00	KEY PLUNGER RETURN	74
-25	4913003	02	BUSHING, PLUNGER	75
-26	2805271	00	PLUNGER, KEYSWITCH, MOLDED (SEE FIG 5 FOR DETAIL BREAKDOWN)	74
-27	2805266	00	SPACE BAR ASSY, KEYBOARD	1
-28	2805245	00	PIN, SPRING, CHES, 3/32 DIA	2
-29	2807788	00	PLUNGER, SWITCH, SPACE BAR	1
-30	2805269	01	SPRING, SPACE BAR	1
			GUIDE, SWITCH, SPACE BAR	2
			COMPRESSION SPRING	1
			KEY PLUNGER RETURN	1

GROUP ASSEMBLY PARTS LIST

FIG & INDEX NO.	PART NUMBER	REF. DESIG.	1	2	3	4	5	6	7	DESCRIPTION	NO. USED PER ASSY	ON CODE
4-31	907451	05								. NUT, PUSH-ON	3	
-32	2807818	00								. BUTTON, PLUG, RECTANGLE	3	
-33	2805235	01								. BUSHING, PLUNGER	1	
	2805243	11								. PLACEMENT CHART, KEYCAPS	NP	
4-	2805251	12								KEYBOARD ASSY, PECULIAR ITEMS (UPPERCASE/LOWERCASE KEYBOARD - INCLUDES SAME KEYS AS 2805251-11 EXCEPT FOR LOWERCASE PROVISION AND 5 ADDITIONAL SYMBOLS) SPECIAL FUNCTION KEYS - SET A	REF	
-17	2805202	04								. PANEL, KEYBOARD, DECORATIVE	1	
-18	2807946	01	A17							. KEYSWITCHING ASSY, KEYBOARD	1	
-19	4912504	00								. SCREW, MACH, FLT HD, NO.6-32, 0.312 L6	3	
-20	2805269	02								. KEY PLUNGER RETURN	74	
-21	2805235	00								. BUSHING, PLUNGER	75	
-22	2805026	00								. PLUNGER, KEYSWITCH, MOLDED	74	
-23	2805458	12								. KEYCAP KIT		
-24	2805253	00								(SEE FIG 5 FOR DETAIL BREAKDOWN)	1	
-25	4913003	02								. SPACE BAR ASSY, KEYBOARD	1	
-26	2805271	00								. PIN, SPRING, CRES, 3/32 DIA	2	
-27	2805266	00								. PLUNGER, SWITCH, SPACE BAR	1	
-28	2805245	00								. SPRING, SPACE BAR	1	
-29	2807788	00								. GUIDE, SWITCH, SPACE BAR	2	
-30	2805269	01								. COMPRESSION SPRING	1	
-31	907451	05								. KEY PLUNGER RETURN	1	
-32	2807818	00								. NUT, PUSH-ON	3	
-33	2805235	01								. BUTTON, PLUG, RECTANGLE	3	
	2805243	12								. BUSHING, PLUNGER	2	
										. PLACEMENT CHART, KEYCAPS	NP	
4-	2805251	13								KEYBOARD ASSY, PECULIAR ITEMS (UPPERCASE KEYBOARD PLUS NUMERIC PAD - CONSISTS OF 2805251-10 PLUS 2805251-11) SPECIAL FUNCTION KEYS - SET A	REF	
-17	2805202	03								. PANEL, KEYBOARD, DECORATIVE	1	
-18	2807946	01	A17							. KEYSWITCHING ASSY, KEYBOARD	1	
-19	4912504	00								. SCREW, MACH, FLT HD, NO.6-32, 0.312 L6	3	
-20	2805269	02								. KEY PLUNGER RETURN	90	
-21	2805235	00								. BUSHING, PLUNGER	91	
-22	2805026	00								. PLUNGER, KEYSWITCH, MOLDED	90	
-23	2805458	13								. KEYCAP KIT		
-24	2805253	00								(SEE FIG 5 FOR DETAIL BREAKDOWN)	1	
-25	4913003	02								. SPACE BAR ASSY	1	
-26	2805271	00								. PIN, SPRING, CRES, 3/32 DIA	2	
-27	2805266	00								. PLUNGER, SWITCH, SPACE BAR	1	
-28	2805245	00								. SPRING, SPACE BAR	1	
-29	2807788	00								. GUIDE, SWITCH, SPACE BAR	2	
-30	2805269	01								. COMPRESSION SPRING	1	
-31	2805235	01								. KEY PLUNGER RETURN	1	
-33	2805243	13								. BUSHING, PLUNGER	2	
										. PLACEMENT CHART, KEYCAPS	NP	
4-	2805251	14								KEYBOARD ASSY, PECULIAR ITEMS (UPPERCASE/LOWERCASE KEYBOARD PLUS NUMERIC PAD - CONSISTS OF 2805251-10 + 2805251-12) SPECIAL FUNCTION KEYS - SET A	REF	
-17	2805202	03								. PANEL, KEYBOARD, DECORATIVE	1	
-18	2807946	01	A17							. KEYSWITCHING ASSY, KEYBOARD	1	
-19	4912504	00								. SCREW, MACH, FLT HD, NO.6-32, 0.312 L6	3	
-20	2805269	02								. KEY PLUNGER RETURN	90	
-21	2805235	00								. BUSHING, PLUNGER	91	
-22	2805026	00								. PLUNGER, KEYSWITCH, MOLDED	90	
-23	2805458	14								. KEYCAP KIT		
										(SEE FIG 5 FOR DETAIL BREAKDOWN)	1	

UNISCOPE 100 DISPLAY TERMINAL
TYPE 3536-06

FIG & INDEX NO.	PART NUMBER	REF. DESIG.	DESCRIPTION							NO. PER ASSY	USED ON CODE	
			1	2	3	4	5	6	7			
4-24	2805253	00									1	
-25	4913003	02									2	
-26	2805271	00									1	
-27	2805266	00									1	
-28	2805245	00									2	
-29	2807788	00									1	
-30	2805269	01									1	
-33	2805235	01									2	
	2805243	14									NP	
4-	2805251	15										REF
-17	2805202	04									1	
-18	2807946	00	A17								1	
-19	4912504	00									3	
-20	2805269	02									78	
-21	2805235	00									78	
-22	2805026	00									78	
-23	2805458	15										
-24	2805253	00									1	
-25	4913003	02									2	
-26	2805271	00									1	
-27	2805266	00									1	
-28	2805245	00									2	
-29	2807788	00									1	
-30	2805269	01									1	
-33	2805235	01									2	
	2805243	15									NP	
4-	2805251	16										REF
-17	2805202	04									1	
-18	2807946	00	A17								1	
-19	4912504	00									3	
-20	2805269	02									78	
-21	2805235	00									78	
-22	2805026	00									78	
-23	2805458	16										
-24	2805253	00									1	
-25	4913003	02									2	
-26	2805271	00									1	
-27	2805266	00									1	
-28	2805245	00									2	
-29	2807788	00									1	
-30	2805269	01									1	
-33	2805235	01									2	
	2805243	16									NP	
4-	2805251	17										REF
-17	2805202	03									1	
-18	2807946	00	A17								1	
-19	4912504	00									3	
-20	2805269	02									90	
-21	2805235	00									91	
-22	2805026	00									90	
-23	2805458	17										
-24	2805253	00									1	
-25	4913003	02									2	
-26	2805271	00									1	
-27	2805266	00									1	

GROUP ASSEMBLY PARTS LIST

FIG & INDEX NO.	PART NUMBER	REF. DESIG.	DESCRIPTION							NO. PER ON ASSY CODE	USED ON ASSY CODE	
			1	2	3	4	5	6	7			
4-28	2805245	00									2	
-29	2807788	00									1	
-30	2805269	01									1	
-33	2805235	01									2	
	2805243	17									NP	
4-	2805251	18										REF
-17	2805202	03									1	
-18	2807946	00	A17								1	
-19	4912504	00										
											3	
-20	2805269	01									90	
-21	2805235	00									91	
-22	2805026	00									90	
-23	2805458	18										
											1	
-24	2805253	00									1	
-25	4913003	02									2	
-26	2805271	00									1	
-27	2805266	00									1	
-28	2805245	00									2	
-29	2807788	00									1	
-30	2805269	01									1	
-33	2805235	01									2	
	2805243	18									NP	
4-	2808036	XX										REF
-2	2805495	01									1	
-3	2807745	00									2	
-4	2899152	00									2	
-5	4912548	11									6	
-5A	4912550	01									8	
-7	4912524	04									8	
-8	2808051	00									1	
-10	2807694	00									2	
-12	4912524	06									1	
-13	4912551	01									3	
-14	2808050	00									8	
-15	2808049	00									8	
-16	4912796	01									3	
-17	2805202	03									1	
-18	2808040	00									1	
4-	2808037	XX										REF
-2	2805495	01									1	
-3	2807745	00									2	
-4	2899152	00									2	
-5	4912548	11									6	
-5A	4912550	01									8	
-7	4912524	04									8	
-8	2808051	00									1	
-10	2807694	00									2	
-12	4912524	06									1	
-13	4912551	01									3	
-14	2808050	00									8	
-15	2808049	00									8	
-16	4912796	01									3	
-17	2805202	04									1	
-18	2808040	02									1	

UNISCOPE 100 DISPLAY TERMINAL
TYPE 3536-06

FIG & INDEX NO.	PART NUMBER	REF. DESIG.	DESCRIPTION							NO. USED PER ON ASSY CODE
			1	2	3	4	5	6	7	
4-	2808038	XX	KEYBOARD ASSEMBLY, ALPHA (SEE FIG 1 FOR NEXT HIGHER ASSY)							REF
VARIATIONS ARE LISTED FOR KEYBOARDS 2808038-00 THRU 2808038-03										
-2	2805495	01	.	SUPPORT, KEYBOARD DIE CASTING						1
-3	2807745	00	.	THUMSCREW, SLOTTED, KNURLED HEAD						2
-4	2899152	00	.	NUT, SHEET SPRING, PUSH-ON						2
-5	4912548	11	.	WASHER, FLAT						6
-5A	4912550	01	.	WASHER, LOCK (SPRING) HELICAL						8
-7	4912524	04	.	SCREW, PAN HEAD, SLOTTED 6-32 X 0.50						8
-8	2808051	00	.	COVER, PROTECTIVE						1
-10	2807694	00	.	SPRING CLIP						2
-12	4912524	06	.	SCREW, PAN HEAD, SLTD. 6-32 X 0.750						1
-13	4912551	01	.	WASHER, LOCK, EXT TOOTH, PH BRZ						3
-14	2808050	00	.	STAND OFF, THREADED - NO. 6-32						8
-15	2808049	00	.	SPACER						8
-16	4912796	01	.	NUT, SELF LKG, HEX 6-32						3
-17	2805202	04	.	PANEL, DECORATIVE						1
-18	2808040	03	.	SWITCH ASSY - KEYBOARD, ALPHA						1
-31	907451	05	.	NUT, PUSH-ON						3
-32	2807818	00	.	BUTTON, PLUG-RECTANGLE						3
4-	2808039	XX	KEYBOARD ASSEMBLY, NUMERIC (SEE FIG 1 FOR NEXT HIGHER ASSY)							REF
VARIATIONS ARE LISTED FOR KEYBOARDS 2808039-00 AND 2808039-01										
-2	2805495	01	.	SUPPORT, KEYBOARD DIE CASTING						1
-3	2807745	00	.	THUMSCREW, SLOTTED, KNURLED HEAD						2
-4	2899152	00	.	NUT, SHEET SPRING, PUSH-ON						2
-5	4912548	11	.	WASHER, FLAT						6
-5A	4912550	01	.	WASHER, LOCK (SPRING) HELICAL						8
-7	4912524	04	.	SCREW, PAN HEAD, SLOTTED 6-32 X 0.50						8
-8	2808051	00	.	COVER, PROTECTIVE						1
-10	2807694	00	.	SPRING CLIP						2
-12	4912524	06	.	SCREW, PAN HEAD, SLTD. 6-32 X 0.750						1
-13	4912551	01	.	WASHER, LOCK, EXT TOOTH, PH BRZ						3
-14	2808050	00	.	STAND OFF, THREADED - NO. 6-32						8
-15	2808049	00	.	SPACER						8
-16	4912796	01	.	NUT, SELF LKG, HEX 6-32						3
-17	2805202	01	.	PANEL, DECORATIVE						1
-18	2808040	01	.	SWITCH ASSY - KEYBOARD, NUMERIC						1

This space reserved for notes.

GROUP ASSEMBLY PARTS LIST




Figure 4. Keyboard, Uniscope 100

UNISCOPE 100 DISPLAY TERMINAL
TYPE 3536-06

FIG. & INDEX NO.	PART NUMBER	REF. DESIG.	DESCRIPTION	NO. USED PER ASSEMBLY
3-	NO NUMBER		KEYCAP DESCRIPTIONS - UNISCOPE 100	NP
-1	4143622 00		* KEYCAP, SQUARE	1
-2	4112775 01		* KEYCAP, SQUARE	1
-3	4112775 02		* KEYCAP, SQUARE	1
-4	4112775 03		* KEYCAP, SQUARE	1
-5	4112775 04		* KEYCAP, SQUARE	1
-6	4112775 05		* KEYCAP, SQUARE	1
-7	4112775 06		* KEYCAP, SQUARE	1
-8	4112775 07		* KEYCAP, SQUARE	1
-9	4112775 08		* KEYCAP, SQUARE	1
-10	4112775 09		* KEYCAP, SQUARE	1
-11	4112775 10		* KEYCAP, SQUARE	1
-12	4112775 11		* KEYCAP, SQUARE	1
-13	4112775 12		* KEYCAP, SQUARE	1
-14	4112775 13		* KEYCAP, SQUARE	1
-15	4112775 14		* KEYCAP, SQUARE	1
-16	4112775 15		* KEYCAP, SQUARE	1
-17	4112775 16		* KEYCAP, SQUARE	1
-18	4112775 17		* KEYCAP, SQUARE	1
-19	4112775 18		* KEYCAP, SQUARE	1
-20	4112775 19		* KEYCAP, SQUARE	1
-21	4112775 20		* KEYCAP, SQUARE	1
-22	4112775 21		* KEYCAP, SQUARE	1
-23	4112775 22		* KEYCAP, SQUARE	1
-24	4112775 23		* KEYCAP, SQUARE	1
-25	4112775 24		* KEYCAP, SQUARE	1
-26	4112775 25		* KEYCAP, SQUARE	1
-27	4112775 26		* KEYCAP, SQUARE	1
-28	4112775 27		* KEYCAP, SQUARE	1
-29	4112775 28		* KEYCAP, SQUARE	1
-30	4112775 29		* KEYCAP, SQUARE	1
-31	4112775 30		* KEYCAP, SQUARE	1
-32	4112775 31		* KEYCAP, SQUARE	1
-33	4112775 32		* KEYCAP, SQUARE	1
-34	4112775 33		* KEYCAP, SQUARE	1
-35	4112775 34		* KEYCAP, SQUARE	1
-36	4112775 35		* KEYCAP, SQUARE	1
-37	4112775 36		* KEYCAP, SQUARE	1
-38	4112775 37		* KEYCAP, SQUARE	1
-39	4112775 38		* KEYCAP, SQUARE	1
-39	4112775 39		* KEYCAP, SQUARE	1
-41	4112775 40		* KEYCAP, SQUARE	1
-42	4112775 41		* KEYCAP, SQUARE	1
-43	4112775 42		* KEYCAP, SQUARE	1
-44	4112775 43		* KEYCAP, SQUARE	1
-45	4112775 44		* KEYCAP, SQUARE	1
-46	4112775 45		* KEYCAP, SQUARE	1
-47	4112775 46		* KEYCAP, SQUARE	1
-48	4112775 47		* KEYCAP, SQUARE	1
-49	4112775 48		* KEYCAP, SQUARE	1
-50	4112775 49		* KEYCAP, SQUARE	1
-51	4112775 50		* KEYCAP, SQUARE	1
-52	4112775 51		* KEYCAP, SQUARE	1
-53	4112775 52		* KEYCAP, SQUARE	1
-54	4112775 53		* KEYCAP, SQUARE	1
-55	4112775 54		* KEYCAP, SQUARE	1
-56	4112775 55		* KEYCAP, SQUARE	1
-57	4112775 56		* KEYCAP, SQUARE	1
-58	4112775 57		* KEYCAP, SQUARE	1
-59	4112775 58		* KEYCAP, SQUARE	1
-60	4112775 59		* KEYCAP, SQUARE	1
-61	4112775 60		* KEYCAP, SQUARE	1
-62	4112775 61		* KEYCAP, SQUARE	1
-63	4112775 62		* KEYCAP, SQUARE	1
-64	4112775 63		* KEYCAP, SQUARE	1
-65	4112775 64		* KEYCAP, SQUARE	1
-66	4112775 65		* KEYCAP, SQUARE	1
-67	4112775 66		* KEYCAP, SQUARE	1
-68	4112775 67		* KEYCAP, SQUARE	1
-69	4112775 68		* KEYCAP, SQUARE	1
-70	4112775 69		* KEYCAP, SQUARE	1

GROUP ASSEMBLY PARTS LIST

FIG & INDEX NO.	PART NUMBER 987654321AANN	REF. DESIG.								DESCRIPTION	NO. USED PER ASSY ON CODE
			1	2	3	4	5	6	7		
5-71	4112775	70	KEYCAP, SQUARE	1
-72	4112775	71	KEYCAP, SQUARE	1
-73	4112775	72	KEYCAP, SQUARE	1
-74	4112775	73	KEYCAP, SQUARE	1
-75	4112775	74	KEYCAP, SQUARE	1
-76	4112775	75	KEYCAP, SQUARE	1
-77	4112775	76	KEYCAP, SQUARE	1
-78	4112775	77	KEYCAP, SQUARE	1
-79	4112775	78	KEYCAP, SQUARE	1
-80	4112775	79	KEYCAP, SQUARE	1
-81	4112775	80	KEYCAP, SQUARE	1
-82	4112775	81	KEYCAP, SQUARE	1
-84	4112775	83	KEYCAP, SQUARE	1
-85	4112775	84	KEYCAP, SQUARE	1
-86	4112775	85	KEYCAP, SQUARE	1
-87	4112775	86	KEYCAP, SQUARE	1
-88	4112775	87	KEYCAP, SQUARE	1
-89	4112775	88	KEYCAP, SQUARE	1
-90	4112775	89	KEYCAP, SQUARE	1
-91	4112775	90	KEYCAP, SQUARE	1
-92	4112775	91	KEYCAP, SQUARE	1
-93	4112775	92	KEYCAP, SQUARE	1
-94	4112775	93	KEYCAP, SQUARE	1
-95	4112775	94	KEYCAP, SQUARE	1
-96	4112775	95	KEYCAP, SQUARE	1
-97	4112775	96	KEYCAP, SQUARE	1
-98	4112775	97	KEYCAP, SQUARE	1
-99	4112775	98	KEYCAP, SQUARE	1
-100	4112775	99	KEYCAP, SQUARE	1
-101	4143622	01	KEYCAP, SQUARE	1
-102	4112776	01	KEYCAP, RECTANGLE	1
-103	4112776	02	KEYCAP, RECTANGLE	1
-104	4112776	03	KEYCAP, RECTANGLE	1
-105	4112776	04	KEYCAP, RECTANGLE	1
-106	4112776	05	KEYCAP, RECTANGLE	1
-107	4112776	06	KEYCAP, RECTANGLE	1
-108	4112776	07	KEYCAP, RECTANGLE	1
-109	4112776	08	KEYCAP, RECTANGLE	1
-110	4112776	09	KEYCAP, RECTANGLE	1
-111	4112776	10	KEYCAP, RECTANGLE	1
-112	4112776	11	KEYCAP, RECTANGLE	1
-113	4112776	12	KEYCAP, RECTANGLE	1
-114	4112776	13	KEYCAP, RECTANGLE	1
-115	4112776	14	KEYCAP, RECTANGLE	1
-116	4112776	15	KEYCAP, RECTANGLE	1
-117	4112776	16	KEYCAP, RECTANGLE	1
-118	4112776	17	KEYCAP, RECTANGLE	1
-119	4112776	18	KEYCAP, RECTANGLE	1
-120	4112776	19	KEYCAP, RECTANGLE	1
-121	4112776	20	KEYCAP, RECTANGLE	1
-122	4112776	21	KEYCAP, RECTANGLE	1
-123	4112776	22	KEYCAP, RECTANGLE	1
-124	4112776	23	KEYCAP, RECTANGLE	1
-125	4112776	24	KEYCAP, RECTANGLE	1
-126	4112776	25	KEYCAP, RECTANGLE	1
-127	4112776	26	KEYCAP, RECTANGLE	1
-128	4112776	27	KEYCAP, RECTANGLE	1
-129	4112776	28	KEYCAP, RECTANGLE	1
-130	4112776	29	KEYCAP, RECTANGLE	1
-131	4112776	30	KEYCAP, RECTANGLE	1
-132	4112776	31	KEYCAP, RECTANGLE	1
-133	4112776	32	KEYCAP, RECTANGLE	1
-134	4112776	33	KEYCAP, RECTANGLE	1
-135	4112776	34	KEYCAP, RECTANGLE	1
-136	4112776	35	KEYCAP, RECTANGLE	1
-137	4112776	36	KEYCAP, RECTANGLE	1
-138	4112776	37	KEYCAP, RECTANGLE	1
-139	4112776	38	KEYCAP, RECTANGLE	1
-140	4112776	39	KEYCAP, RECTANGLE	1
-141	4112776	40	KEYCAP, RECTANGLE	1

UNISCOPE 100 DISPLAY TERMINAL
TYPE 353e-06

FIG & INDEX NO.	PART NUMBER 987654321AANN	REF. DESIG.	1	2	3	4	5	6	7	DESCRIPTION	NO. USED PER ON ASSY CODE
5-142	4112776	41	KEYCAP, RECTANGLE	1
-143	4112776	42	KEYCAP, RECTANGLE	1
-144	4112780	00	KEYCAP	1
-145	4143622	02	KEYCAP, SQUARE	1
-146	4112777	01	KEYCAP, RECTANGLE	1
-147	4112777	02	KEYCAP, RECTANGLE	1
-148	4112777	03	KEYCAP, RECTANGLE	1
-149	4112777	04	KEYCAP, RECTANGLE	1
-150	4112777	05	KEYCAP, RECTANGLE	1
-151	4112777	06	KEYCAP, RECTANGLE	1
-152	4112777	07	KEYCAP, RECTANGLE	1
-153	4112777	08	KEYCAP, RECTANGLE	1
-154	4112777	09	KEYCAP, RECTANGLE	1
-155	4112777	10	KEYCAP, RECTANGLE	1
-156	4112777	11	KEYCAP, RECTANGLE	1
-157	4112777	12	KEYCAP, RECTANGLE	1
-158	4112777	13	KEYCAP, RECTANGLE	1
-159	4112777	14	KEYCAP, RECTANGLE	1
-160	4112777	15	KEYCAP, RECTANGLE	1
-161	4112777	16	KEYCAP, RECTANGLE	1
-162	4112777	17	KEYCAP, RECTANGLE	1
-163	4112777	18	KEYCAP, RECTANGLE	1
-164	4112777	19	KEYCAP, RECTANGLE	1
-165	4112777	20	KEYCAP, RECTANGLE	1
-166	4112777	21	KEYCAP, RECTANGLE	1
-167	4112777	22	KEYCAP, RECTANGLE	1
-168	4112777	23	KEYCAP, RECTANGLE	1
-169	4112777	24	KEYCAP, RECTANGLE	1
-170	4112777	25	KEYCAP, RECTANGLE	1
-171	4112777	26	KEYCAP, RECTANGLE	1
-172	4112777	27	KEYCAP, RECTANGLE	1
-174	4112777	29	KEYCAP, RECTANGLE	1
-175	4112777	30	KEYCAP, RECTANGLE	1
-176	4112777	31	KEYCAP, RECTANGLE	1
-177	4112777	32	KEYCAP, RECTANGLE	1
-178	4112777	33	KEYCAP, RECTANGLE	1
-179	4112777	34	KEYCAP, RECTANGLE	1
-180	4112777	35	KEYCAP, RECTANGLE	1
-181	4112777	36	KEYCAP, RECTANGLE	1
-182	4112777	37	KEYCAP, RECTANGLE	1
-183	4112777	38	KEYCAP, RECTANGLE	1
-184	4112777	39	KEYCAP, RECTANGLE	1
-185	4112777	40	KEYCAP, RECTANGLE	1
-186	4112777	41	KEYCAP, RECTANGLE	1
-187	4112777	42	KEYCAP, RECTANGLE	1
-188	4112777	43	KEYCAP, RECTANGLE	1
-189	4112777	44	KEYCAP, RECTANGLE	1
-190	4112777	45	KEYCAP, RECTANGLE	1
-191	4112777	46	KEYCAP, RECTANGLE	1
-192	4112777	47	KEYCAP, RECTANGLE	1
-193	4112777	48	KEYCAP, RECTANGLE	1
-194	4112777	49	KEYCAP, RECTANGLE	1
-195	4112777	50	KEYCAP, RECTANGLE	1
-196	4112777	51	KEYCAP, RECTANGLE	1
-197	4112777	52	KEYCAP, RECTANGLE	1
-198	4112777	53	KEYCAP, RECTANGLE	1
-199	4112777	54	KEYCAP, RECTANGLE	1
-200	4112777	55	KEYCAP, RECTANGLE	1
-201	4112777	56	KEYCAP, RECTANGLE	1
-202	4112777	57	KEYCAP, RECTANGLE	1
-203	4112777	58	KEYCAP, RECTANGLE	1
-204	4112777	59	KEYCAP, RECTANGLE	1
-205	4112777	60	KEYCAP, RECTANGLE	1
-206	4112777	61	KEYCAP, RECTANGLE	1
-207	4112777	62	KEYCAP, RECTANGLE	1
-208	4112777	63	KEYCAP, RECTANGLE	1
-209	4112777	64	KEYCAP, RECTANGLE	1
-210	4112777	65	KEYCAP, RECTANGLE	1
-211	4112797	00	KEYCAP, RECTANGLE	1
-212	4112797	01	KEYCAP, RECTANGLE	1

This space reserved for notes.

INDEX NO	CHAR	INDEX NO	CHAR	INDEX NO	CHAR	INDEX NO	CHAR	INDEX NO	CHAR	INDEX NO	CHAR
1	\	17	P	33	β	49	Ⓞ	65	\	81	7
2	A	18	Q	34		50	†	66	≠	82	8
3	B	19	R	35		51	⌒	67	δ	83	9
4	C	20	S	36	#	52	<	68	BS	84	}
5	D	21	T	37	\$	53	†	69	CR	85	=
6	E	22	U	38	%	54	>	70	SPEC	86	?
7	F	23	V	39	B	55	€	71	□	87	!
8	G	24	W	40	7	56	Π	72	%	88	-
9	H	25	X	41	(57	@	73	~	89]]
10	I	26	Y	42)	58	LOCK	74	⌒	90	[[
11	J	27	Z	43	?	59	BEL	75	1	91	6
12	K	28	.	44	=	60	VT	76	2	92	
13	L	29	,	45	->	61	FF	77	3	93	⌒
14	M	30	:	46	*	62	EM	78	4	94	⌒
15	N	31	:	47	LF	63	HT	79	5	95	⌒
16	O	32	*	48	0	64	[80	6	96]]

INDEX NO	CHAR	INDEX NO	CHAR	INDEX NO	CHAR	INDEX NO	CHAR	INDEX NO	CHAR	INDEX NO	CHAR	INDEX NO	CHAR	INDEX NO	CHAR
97	{	112	MESSAGE WAITING	132	CYCLE	152	≡	172	≡	192	≡	212	TRANSMIT UNPROT DISPL		
98	-	113	TRANSMIT	133	SHIFT LOCK	153	λ	173	λ	193	*	211	TRANSMIT		
99	∧	114	TAB	134	SELECT	154	□	174	□	194	□	210	•		
100	@	115	←	135	OUTPUT	155	□	175	≠	195	≠	209	0		
101	∧	116	CHAR ERASE	136	INPUT	156	1/2	176	≤	196	≤	208	9		
102	ERASE TO END OF DISPL	117	EOM S	137	READ	157	2/1	177	≥	197	≥	207	8		
103	ERASE TO END OF LINE	118	DUP	138	PUNCH	158	3/1	178	≠	198	≠	206	7		
104	IN DISPL DELETE IN LINE	119	CLEAR	139	SOE	159	4/1	179	≠	199	≠	205	6		
105	IN DISPL INSERT IN LINE	120	RELEASE	140	F1	160	5/1	180	√	200	√	204	5		
106	CURSOR TO HOME	121	CONTROL	141	F2	161	6/1	181	φ	201	φ	203	4		
107	SOM	122	SHIFT	142	F3	162	7/1	182	√	202	√	202	3		
108	↑	123	Ⓞ	143	F4	163	8/1	183	≠	203	≠	201	2		
109	□	124	DELETE IN LINE	144	RETURN	164	9/1	184	□	204	□	200	1		
110	⌒	125	INSERT IN LINE	145	CHAR ERASE	165	+	185	—	205	—	200	1		
111	⋮	126	RETURN	146	RETURN	166	○/□	186	∧	206	∧	200	1		
		127	⌒	147	↵	167	↳	187	↳	207	↳	200	1		
		128	[148	√	168	⊗	188	⊗	208	⊗	200	1		
		129	□	149	◇	169	φ	189	φ	209	φ	200	1		
		130	PRINT	150	Σ	170	÷	190	÷	210	÷	200	1		
		131	TAB SET	151	↵	171	↳	191	↳	211	↳	200	1		

TT112

Figure 5. Keycaps

UNISCOPE 100 DISPLAY TERMINAL
TYPE 3536-06

FIG # INDEX NO.	PART NUMBER	REF. DESIG.	1	2	3	4	5	6	7	DESCRIPTION	NO. USED PER ON ASSY CODE
6-	2807476 00	#3								CABLE ASSEMBLY, INTERNAL MODEM (SEE FIG 2 FOR NEXT HIGHER ASSY)	REF 1
-1	2899147 00	A14P10								INS. ELEC CONN. 20 CONTACTS, FEMALE	20
-2	2899148 00									CONTACT, ELECTRICAL PLUG 20-24AWG	1
-3	4915136 00	A15-J01								CONN ELEC REC. MALE 25 CONTACTS	1
-4	2899514 00									CONTACT, ELECTRICAL CONNECTOR MALE	20





Figure 6. Cable Assembly, Internal Modem

FIG # INDEX NO.	PART NUMBER	REF. DESIG.	1	2	3	4	5	6	7	DESCRIPTION	NO. USED PER ON ASSY CODE
7-	2807955 01	#1								WIRING HARNESS ASSEMBLY (SEE FIG 2 FOR NEXT HIGHER ASSY)	REF 1
-1	2899161 00	VIPI								SOCKET, 14 PIN CRT	1
-2	2899267 00	A3P1 ADP1								CONNECTOR, 50 HOLES FEMALE	2
-3	3004893 02									CONTACT, PL & RECPT. 18AWG, 5 AMP	12
-4	3004893 03									CONTACT, PL & RECPT. 26-22AWG, 5A	71
-5	2899420 00									SPLICE, CONDUCTOR	1
-6	2899394 01									TERMINAL, TAPER TAB, RECEPTACLE	4
-7	2899316 00									LENS, INDICATOR LIGHT - PLUNGER TYPE	1
-8	2899317 00									LAMP, INCANDESCENT 28V, 0.06A	1
-9	2899315 01	S03								SWITCH, PUSH, ILLUM. SPDT TAPER TAB	1
-10	2899072 01	R01								RESISTOR, VAR, 1500 OHMS 20K 1/2W	1
-11	2899104 00	U502								LIGHT, IND. REPL LAMP, 28V, 1.30 CP	1
-12	2899074 01	R02 R04								RESISTOR, VAR, 1M 20K 2W LIN. COMP.	2
-13	910634 11	C01								CAP. 0.047UF 10K 600V PAPER	1
-14	911456 00	W1E2								TERMINAL LUG, SOLDER	1
-15	2899074 02	R05								RESISTOR, VAR, 10K 20K 2W LIN. COMP.	1
-16	2899073 00	R03								RESISTOR, VAR, 5K 20K 0.5W LIN. COMP.	1
-17	4914193 35	C02								CAP. 50KPF 20K 100V CERAMIC	1
-18	2899146 00	A14P8								INS. ELEC CONN 40 HOLES FEMALE	2
-19	2899148 00	A14P9								CONTACT FEMALE 20-24AWG GOLD PL	57
-20	2805512 00	A14P12								INSULATOR, CONNECTOR	1
-21	2899280 00									CONTACT FEMALE 0.000030 PLATE	11
-22	3006413 00									TERM. TAB RECEPTACLE 0.032X0.250 TAB	2
-23	2899456 00	A2J1								CONNECTOR, FEMALE 24 CONTACT POS	1
-24	2899448 00									CONTACT, ELECTRICAL - FEMALE	23
-25	906495 02									TERMINAL, QUICK DISCONNECT	4
-26	906495 04									TERMINAL, QUICK DISCONNECT	4
-27	2899068 00									TERM. 0 DISC. FEMALE, 0.187	18



TT100

Figure 7. Wiring Harness Assembly

GROUP ASSEMBLY PARTS LIST

FIG & INDEX NO.	PART NUMBER	REF. DESIG.	1	2	3	4	5	6	7	DESCRIPTION	NO. USED PER ON ASSY CODE
9-	2807982	00 W5								KEYBOARD CABLE ASSEMBLY (SEE FIG 1 FOR NEXT HIGHER ASSY)	REF
-1	2899093	00 A17P1								. INS CONN FEMALE, 20 CONTACT	1
-2	2899081	00								. . CONTACT, PRINTED CIRCUIT BOARD, MINIATURE LEAF TYPE	32
-3	2899090	00 A17P2								. INS CONN FEMALE, 16 CONTACT	1
-4	3007553	02 A3P2								. INSULATOR, CONNECTOR 36 POSITIONS	1
-5	3004893	03								. . CONTACT, PL & RECPT. 26-22AWG, 5A	32




Figure 9. Keyboard Cable Assembly

FIG & INDEX NO.	PART NUMBER	REF. DESIG.	1	2	3	4	5	6	7	DESCRIPTION	NO. USED PER ON ASSY CODE
10-	2805285	00 W4								CABLE ASSEMBLY, AUX I/F, INTERNAL (SEE FIG 1 FOR NEXT HIGHER ASSY)	REF
-1	2899323	00 P1								. CONNECTOR, PLUG - L 50 PIN	1
-2	2899322	00								. . TERMINAL PIN RECPT. FEMALE, 22-26AWG, CRIMP TYPE	40
-3	2899321	00 J2								. CONNECTOR, FEMALE, 50 CONTACT	1
-4	2899513	00								. . CONTACT, ELECT CONNECTOR - FEMALE	40




Figure 10. Cable Assembly, Aux I/F, Internal

UNISCOPE 100 DISPLAY TERMINAL
TYPE 3536-06

FIG & INDEX NO.	PART NUMBER	REF. DESIG.	1	2	3	4	5	6	7	DESCRIPTION	NO. USED PER ON ASSY	CODE
11-	7099615	00								CABLE ASSEMBLY, PARALLEL I/F (3760) (SEE FIG 1 FOR NEXT HIGHER ASSY)	REF	
-1	7904243	00								. CONNECTOR PLUG, FEMALE, 52 CONTACT	1	
-2	904656	00								. . HARDWARE SET, ELECT CONNECTOR	2	
-3	7904207	00								. ADAPTOR, CABLE TO CONNECTOR	1	
-4	7904204	00								. CONNECTOR PLUG, FEMALE, 44 CONTACT	1	
-5	7904209	01								. ADAPTOR, CABLE TO CONNECTOR	1	




Figure 11. Cable Assembly, Parallel I/F (3760)

SECTION 3
REFERENCE DESIGNATION INDEX

REF DESIG	FIG & INDEX NO.	REF DESIG	FIG & INDEX NO.	REF DESIG	FIG & INDEX NO.	REF DESIG	FIG & INDEX NO.
A2.....	2-29	A15J1....	6-3	C3.....	3-3	S3.....	7-9
A2.....	3-75	A16L1....	2-43	C4.....	3-5	T1.....	3-25
A3.....	1-15	A16L2....	2-41	CB1.....	2-15	T2.....	3-28
A5.....	1-14	A17P1....	9-1	CR1.....	3-17	V1.....	2-20
A7.....	1-7	A17P2....	9-3	CR2.....	3-16	V1P1....	7-1
A8.....	1-8	A2J1.....	7-23	CR3B,CR4.	3-31	W1.....	2-40
A9.....	1-9	A2J1.....	8-5	DS1.....	2-31	W1.....	7-4
A10.....	1-10	A2P1.....	8-7	DS2.....	7-11	W3.....	2-38
A11.....	1-11	A2W1.....	3-27	DS03,DS4.	2-19	W3.....	6-212
A12.....	1-12	A2W1.....	8-27	J2.....	10-3	W4.....	1-17
A13.....	1-13	A3P2.....	9-4	P1.....	10-1	W4.....	10-5
A14.....	2-53	A3P1,ASP1	7-2	PS1.....	3-11	W5.....	1-16
A17.....	4-18	B1.....	2-61	R1.....	7-10	W5.....	9-9
A14PB....	7-18	C1.....	3-6	R3.....	7-16	W1E2....	7-14
A14P9....	7-18	C1.....	7-13	R5.....	7-15		
A14P10...	6-1	C2.....	3-4	R02,R4...	7-12		
A14P12...	7-20	C2.....	7-17	S1.....	2-10		

SECTION 4

NUMERICAL INDEX

PART NUMBER	FIG & INDEX NO.	PART NUMBER	FIG & INDEX NO.	PART NUMBER	FIG & INDEX NO.
904656	00 11-2	2805253	00 4-24	2807490	02 1-2
905818	03 3-8	2805253	00 4-24	2807490	03 1-2
906495	02 7-25	2805253	00 4-24	2807490	04 1-2
906495	04 7-26	2805253	00 4-24	2807637	01 2-35
906495	04 8-9	2805256	00 4-8	2807648	00 2-13
907451	05 4-31	2805264	00 4-1	2807694	00 4-10
907451	05 4-31	2805266	00 4-27	2807694	00 4-10
910834	11 7-13	2805266	00 4-27	2807694	00 4-10
911458	00 7-14	2805266	00 4-27	2807707	00 2-46
911651	03 2-33	2805266	00 4-27	2807738	01 2-1
911651	03 2-67	2805266	00 4-27	2807745	00 4-3
911651	03 2-72	2805266	00 4-27	2807745	00 4-3
2805022	05 4-15	2805268	05 4-14	2807745	00 4-3
2805026	00 4-22	2805269	01 4-20	2807745	00 4-3
2805026	00 4-22	2805269	01 4-30	2807759	01 2-2
2805026	00 4-22	2805269	01 4-30	2807764	00 3-1
2805026	00 4-22	2805269	01 4-30	2807772	00 2-71
2805202	01 4-17	2805269	01 4-30	2807775	00 1-4
2805202	01 4-17	2805269	01 4-30	2807775	01 1-4
2805202	03 4-17	2805269	01 4-30	2807775	02 1-4
2805202	03 4-17	2805269	02 4-20	2807775	03 1-4
2805202	04 4-17	2805269	02 4-20	2807775	04 1-4
2805202	04 4-17	2805269	02 4-20	2807786	02 1-8
2805202	04 4-17	2805269	02 4-20	2807786	00 4-29
2805202	04 4-17	2805269	02 4-20	2807786	00 4-29
2805202	04 4-17	2805271	00 4-26	2807786	00 4-29
2805204	00 4-9	2805271	00 4-26	2807797	00 2-58
2805235	00 4-21	2805271	00 4-26	2807798	00 2-59
2805235	00 4-21	2805285	00 1-17	2807802	00 2-63
2805235	00 4-21	2805285	00 10-5	2807803	00 2-47
2805235	00 4-21	2805290	05 1-7	2807803	01 2-48
2805235	01 4-33	2805338	09 1-10	2807816	02 1-8
2805235	01 4-33	2805352	07 1-10	2807818	00 4-32
2805235	01 4-33	2805456	10 4-23	2807850	00 2-39
2805235	01 4-33	2805458	11 4-23	2807918	03 1-7
2805235	01 4-33	2805458	12 4-23	2807934	02 1-15
2805243	10 4-23	2805458	13 4-23	2807939	00 3-24
2805243	11 4-33	2805458	14 4-23	2807946	00 4-18
2805243	12 4-33	2805458	15 4-23	2807946	00 4-18
2805243	13 4-33	2805458	16 4-23	2807946	00 4-18
2805243	14 4-33	2805458	17 4-23	2807946	00 4-18
2805243	15 4-33	2805458	18 4-23	2807946	01 4-18
2805243	16 4-33	2805493	00 2-42	2807946	01 4-18
2805243	17 4-33	2805495	00 4-2	2807946	01 4-18
2805243	18 4-33	2805495	01 4-2	2807946	01 4-18
2805245	00 4-28	2805495	01 4-2	2807950	01 2-24
2805245	00 4-28	2805499	00 4-6	2807951	00 3-7
2805245	00 4-28	2805512	00 7-20	2807952	00 3-2
2805245	00 4-28	2807351	00 2-21	2807953	00 1-1
2805251	XX 1-5	2807366	00 2-44	2807953	00 2-18
2805251	XX 4-32	2807416	00 1-3	2807954	00 2-29
2805251	10 4-16	2807416	01 1-3	2807954	00 3-75
2805251	11 4-23	2807416	02 1-3	2807955	01 2-40
2805251	12 4-33	2807416	03 1-3	2807955	01 7-4
2805251	13 4-33	2807416	04 1-3	2807970	01 8-5
2805251	14 4-33	2807456	00 1-6	2807981	01 2-74
2805251	15 4-33	2807461	00 2-41	2807982	00 1-16
2805251	16 4-33	2807476	00 2-38	2807982	00 9-9
2805251	17 4-33	2807476	00 6-212	2807985	00 3-27
2805251	18 4-33	2807490	00 1-2	2807985	00 8-27
2805253	00 4-24	2807490	01 1-2	2807986	01 1-14

UNISCOPE 100 DISPLAY TERMINAL
TYPE 3536-06

PART NUMBER	FIG # INDEX NO.	PART NUMBER	FIG # INDEX NO.	PART NUMBER	FIG # INDEX NO.
2807992	01 1-14	2899161	00 7-1	4112775	35 5-36
2808006	00 2-32	2899262	00 3-11	4112775	36 5-37
2808009	00 2-66	2899267	00 7-2	4112775	37 5-38
2808010	00 3-18	2899274	00 3-17	4112775	38 5-39
2808012	00 2-53	2899280	00 7-21	4112775	39 5-39
2808019	00 2-5	2899305	00 2-43	4112775	40 5-41
2808036	XX 1-5	2899315	01 7-9	4112775	41 5-42
2808036	XX 4-33	2899316	00 2-12	4112775	42 5-43
2808037	XX 1-5	2899316	00 7-7	4112775	43 5-44
2808037	XX 4-18	2899317	00 7-6	4112775	44 5-45
2808038	XX 1-5	2899321	00 10-3	4112775	45 5-46
2808038	XX 4-18	2899322	00 10-2	4112775	46 5-47
2808039	XX 1-5	2899323	00 10-1	4112775	47 5-48
2808039	XX 4-32	2899377	00 2-27	4112775	48 5-49
2808040	00 4-18	2899380	03 2-25	4112775	49 5-50
2808040	01 4-18	2899381	01 2-61	4112775	50 5-51
2808040	02 4-18	2899394	01 7-6	4112775	51 5-52
2808040	03 4-18	2899395	00 2-65	4112775	52 5-53
2808041	00 2-69	2899418	01 2-36	4112775	53 5-54
2808049	00 4-15	2899420	00 7-5	4112775	54 5-55
2808049	00 4-15	2899445	00 8-4	4112775	55 5-56
2808049	00 4-15	2899448	00 7-24	4112775	56 5-57
2808050	00 4-14	2899449	00 8-8	4112775	57 5-58
2808050	00 4-14	2899456	00 7-23	4112775	58 5-59
2808050	00 4-14	2899457	00 8-7	4112775	59 5-60
2808050	00 4-14	2899464	00 2-15	4112775	60 5-61
2808051	00 4-8	2899467	00 3-25	4112775	61 5-62
2808051	00 4-8	2899509	00 2-14	4112775	62 5-63
2808052	00 1-9	2899513	00 10-4	4112775	63 5-64
2808053	00 1-9	2899514	00 6-4	4112775	64 5-65
2808054	00 1-11	3004893	02 7-3	4112775	65 5-66
2808055	00 1-12	3004893	03 7-4	4112775	66 5-67
2808056	00 1-11	3004893	03 9-5	4112775	67 5-68
2808057	00 1-12	3006413	00 7-22	4112775	68 5-69
2808058	00 1-13	3007287	00 2-30	4112775	69 5-70
2808059	00 1-11	3007553	02 9-4	4112775	70 5-71
2808060	00 1-12	3007700	02 2-75	4112775	71 5-72
2808061	00 1-11	3008589	00 3-14	4112775	72 5-73
2808062	00 1-12	3011173	09 3-15	4112775	73 5-74
2808063	00 1-12	3011815	00 2-37	4112775	74 5-75
2808079	00 2-4A	3156579	04 2-60	4112775	75 5-76
2899011	00 3-31	4112775	01 5-2	4112775	76 5-77
2899012	00 3-16	4112775	02 5-3	4112775	77 5-78
2899017	03 2-20	4112775	03 5-4	4112775	78 5-79
2899050	02 3-26	4112775	04 5-5	4112775	79 5-80
2899068	00 7-27	4112775	05 5-6	4112775	80 5-81
2899068	00 8-1	4112775	06 5-7	4112775	81 5-82
2899072	01 7-10	4112775	07 5-8	4112775	83 5-84
2899073	00 7-16	4112775	08 5-9	4112775	84 5-85
2899074	01 7-12	4112775	09 5-10	4112775	85 5-86
2899074	02 7-15	4112775	10 5-11	4112775	86 5-87
2899081	00 9-2	4112775	11 5-12	4112775	87 5-88
2899087	00 8-6	4112775	12 5-13	4112775	88 5-89
2899090	00 9-3	4112775	13 5-14	4112775	89 5-90
2899093	00 9-1	4112775	14 5-15	4112775	90 5-91
2899095	02 2-6	4112775	15 5-16	4112775	91 5-92
2899095	02 3-32	4112775	16 5-17	4112775	92 5-93
2899098	01 2-11	4112775	17 5-18	4112775	93 5-94
2899100	01 2-57	4112775	18 5-19	4112775	94 5-95
2899103	01 2-18	4112775	19 5-20	4112775	95 5-96
2899104	00 7-11	4112775	20 5-21	4112775	96 5-97
2899105	00 3-6	4112775	21 5-22	4112775	97 5-98
2899105	01 3-4	4112775	22 5-23	4112775	98 5-99
2899105	02 3-5	4112775	23 5-24	4112775	99 5-100
2899105	03 3-3	4112775	24 5-25	4112776	01 5-102
2899110	01 2-19	4112775	25 5-26	4112776	02 5-103
2899122	00 3-28	4112775	26 5-27	4112776	03 5-104
2899144	00 2-10	4112775	27 5-28	4112776	04 5-105
2899146	00 7-18	4112775	28 5-29	4112776	05 5-106
2899147	00 6-1	4112775	29 5-30	4112776	06 5-107
2899148	00 6-2	4112775	30 5-31	4112776	07 5-108
2899148	00 7-19	4112775	31 5-32	4112776	08 5-109
2899152	00 4-4	4112775	32 5-33	4112776	09 5-110
2899152	00 4-4	4112775	33 5-34	4112776	10 5-111
2899152	00 4-4	4112775	34 5-35	4112776	11 5-112

NUMERICAL INDEX

PART NUMBER	FIG & INDEX NO.	PART NUMBER	FIG & INDEX NO.	PART NUMBER	FIG & INDEX NO.
4112776	12 5-113	4112777	35 5-180	4912525	01 2-56
4112776	13 5-114	4112777	36 5-181	4912525	03 2-52
4112776	14 5-115	4112777	37 5-182	4912527	04 2-28
4112776	15 5-116	4112777	38 5-183	4912539	00 2-45
4112776	16 5-117	4112777	39 5-184	4912540	00 3-30
4112776	17 5-118	4112777	40 5-185	4912540	01 2-9
4112776	18 5-119	4112777	41 5-186	4912540	01 3-21
4112776	19 5-120	4112777	42 5-187	4912540	01 3-31
4112776	20 5-121	4112777	43 5-188	4912540	01 3-32
4112776	21 5-122	4112777	44 5-189	4912540	02 3-13
4112776	22 5-123	4112777	45 5-190	4912548	01 4-5
4112776	23 5-124	4112777	46 5-191	4912548	02 2-4
4112776	24 5-125	4112777	47 5-192	4912548	11 3-19
4112776	25 5-126	4112777	48 5-193	4912548	11 3-31
4112776	26 5-127	4112777	49 5-194	4912548	11 4-5
4112776	27 5-128	4112777	50 5-195	4912548	11 4-5
4112776	28 5-129	4112777	51 5-196	4912548	11 4-5
4112776	29 5-130	4112777	52 5-197	4912550	00 3-29
4112776	30 5-131	4112777	53 5-198	4912550	01 2-17
4112776	31 5-132	4112777	54 5-199	4912550	01 2-49
4112776	32 5-133	4112777	55 5-200	4912550	01 3-20
4112776	33 5-134	4112777	56 5-201	4912550	01 3-31
4112776	34 5-135	4112777	57 5-202	4912550	01 4-5A
4112776	35 5-136	4112777	58 5-203	4912550	01 4-5A
4112776	36 5-137	4112777	59 5-204	4912550	01 4-5A
4112776	37 5-138	4112777	60 5-205	4912550	02 2-51
4112776	38 5-139	4112777	61 5-206	4912550	02 2-55
4112776	39 5-140	4112777	62 5-207	4912551	01 2-8
4112776	40 5-141	4112777	63 5-208	4912551	01 3-32
4112776	41 5-142	4112777	64 5-209	4912551	01 4-13
4112776	42 5-143	4112777	65 5-210	4912551	01 4-13
4112777	01 5-146	4112780	00 5-144	4912551	01 4-13
4112777	02 5-147	4112797	00 5-211	4912551	01 4-13
4112777	03 5-148	4112797	01 5-212	4912551	02 2-54
4112777	04 5-149	4143622	00 5-1	4912551	02 3-12
4112777	05 5-150	4143622	01 5-101	4912551	02 4-13
4112777	06 5-151	4143622	02 5-145	4912551	03 2-26
4112777	07 5-152	4912504	00 4-19	4912796	01 4-16
4112777	08 5-153	4912504	00 4-19	4912796	01 4-16
4112777	09 5-154	4912504	00 4-19	4912796	01 4-16
4112777	10 5-155	4912504	00 4-19	4913003	02 4-25
4112777	11 5-156	4912524	00 2-23	4913003	02 4-25
4112777	12 5-157	4912524	00 3-9	4913003	02 4-25
4112777	13 5-158	4912524	01 2-7	4913003	02 4-25
4112777	14 5-159	4912524	01 2-34	4913556	03 2-3
4112777	15 5-160	4912524	01 2-73	4914061	00 4-12
4112777	16 5-161	4912524	01 3-32	4914193	35 7-17
4112777	17 5-162	4912524	02 2-68	4914485	04 2-31
4112777	18 5-163	4912524	02 3-10	4914901	07 8-2
4112777	19 5-164	4912524	04 2-64	4914901	08 8-3
4112777	20 5-165	4912524	04 3-31	4915136	00 6-3
4112777	21 5-166	4912524	04 4-7	4956341	16 2-22
4112777	22 5-167	4912524	04 4-7	4956810	05 2-70
4112777	23 5-168	4912524	04 4-7	7099615	00 1-18
4112777	24 5-169	4912524	06 4-12	7099615	00 11-4
4112777	25 5-170	4912524	06 4-12	7904204	00 11-4
4112777	26 5-171	4912524	06 4-12	7904207	00 11-3
4112777	27 5-172	4912524	06 4-12	7904209	01 11-5
4112777	29 5-174	4912524	07 2-16	7904243	00 11-1
4112777	30 5-175	4912524	07 2-50		
4112777	31 5-176	4912524	07 3-22	NO NUMBER	1-
4112777	32 5-177	4912524	12 3-22		
4112777	33 5-178	4912524	13 3-23		
4112777	34 5-179	4912524	14 2-62		

BOOK CHANGE REQUEST

BOOK NO. M _ _ _ _ _	HCB	TITLE
-------------------------	-----	-------

BE SURE TO COMPLETE ADDRESS ON OPPOSITE SIDE OF CARD. USE THE ADDRESS FOR THE APPROPRIATE PREFIX SHOWN BELOW:

1. TECHNICAL OPERATIONS:

MA _ _ _ _ 2276 HIGHCREST DRIVE, ROSEVILLE, MINN. 55113
 MH _ _ _ _ BOX 500 BLUE BELL, PA. 19422
 MI _ _ _ _ 311 TURNER ST., MD 12A UTICA, NEW YORK 13501
 MR _ _ _ _ 322 N. 21st ST. WEST, SALT LAKE CITY, UTAH 84116
 MT _ _ _ _ 1905 ROWLAND AVE., CINNAMINSON, N.J. 08077

2. WORLDWIDE DISTRIBUTION CENTER:

ML _ _ _ _ 2121 LANDMEIR RD., ELK GROVE VILLAGE, ILL. 60007

DESCRIBE CHANGE OR PROBLEM. IDENTIFY PARAGRAPH AND PAGE NUMBERS.

LOCATION ISSUING REQUEST

LOCATION	DEPARTMENT	DATE / /
NAME		TELEPHONE NO.

REQUESTING ORGANIZATION — DO NOT WRITE BELOW THIS LINE.

FINAL DISPOSITION

EVALUATED BY	<input type="checkbox"/> APPROVED <input type="checkbox"/> REJECTED	DATE	BCR NO.
--------------	--	------	---------

FROM:

PLACE
FIRST
CLASS
STAMP
HERE

TO:

SPEERRY UNIVAC