M I C R O C H E S S

KIM Cassette Loading Instructions

1 Enter (RS) to reset KIM.
2 Enter (AD) 0 0 F 1 (DA) 0 0 to reset decimal flag
3 Enter (AD) 1 7 F 9 (DA) C 1 to enter tape ID.
4 Enter (AD) 1 8 7 3 (GO) to begin read routine.
5 Start your cassette player.
6 When you see: 0000 D8   stop your cassette player.
7 Enter (RS) (AD) 1 8 7 3 (GO) to read block 2.
8 Start your cassette player.
9 When you see: 0000 D8   stop your cassette player.
10 Enter (RS) (GO)   to start program execution.

If you wish KIM to play a specific opening, enter the ID in address 17F9 and load the opening data. Enter (RS) before and after each tape load.

Data for Openings

Microchess plays

white	black	Opening
A0	A1	Four Knights
A2	A3	French Defence
A4	A5	Ruy Lopez
A6	A7	Queen's Indian
A8	A9	Guioco Piano

Remember to always press (RS) between each tape load. Otherwise, data at 0100 and 0101 may be overwritten by the stack. Verify these locations against the program listing if you have trouble executing the program.

A second copy of the two main programs can be found after the openings.