

page 58,132
title network_virtual_disk_driver

```
*****
;*
;* Virtual Disk Driver April 11, 1983 *
;* Version 3.0 J. Whitnell*
;*
;* Modified from Zynar's DOS 1.1 virtual disk driver. *
;*
;* This driver has knowledge of the DOS 2.0 drive parameter blocks*
;* which appear only in Microsoft OEM documentation. If you are*
;* using version 3.0 or later, you should check this. (I did, and*
;* and version 3.0 gives some values we need. We still use dpbs,*
;* however jdwl).
;*
*****
;*
;* History
;*
;* JDW 5-18-83
;* Support to fix DOS bug (#572). If character and block
;* device drivers are mixed together, DOS allocates tables
;* for both in the same memory. To get around the problem,
;* we must allocate an extra chunk of memory and tell DOS
;* about it. Hence, the vdisk is init'd first, and calculates
;* enough space for the drive table that DOS needs. It
;* then returns drive_end as its end. DOS then builds
;* its tables and init's the other character devices. They
;* return the value (from your_end) that vdisk calculates
;* so that DOS puts its other tables past the end.
;*
;* JDW 5-28-83
;* Fixes to remove address table. We now just store arcnet
;* address and figure things out from there. Also added DIM
;* support, offset drives from 1 instead of 0. Changed interface
;* to vdisk_virt_io to accept station # in DH.
;*
;* cwp 7-31-83
;* Removed logic in real_build_bpb to optionally copy 2.0 bpb,
;* now always copies.
;* Fixed output with verify
;* Made max_drives and clicking settable options
;*
;* PLS 8-9-83
;* Fix to compute length of a DOS 1.1-zformatted volume properly
;*
;* cwp 8-15-83
;* Fix to always zap media desc. in bpb, not only if size changes
;* Fix to keep Media_desc below 128 to keep from looking like ibm
;*
;* cwp 9-13-83
;* added our own pointer to ncmd driver header
;* added encrypted vector to setiobsw
;* added setiobsw routine and job switch timeout logic
;* fixed non-$fe vprints
;* fixed msdos bug #573. see comment for var media_desc
;*
;* JDW 9-27-83 Version 2.1
;* Break driver again by adding mirror volumes.
;* Also added timeouts and our_drive to header.
;*
```

```
.* Also added ve_timeout error code so everyone knows we
.* couldn't talk to the other end.
.* JDW 11-27-83 Version 3.0
.* Use cwp's level 4 instead of Zynar's.
.* JDW 2-16-84 Version 3.1b
.* Add code to remap drives from floppy/hard disk to us for
.* boot from net.
.* JDW 2-22-84 Version 3.1c
.* Add more rb's.
.* GIGI 4-9-84 Version 3.1d
.* Move alloc_more_rbs to l4asm so it gets done for ram version
.* of level 4 (nettemp.sys). Call alloc_more_rbs after calling
.* l4_init.
.* Use common stack as other drivers.
.* Change vdisk_init to initialize all bpb's (not just starting
.* at our_drive).
.* GIGI 4-20-84
.* Fix vdl4init to copy dims from Nic ram correctly.
.* Trace off.
.* JDW/GIGI 4-23-84
.* Add remapped3 for drive C (fix for booting virtual C on
.* floppyless machine).
.* GIGI 4-24-84 Version 3.1
.* Change version for FCS. All trace off.
.* GIGI 4-25-84
.* Change start_noise/end_noise to half_click.
.* GIGI 7-02-84
.* Remove call to build_bpb in read_disk_info so ?drive would
.* not clear MediaChanged flag.
.* Version 3.1.1.
.* GIGI 7-13-84
.* Support Non-IBM DOS by checking for OEM_Name ("IBM 2.0") then
.* check for NIBM_OEM ("IBM 2.0", to be patched) in BPB.
.* Version 3.1.2.
.* GIGI 8-1-84
.* Change version to 3.1.3a to include niccode with int13 fix.
.* PLS 9-12-84
.* Add IBM/Denver RPQ drive-remapping logic to FindDrive. Add
.* conditional assembly flag "denver". No change to non-RPQ
.* versions. RPQ is version 3.1.4a.
.* GIGI 12-04-84
.* Change version to 3.1.3b for virtual printer initialization
.* fixes (for Ctrl PrtSc from BASIC without parallel printer
.* interface).
.* DEBRA 2-25-85
.* Change version to 3.2a for adding retry on disk errors.
.* Number of times to retry is set in header block.
.* DEBRA 3-14-85
.* Change version to 3.2b for adding alt-222 option on header block.
.* so that user can disable alt-222 and not to close the virtual
.* printer from the keyboard. Default is alt-222 on. This option
.* can be changed by running netconf.exe.
.* esp 23 Jul 1985
.* fix vdiskio bug, alt222 option bug, and added code to download
```

```
;* dim info into our NIC RAM. change version to 3.2c
;* esp 25 Jul 1985
;* change version to 3.2d. fix problem with changing fs when
;* issuing network commands.
;* jdww 8 Aug 1985 V 3.2e
;* Add timeout byte to header for virtual printer
;* jdww 13 Aug 1985 V 3.2f
;* Set timeout to 15 seconds, add cursor init code.
;* jdww 26 Aug 1985 V 3.2g
;* For DOS 3.x, get drive number from init block for FindDrive.
;* Also don't fix DOS 2.x bug if running DOS 3.x (init_vidsk)
;* jdww 19 Sept 1985 V 3.2h
;* Fix bsave in ncmd.
;* gkn 28 Oct 1985 V 3.2i
;* Added code by conditional assembly to support Zenith 120.
;* Added in modules vdisk.asm and vdinit.asm.
;* Added conditional assembly to support Zenith 120 speaker click
;* Added speaker click changes in vddef.asm and vdmisc.asm
;* gkn 31 Dec 1985 V 3.2j
;* Added to vddef.asm, 'driver_busy' and 'rb_busy'. Also added
;* notready condition to 'status' macro. Also added 'extern rb_ptr:dword'
;* Added checking and returning error in vddos.asm if drivers are
;* busy. Error is returned to DOS in request header status field.
;* Output status function was added to vddos driver to return
;* status if RB is free or connected.
;*
;*Copyright (c) 1982, 1983 Zynar Ltd.
;*Copyright (c) 1983 Nestar Systems, Inc. Version 2.0
;*Copyright (c) 1983, 1984 Nestar Systems, Inc. Version 3.0
;*Copyright (c) 1984 Nestar Systems, Inc. Version 3.1
;*Copyright (c) 1985 Nestar Systems, Inc. Version 3.2
;*
name vdisk_driver

ELSE
%OUT Pass 2 ...
ENDIF

= 0000 trace equ 0
= 0000 vers3 equ 0
= 0000 for_z120 equ 0 ; one if to run on Zenith 120
denver equ 1 ;denver should be defined only for Denver RPQ

0000 CSEG segment public 'CODE'

assume CS:CSEG,DS:CSEG,ES:NOTHING,SS:NOTHING

C include vdbdc1.asm ; Debug definitions
C
C
C writeln macro str
C local wr1,wr2
C if TRACE
```

```
C          push    si
C          lea    si,wr2
C          call   print_string
C          pop    si
C          jmp    wr1
C wr2:     db     str,OaH,OdH,OH
C wr1:
C endif
C          endm
C ;
C write   macro   str
C         local  wr1,wr2
C if      TRACE
C         push   si
C         lea   si,wr2
C         call  print_string
C         pop   si
C         jmp   wr1
C wr2:     db     str,OH
C wr1:
C endif
C         endm
C ;
C writeint macro   int
C          trace
C          if
C          push   ax
C          mov   ax,int
C          call  print_word
C          pop   ax
C          endif
C          endm
C ;
C writebyte macro   byt
C              trace
C              if
C              push   ax
C              mov   al,byt
C              call  print_byte
C              pop   ax
C              endif
C              endm
C ;
C endif    ; TRACE
C          endif ; for_z120
C          extrn print_string:near, print_crlf:near,print_byte:near
C          extrn print_word:near, print_hex : near,print_char:near
C          %OUT .....VDISK_DEFINITIONS/RAM
C          include vdbpb.asm ; bpb defintion
C bpb      struc
```

```

0000 ????      C          BBytesPerSect  dw    ?
0002 ??       C          BSectPerClust  db    ?
0003 ????      C          BResvSect      dw    ?
0005 ??       C          BFATCount      db    ?
0006 ????      C          BDirEntries    dw    ?
0008 ????      C          BSectCount     dw    ?
000A ??       C          BMediaDesc     db    ?
000B ????      C          BFATSize       dw    ?
C          ;
000D ????      C          BSectsPerTrack  dw    ?
000F ????      C          BHeadCount    dw    ?
0011 ????      C          BHiddenSects   dw    ?
C          ; Nestar stuff.
0013 ??       C          BMediaChanged  db    ?
C          ; FS address
0014 ??       C          BPriFS      db    ?
0015 ??       C          BSecFS      db    ?
C          ; FS state
0016 ??       C          BPriRead    db    ?
0017 ??       C          BPriWrite   db    ?
0018 ??       C          BSecRead    db    ?
0019 ??       C          BSecWrite   db    ?
C          ; IOB error code
001A ??       C          BPriErr     db    ?
001B ??       C          BSecErr     db    ?
C          ; Dim stuff
001C ??       C          BFileType   db    ?
001D ??       C          BFileSubType  db    ?
001E ??       C          BAccess     db    ?
001F ??       C          BShr        db    ?
0020          C          bpb        ends
C
= 0052      C          ReadState   equ    'R'          ; Read from this server
= 0043      C          CompState   equ    'C'          ; Read and compare to other server
= 0057      C          WriteState  equ    'W'          ; Write to this server
= 002D      C          NotUsedState equ    '-'          ; Something wrong. Don't use this server
C
= 0001      C          BPriDim     equ    1
= 0002      C          BSecDim     equ    2
C
= 0020      C          NotMountedType equ    ' '          ; This drive has nothing mounted on it
C
C          include vdef.asm          ;ram/definitions
C
C          subttl vdisk_definitions/ram

```

= FFFF
= 0000
= 0000

```
C          page
C
C          ;return values for interface routines:
C          ;-----
C          TRUE          equ    0FFFFH
C          FALSE         equ    00000H
C          NIL           equ    00000H
C
C
C          ;macros:
C          ;-----
C          ;
C          ;Set status byte of Request Header
C          ;
C          status        macro    state,err,rc
C                          ifidn  <state>,<done>
C                              or
C                              es:word ptr srh_sta_fld[bx],0100h
C                          endif
C                          ifidn  <state>,<busy>
C                              or
C                              es:word ptr srh_sta_fld[bx],0200h
C                          endif
C                          ifidn  <err>,<error>
C                              or
C                              es:word ptr srh_sta_fld[bx],8000h
C                          endif
C                          ifidn  <state>,<notready>
C                              or
C                              es:word ptr srh_sta_fld[bx],8002h
C                          ifnb
C                              <rc>
C                              or
C                              es:word ptr srh_sta_fld[bx],rc
C                          endif
C          endm
C
C          ;Real long jump
C          ;-----
C          bnz           macro    to
C                          local  b
C                          jz      b
C                          jmp     to
C          b:
C                          endm
C
C          ;
C          ;Long call in local segment
C          ;-----
C          lcall         macro    longest          ; Call to long procedure in current seg
C                          push    cs             ; CS is on stack for return
```

```
C          call    longest      ; Then do a near call.
C          endm
C
C          ;byte sex along the wire is hi-order first:
C          ;-----
C          flip      macro    hi,lo
C                   xchg    hi,lo
C                   endm
C
C          ;*****
C          ;IOB commands:
C          ;-----
= 0001    C          IOB_read      equ    1
= 0002    C          IOB_write    equ    2
= 0003    C          IOB_special equ    3          ;special iob's to read execut only
= 0004    C          IOB_init     equ    4          ;not currently used
C
C          ;IOB error codes:
C          ;-----
= 0000    C          ve_ok          equ    0
= 0001    C          ve_no_drive   equ    1          ;no drive mounted          => BIOS_timeout
= 0002    C          ve_illegal_op    equ    2          ;not read/write/init     => BIOS_bad_nec
C                   ; or not special for execute only
= 0003    C          ve_bad_machine   equ    3          ;server not know us      => BIOS_bad_nec
= 0004    C          ve_no_read      equ    4          ;no read_access          => BIOS_write_protect
= 0005    C          ve_no_write    equ    5          ;no write access         => BIOS_write_protect
= 0006    C          ve_bad_block     equ    6          ;                          => BIOS_record_not_fnd
= 0007    C          ve_no_descr_write equ    7          ;no write to descriptor  => BIOS_record_not_fnd
= 0008    C          ve_bad_disk      equ    8          ;peer error (NFS disk)   => BIOS_bad_nec
= 0009    C          ve_restriction   equ    9          ;implementation restriction => BIOS_bad_nec
= 000A    C          ve_level4        equ    10         ;Maude level 4 failure   => BIOS_timeout
= 000B    C          ve_protocol     equ    11         ;peer protocol error     => BIOS_timeout
= 000C    C          ve_internal      equ    12         ;our error (= client abort) => BIOS_timeout
= 000C    C          ve_client_abort  equ    12         ;                          => BIOS_timeout
= 000D    C          ve_timeout      equ    13         ; our timeout.
C
C          ;interrupt vector numbers:
C          ;-----
= 000E    C          ife trace
= 0010    C          write_tty      equ    0EH          ;write screen function
C          video_call      equ    10H          ;int number for screen action
C          endif
C
= 0011    C          equip_call     equ    11H          ;rom bios equipment vector
= 0013    C          diskio_call    equ    13H          ;rom bios disk i/o vector
```

```

= 0016      C kbdio_call      equ    16H      ;rom bios keyboard i/o vector
= 001B      C break_call       equ    1BH      ;rom bios break vector
= 00FD      C map_int          equ    0FDH     ;map interrupt vector
C
C ;port addresses on motherboard used to make noise:
C ;-----
C
= 0040      C timer_zero       equ    40h      ;base of timer chip regs.
= 0042      C timer_two        equ    timer_zero+2
= 0043      C timer_ctrl       equ    timer_zero+3 ;control reg. for timer
= 0002      C spkr_enable      equ    2        ;speaker enable
C else      ; not for_z120
= 0061      C spkr_port        equ    61h      ;port that controls speaker
C endif     ; for_z120
C
C ;drive and address table definitions:
C ;-----
= 001A      C def_max_drive    equ    26
C
C ;DOS calls:
C ;-----
= 0052      C GET_IN_VARS      equ    52H      ; Return internal vars ptr in es:bx
= 0030      C DOS_VERS         equ    30H      ; Return DOS version number
C
C ;DOS 2.0/2.1 internal variables defintions:
C ;-----
= 0000      C dpb_chain        equ    0        ; Chain of drive parameter blocks
= 0010      C last_drive       equ    10H      ; Maximum number of drives in sys
= 0017      C drivers_chain    equ    17H      ; Chain of all drivers
C
C ;Drive Parameter Block (for DOS 2.0 ONLY!):
C ;-----
C ;
C ; Copied from DOSSYM.ASM in MicroSoft OEM documentation.
C ; Note: This documentation is marked Caveat Programmer by
C ; Microsoft. This structure should be checked in new
C ; versions of DOS.
C ;
= 0040      C DIRSTRLEN       equ    64
C
C dpb          struc
0000 ??      C dpb_drive        db    ?        ; Logical drive number (A=0, B=1)
0001 ??      C dpb_UNIT         db    ?        ; Drive unit number
0002 ???     C dpb_sector_size  dw    ?        ; Size of physical sectors in bytes
0004 ??      C dpb_cluster_mask db    ?        ; Sectors/cluster - 1
0005 ??      C dpb_cluster_shift db    ?        ; Log2 of sectors/cluster
0006 ???     C dpb_first_FAT    dw    ?        ; Starting record of FATs
0008 ??      C dpb_FAT_count    db    ?        ; Number of FATs for this drive
0009 ???     C dpb_root_entries dw    ?        ; Number of directory entries
000B ???     C dpb_first_sector dw    ?        ; First sector of first cluster
000D ???     C dpb_max_cluster  dw    ?        ; Number of clusters on drive + 1
000F ??      C dpb_FAT_size     db    ?        ; Number of records occupied by FAT

```



```
0010 ????      C dpb_dir_sector      dw    ?      ; Starting sector of directory
0012 ???????? C dpb_driver_addr    dd    ?      ; Pointer to driver
0016 ??       C dpb_media          db    ?      ; Media byte
0017 ??       C dpb_first_access   db    ?      ; This is initialized to -1 to force
C                                     ; a media check the first time this DPB
C                                     ; is used
0018 ???????? C dpb_next_dpb      dd    ?      ; Pointer to next dpb
001C ????     C dpb_current_dir    dw    ?      ; Cluster number of start of current directory
C                                     ; 0 indicates root, -1 indicates invalid
C                                     ; (disk ? changed)
001E 0040[    C dpb_dir_text       db    DIRSTRLEN dup (?)
    ??
]
C
C                                     ; ASCII string of current directory
005E         C dpb                ends
= 005E      C dpbsiz             equ    size dpb
C
C ;Long Pointer Struc
C ;-----
C pointer      struc
0000 ????     C off                dw    ?
0002 ????     C segp               dw    ?
0004         C pointer            ends
C
C
C ;miscellaneous constants:
C ;-----
= 0020      C io_limit           equ    020H      ; Max blocks we can read
= 005E      C DOS_disk_entry_size equ    05EH      ; Size of DOS's drive table entry
```

```
C          page
C
C
C
C      ;the first executable instruction in the VDISK code segment must be a DOS
C      ;2.0 header block.
C          extrn  stack_top:near, sp_save:word
C          extrn  ss_save:word, stack_use:byte
C          extrn  nc_head:near,driver_end:near,14_init:near
C          extrn  vp_vol_unit:byte, rb_ptr : dword
C          public your_end, my_end, half_click
C          public our_drive, db_flag, driver_busy, rb_busy
C          public click_on, more_rbs, rty_num, alt222, timeout
C          extrn  vdisk_io: near
C          extrn  alloc_more_rbs:near, 14_vars:dword
C
C      next_dev    dw    nc_head        ;pointer to next device
C                  dw    0
C      attribute  dw    2000h          ;block device (non-ibm format)
C      strategy   dw    dev_strategy   ;pointer to device strategy
C      interrupt  dw    dev_int        ;pointer to device interrupt handler
C      dev_name    db    ?              ;number of block devices, filled in by init_vdisk
C                  db    7 dup (?)     ;7 bytes of filler
C
C      ;
C      ; **** magic ****
C      ; These constants are patched by NETCONFIG.EXE and must follow the
C      ; device driver header.
C      ;
C      = 1776
C      secret_bias  equ    1776h          ;offset bias used to hide vectors
C      ;
C      max_drive    dw    def_max_drive  ;soft limit to drives
C      click_on     dw    spkr_enable    ;2 for noise, 0 for silent
C                  dw    nc_head        ;pointer to ncmd header
C                  dw    secret_bias + offset setiobsw
C      db_flag      db    1              ;one for extra info.
C                  ;zero for the quiet life...
C      our_drive    db    ?              ; Driver number we start at.
C      ;
C      more_rbs     dw    4              ; Number of rb's to add in
C      ;
C      rty_num      dw    5              ; Number of times to retry when timeouts
C      ;
C      alt222       dw    1              ; 1 = alt-222 on, 0 = alt-222 off
C      timeout      dw    15*18         ; Number of ticks (vprn timeout)
C      ;
C      ;
C      version      db    'VDISK V3.2j, 12-31-85.  gkn,jdw,tmd,dsj,cwp,gigi,pls,debra,esp./alt/cat
C                  and a cast of thousands'
C
C      33 2E 32 6A 2C 20 31 C
C      32 2D 33 31 2D 38 35 C
```

```
2C 20 20 67 6B 6E 2C C
6A 64 77 2C 74 6D 64 C
2C 64 73 6A 2C 63 77 C
70 2C 67 69 67 69 2C C
70 6C 73 2C 64 65 62 C
72 61 2C 65 73 70 2C C
2F 61 6C 74 2F 63 61 C
74 20 61 6E 64 20 61 C
20 63 61 73 74 20 6F C
66 20 74 68 6F 75 73 C
61 6E 64 73 C
C
C ; *** end of magic ***
C
C ;
0083 00 C driver_busy db 0 ;0 if not busy, 1 if network.sys
C ; drivers are busy
0084 00 C rb_busy db 0 ;0 if not busy, 1 if RB conn_status
C ; is not connected
C
0085 ??? C rh_off dw ? ;request header offset
0087 ??? C rh_seg dw ? ;request header segment
C
C ;vars used in special iob processing
C ;
0089 00 C iob_switch db 0 ;non-zero for special read iobs
008A 0000 C iob_timeout dw 0 ;in 18.2 ticks/sec.
C ;
008C ??? C end_special_lo dw ? ;expiration time for special iobs.
008E ??? C end_special_hi dw ?
C ;
C ; public remapped1 ; For vdl4init
0090 FF C remapped1 db OFFH ; Drive remapped by us
0091 FF C remapped2 db OFFH ; Drive remapped by us
0092 FF C remapped3 db OFFH ; Drive remapped by us
0093 ?? C special_drive db ? ;only acceptable drive for
C ; special iobs, set by setiobsw
C ;
0094 176F C int_la_1 dw 5999 ;an "int la" = (5999+7723) div 2
= 1E2B C int_la_2 equ 7723
C ;
C ;
0096 ??? C your_end dw ? ; Offset to end of driver.
0098 0000 E C my_end dw offset driver_end ; My end of driver.
C ;
009A 0000 C control_word dw 0 ;for NIC_link board,routine
C ;
009C 00 00 00 00 C old_13_vector dd 0 ;stash for old diskio vector
00A0 00 00 00 00 C old_11_vector dd 0 ;stash for old equipment vector
00A4 00 00 00 00 C old_1B_vector dd 0 ;stash for old break vector
C ;vector
C ;
C ;DOS appears to want more than just a disk change flag to cause it to
C ;update it's internal bpb's
```

```
C ;This byte is incremented each time a disk change occurs, we think this
C ;convinces DOS that the disk has really changed
C ;
00A8 01 C Media_desc db 1 ; Our current media.
C ;
C ;Locals for various routines
C ;-----
00A9 ?? C save_drive db ? ; For build_bpb
00AA ?? C io_fs db ? ; File server I/O is sent to.
C ;
C ;Constants stored in memory (Hopefully they don't change)
C ;-----
00AB 0020 C type_bpb dw type_bpb ; Idiots couldn't put immediate mode on mul
00AD 0200 C bytes_per_sector dw 0200H ; What is being used
00AF 0200 C block_size dw 0200H ; For non-DOS mounts.
00B1 49 42 4D 20 20 32 2E C OEM_Name db 'IBM 2.0' ; Our OEM Name (8 bytes)
30 C
00B9 50 4C 41 4E 34 30 30 C ID db 'PLAN4000/IBMPC/DOS1.1'
30 2F 49 42 4D 50 43 C
2F 44 4F 53 31 2E 31 C
C
= 0015 C ID_len equ $ - offset ID ; DOS 1.1 id.
00CE 4F 45 4D 2D 3E C marker db 'OEM->'
00D3 49 42 4D 20 20 32 2E C NIBM_OEM db 'IBM 2.0' ; alternate OEM Name to be patched
30 C
C
C
C ;structures:
C ;-----
C etna_dim struc
C EDCode db ?
C EDSubCode db ?
C EDDriveNum dw ?
C EDFileType db ?
C EDFileSubType db ?
C EDAccess db ?
C EDShr db ?
C EDSIZE dd ?
C EDFiller db 6 dup (?)
C
C ]
C
0012 C etna_dim ends
C
= 0000 C NopCode equ 0
= 0001 C MountCode equ 1
= 0002 C UnmountCode equ 2
C
C
= 000D C bpb_on_disk equ 0DH ; Number of bytes actually on disk
C
```

```

= 01C0          C Code_Len      equ          448d          ; from Zynar's format routine.
                C
                C Boot_Record  struc
0000 01C0[      C B_Code        db          Code_Len dup (?)
    ??         C
    ]         C
                C
01C0 0015[      C B_ID          db          ID_len dup (?)
    ??         C
    ]         C
                C
0105 ??         C B_vpb_spc     db          ?
0106 ??         C B_vpb_csf     db          ?
0107 ???       C B_vpb_vol_ss  dw          ?
0109 ??         C B_vpb_nfats   db          ?
010A ???       C B_vpb_nf      dw          ?
010C ???       C B_vpb_data_ss dw          ?
010E ???       C B_vpb_ndc     dw          ?
01E0 ??         C B_vpb_spf     db          ?
01E1 ???       C B_vpb_dir_ss  dw          ?
01E3 0010[      C B_filler     db          29d dup (?)
    ??         C
    ]         C
                C
0200          C Boot_Record  ends
                C
                C block0      struc
0000 0003[      C B0Jump       db          3 dup (?)
    ??         C
    ]         C
                C
0003 0008[      C B00EM        db          8 dup (?)
    ??         C
    ]         C
                C
                C
0008 ???       C B0BytesPerSect dw        ?
0009 ??         C B0SectPerClust db        ?
000E ???       C B0ResvSect    dw        ?
0010 ??         C B0FATCount    db        ?
0011 ???       C B0DirEntries  dw        ?
0013 ???       C B0SectCount   dw        ?
0015 ??         C B0MediaDesc   db        ?
0016 ???       C B0FATSize     dw        ?
                C
                C ;
0018 ???       C B0SectsPerTrack dw        ?
001A ???       C B0HeadCount   dw        ?
001C ???       C B0HiddenSects dw        ?
001E          C block0      ends
                C
                C request_header struc
0000 ??         C RhLength      db        ?
0001 ??         C RhUnit        db        ?
0002 ??         C RhCommandCode db        ?
0003 ???       C RhStatus      dw        ?

```

```

0005 0008[      C      RhDOSResv      db      8 dup (?)
      ??          C
      ]          C
0000          C      request_header ends
      C
= 0000          C      dos_init      equ      0      ; Initilize driver
= 0001          C      dos_media_check equ      1      ; Has media been changed?
= 0002          C      dos_build_bpb  equ      2
= 0003          C      dos_ioctl_in   equ      3
= 0004          C      dos_read      equ      4
= 0005          C      dos_read_nowait equ      5
= 0006          C      dos_in_status  equ      6
= 0007          C      dos_in_flush   equ      7
= 0008          C      dos_output     equ      8
= 0009          C      dos_out_verify  equ      9
= 000A          C      dos_out_status  equ     10
= 000B          C      dos_out_flush   equ     11
= 000C          C      dos_ioctl_out  equ     12
      C
0000 0000[      C      init_rh      struc
      ??          C      IRH          db      type request_header dup (?)
      ]          C
0000 ??          C      IUnitCount   db      ?
000E 00 00 00 00 C      IDriverEnd   dd      0
0012 00 00 00 00 C      IBPBArray    dd      0
0016 00          C      IOurDrive    db      0
0017          C      init_rh      ends
      C
0000 0000[      C      build_bpb_rh  struc
      ??          C      BPBRH        db      type request_header dup (?)
      ]          C
0000 ??          C      BPBMediaDesc db      ?
000E 00 00 00 00 C      BPBTempBuffer dd      0
0012 00 00 00 00 C      BPBBPBPointer dd      0
0016          C      build_bpb_rh ends
      C
      C      ; Parameter Header Offsets
      C      ;
= 0000          C      srh          equ      0      ;static request header start
= 0000          C      srh_len      equ     13      ; " " " length
=          C      srh_len_fld equ srh   ; " " " " field
= 0001          C      srh_ucd_fld  equ srh+1    ; " " " unit code field
= 0002          C      srh_ccd_fld  equ srh+2    ; " " " command code field
= 0003          C      srh_sta_fld  equ srh+3    ; " " " status field
= 0005          C      srh_res_fld  equ srh+5    ; " " " reserved area field
      C
      C      ;
      C      ; Input/Output

```



```
?? C  
?? C  
?? C  
?? C  
?? C  
?? C  
?? C  
?? C  
?? C  
?? C  
] C  
C  
C ; We start out life looking like double sided  
C ; floppies.  
041B 001A[ C bpb_ptr_table dw def_max_drive dup (?)  
???? ] C  
C  
C  
044F ??? C temp_bpb bpb <> ; Copy of bpb for build_bpb  
0451 ?? C  
0452 ??? C  
0454 ?? C  
0455 ??? C  
0457 ??? C  
0459 ?? C  
045A ??? C  
045C ??? C  
045E ??? C  
0460 ??? C  
0462 ?? C  
0463 ?? C  
0464 ?? C  
0465 ?? C  
0466 ?? C  
0467 ?? C  
0468 ?? C  
0469 ?? C  
046A ?? C  
046B ?? C  
046C ?? C  
046D ?? C  
046E ?? C  
C  
C  
C ;vdisk tables for volumes without header (1.1 floppy size)  
C ;-----  
046F 0200 C single_8_bpb bpb <200H, 1, 1, 2, 64d, 40*8, OFEH, 1, 8, 1, 0, 0 >  
0471 01 C  
0472 0001 C  
C
```



```
0474 02          C
0475 0040        C
0477 0140        C
0479 FE          C
047A 0001        C
047C 0008        C
047E 0001        C
0480 0000        C
0482 00          C
0483 ??          C
0484 ??          C
0485 ??          C
0486 ??          C
0487 ??          C
0488 ??          C
0489 ??          C
048A ??          C
048B ??          C
048C ??          C
048D ??          C
048E ??          C
C
C ;double_8_bpb  bpb  <200H, 2, 1, 2, 112d, 2*40*8, 0FFH, 1, 8, 2, 0, 0 >
048F 0200        C ;single_9_bpb  bpb  <200H, 1, 1, 2, 64d, 40*9, 0FCH, 1, 9, 1, 0, 0 >
0491 01          C
0492 0001        C
0494 02          C
0495 0040        C
0497 0168        C
0499 FC          C
049A 0001        C
049C 0009        C
049E 0001        C
04A0 0000        C
04A2 00          C
04A3 ??          C
04A4 ??          C
04A5 ??          C
04A6 ??          C
04A7 ??          C
04A8 ??          C
04A9 ??          C
04AA ??          C
04AB ??          C
04AC ??          C
04AD ??          C
04AE ??          C
C
C double_9_bpb  bpb  <200H, 2, 1, 2, 112d, 2*40*9, 0FDH, 1, 9, 2, 0, 0 >
04AF 0200        C
04B1 02          C
04B2 0001        C
04B4 02          C
04B5 0070        C
04B7 02D0        C
```


04EF ????????

C rh_bpb_ptr
C

dd ?

%OUTVDISK_DOS_INTERFACE
C include vddos.asm ;DOS 2.0 interface
C
C subttl DOS Interface to virtual disk driver

```
C      page
C      -----
C      ;
C      ;       DOS interface to virtual disk driver. This routine interprets
C      ;       calls to the driver.
C      ;
C      ;-----
C      ;
04F3   C      vdisk  proc   far
C      ;
C      ;       function table
C      ;
04F3   C      funtab  label  byte
C      ;
04F3   C          dw   init_vdisk      ;initialization
04F5   C          dw   media_check    ;media check (block only)
04F7   C          dw   build_bpb      ;build bpb
04F9   C          dw   ioctl_in      ;ioctl input
04FB   C          dw   input          ;input (read)
04FD   C          dw   nd_input      ;non_destructive input no wait (char only)
04FF   C          dw   in_stat       ;input status
0501   C          dw   in_flush      ;input flush           "  "
0503   C          dw   output        ;output (*write)
0505   C          dw   out_verify     ;output (write) with verify
0507   C          dw   out_stat      ;output status         "  "
0509   C          dw   out_flush     ;output flush         "  "
050B   C          dw   ioctl_out     ;ioctl output
C      ;
C      ;       device strategy
C      ;
050D   C      dev_strategy:
050D   C          mov   cs:rh_seg,es    ;save segment of request header pointer
0512   C          mov   cs:rh_off,bx   ;save offset of "  "
0517   C          ret
C      ;
C      ;       device interrupt handler
C      ;
0518   C      dev_int:
C      ; preserve machine state on entry
C      ;
0518   C          cld
0519   C          push  ds
051A   C          push  es
051B   C          push  ax
051C   C          push  bx
051D   C          push  cx
051E   C          push  dx
051F   C          push  di
0520   C          push  si
0521   C          push  bp
C      ;
C      ;       Now set DS to be the code segment
C      ;
0522   C          mov   ax,cs
0524   C          mov   ds,ax
```

```
C      assume ds:cseg
C      ;
C      ; Set up local stack
C      ;
0526 FE 06 0000 E      C      inc      stack_use      ;we know we are first user
052A 89 26 0000 E      C      mov      sp_save,sp
052E 8C 16 0000 E      C      mov      ss_save,ss
0532 FA                C      cli
0533 90                C      nop
0534 BC 0000 E      C      mov      sp,offset stack_top
0537 8E D0            C      mov      ss,ax      ;still = cs
0539 FE 06 0083 R      C      inc      driver_busy
053D 80 3E 0083 R 01    C      cmp      driver_busy,1 ; are other driver active
0542 74 10            C      je      notbusy
0544 FB                C      sti      ; enable interrupts
C      status notready,noerror,0 ; send notready error
0551 EB 35 90        C      jmp     exit      ; return to DOS
C      ;
C      ; do iob switch processing
C      ;
C      ;
0554 notbusy:
0554 FB                C      sti      ;enable interrupts
0555 80 3E 0089 R 00    C      cmp      iob_switch,0 ;in special iob mode ?
055A 74 1C            C      je      do_function ;skip this if not
C      ;I don't think this will work if the protected program is loading across midnight
055C E8 0C77 R      C      call     get_tod      ;get current time
055F 2B 16 008C R      C      sub      dx,end_special_lo ;compare against expire time
0563 1B 0E 008E R      C      sbb      cx,end_special_hi
0567 73 0A            C      jnc     cancel_special ;cancel if tod >= end_special
0569 26: 8A 47 01      C      mov      al,es:srh_ucd_fld[bx] ;check for correct special drive
056D 3A 06 0093 R      C      cmp      al,special_drive ;stay in special iob state if
0571 74 05            C      je      do_function ; correct drive
0573 cancel_special:
0573 C6 06 0089 R 00      C      mov      iob_switch,0 ;clear the iob switch
0578 do_function:
C      ;
C      ; Do the branch according to the function passed
C      ;
0578 26: 8A 47 02      C      mov      al,es:srh_ccd_fld[bx] ;get function byte
057C D0 C0            C      rol      al,1      ;get offset into table
057E 8D 3E 04F3 R      C      lea     di,funtab ;get address of function table
0582 32 E4            C      xor      ah,ah
C      write 'Dos function: '
C      writeint ax
C      writeln ''
0584 03 F8            C      add     di,ax
C      ; call dos_debug
0586 FF 25            C      jmp     word ptr[di]
```

```
C      page
C      ;*****
C      ;
C      ;      common exit
C      ;
0588      exit:
C      ;      writeln 'At exit...'
0588      E8 0CBA R      call set_end_special      ;remember time of last call to us
C      ;      writeln 'after set_end_special'
0588      2E: 8E 06 0087 R      mov es, cs:rh_seg
0590      2E: 8B 1E 0085 R      mov bx, cs:rh_off
C      ;      write 'Returning '
C      ;      writeint es:[bx].RhStatus
C      ;      writeln ' '
0595      FA
0596      2E: 8E 16 0000 E      cli
0598      2E: 8B 26 0000 E      mov ss, cs:ss_save      ; Restore stack pointer
05A0      FE 0E 0000 E      mov sp, cs:sp_save
05A4      FE 0E 0083 R      dec stack_use      ; we know we are outer user
05A8      FB
05A9      5D
05AA      5E
05AB      5F
05AC      5A
05AD      59
05AE      5B
05AF      58
0580      07
0581      1F
0582      CB
C      ;      pop bp
C      ;      pop si      ;restore all of the registers
C      ;      pop di
C      ;      pop dx
C      ;      pop cx
C      ;      pop bx
C      ;      pop ax
C      ;      pop es
C      ;      pop ds
C      ;      ret
C      vdisk      endp
```

```
05B3          C          page
C          C vsub      proc      near
C          C ;*****
C          C ;
C          C ; media check
C          C ;
0583          C media_check:          ; media check (block only)
05B3 E8 0C66 R C          call      get_drive
05B6 B4 00      C          mov       ah,0          ; Convert to 16 bits
0588 2E: F7 26 00AB R C          mul      cs:type_bpb ; Offset into bpb table
C          C ;
05BD 8B F0      C          mov       si,ax          ; To an index register
05BF 2E: 8A 84 00EE R C          mov       al,cs:bpb_table[si].BMediaChanged
C          C ;
05C4 2E: 80 BC 00F7 R 20 C          cmp      cs:bpb_table[si].BFileType, NotMountedType
05CA 75 02      C          jne      mcl
05CC 80 01      C          mov       al, MediaNotTouched
C          C ;
05CE          C mcl:
05CE 26: 88 47 0E C          mov       es:ret_byte[bx],al ; Return to caller
C          C ;
05DE EB A8      C          status done,noerror,0 ;turn on the done bit
C          C          jmp      exit
```

```
C          page
C          ;*****
C          ;
C          ; build bios parameter block
C          ;
05E0      build_bpb:
05E0      call    real_build_bpb      ; Do the real work
05E3      EB A3      jmp    exit
C
C          ;*****
C          ;
C          ; the following entries are for not supported by this device
C          ;
05E5      ioctl_in:
05E5      ioctl_out:
05E5      nd_input:      ;non_destructive input no wait (char only)
05E5      in_stat:      ;input status
05E5      in_flush:      ;input flush
05E5      out_flush:      ;output flush
C          status done,error,03H
05F7      EB 8F      jmp    exit
```



```
C      page
C      ;*****
C      ;
C      ; Output Status
C      ;
C      out_stat:          ;output status
C      cmp      rb_busy,0      ; RB Connected?
C      je      vd_notbusy     ; rb is not busy
C      status  busy,noerror,0 ;turn on the busy bit
C      vd_notbusy:
C      jmp     exit
```

```

C      page
C      ;*****
C      ;
C      ; disk write
C      ;
060F   out_verify:
060F   output:
060F   E8 0C66 R      call    get_drive          ;output (write)
0612   F6 26 00AB R  mul    byte ptr type_bpb   ; Convert to offset in bpb table
0616   8B F0        mov    si, ax
C      ;
0618   B4 05        mov    ah, ve_no_write     ; Set default error code
061A   2E: 88 A4 00F5 R  mov    cs:bpb_table[si].BPriErr,ah; store in table
061F   2E: 88 A4 00F6 R  mov    cs:bpb_table[si].BSecErr,ah
0624   BA 0000      mov    dx, 0              ; Clear length in case no write
C      ;
0627   B4 00        mov    ah, ve_ok          ; If primary is not being written too,
0629   2E: 80 BC 00F2 R 57  cmp    cs:bpb_table[si].BPriWrite, WriteState
062F   75 26        jne   o5
C      ;
0631   2E: 8A 84 00EF R  mov    al, cs:bpb_table[si].BPriFS
0636   84 03        mov    ah, ve_bad_machine
0638   0A C0        or    al,al              ; If 0, then this hasn't been set
063A   74 1B        jz    o5
063C   A2 00AA R     mov    io_fs,al          ; Set file server for i/o
C      ;
063F   56          push   si
0640   E8 06BF R     call  out1
0643   5E          pop    si
C      ;
0644   80 FC 01      cmp    ah, ve_no_drive
0647   75 0E        jne   o5
0649   2E: 80 BC 00F0 R 00  cmp    cs:bpb_table[si].BSecFS, 0
064F   75 06        jne   o5
0651   2E: C6 84 00F7 R 20  mov    cs:bpb_table[si].BFileType, NotMountedType
C      ;
0657   o5:
0657   2E: 88 A4 00F5 R     mov    cs:bpb_table[si].BPriErr, ah
065C   2E: C6 84 00F6 R 00  mov    cs:bpb_table[si].BSecErr, ve_ok
C      ;
0662   2E: 80 BC 00F4 R 57  cmp    cs:bpb_table[si].BSecWrite, WriteState
0668   75 18        jne   o2
066A   2E: 8A 84 00F0 R     mov    al, cs:bpb_table[si].BSecFS
066F   84 03        mov    ah, ve_bad_machine
0671   0A C0        or    al,al              ; If 0, then this hasn't been set
0673   74 08        jz    o6
0675   A2 00AA R     mov    io_fs, al
C      ;
0678   56          push   si
0679   E8 06BF R     call  out1
067C   5E          pop    si
C      ;
067D   o6:
067D   2E: 88 A4 00F6 R     mov    cs:bpb_table[si].BSecErr, ah
C      ;
```

```
0682          C o2:
0682 2E: 8A 84 00F5 R C      mov    al, cs:bbp_table[si].BPriErr
0687 3C 00      C      cmp    al, ve_ok          ; Is primary ok
0689 75 06      C      jne   o3              ; No, report error
C ;
068B 86 E0      C      xchg  ah, al
068D 3C 00      C      cmp    al, ve_ok          ; Is secondary ok
068F 74 1F      C      je    o4              ; Yes, no error so return
C ;
0691          C o3:
0691 26: 29 57 12 C      sub    es: word ptr [bx].count, dx
0695 B4 00      C      mov    ah, 0             ; Update count and set error to int
0697 8B F0      C      mov    si, ax
0699 8A 84 04CF R C      mov    al, BIOS_error[si] ; translate from IOB error
C      status done, error, ax
C      jmp   exit
C ;
0680          C o4:
0680          C      status done, noerror, 0
068C E9 0588 R   C      jmp   exit
C ;
C ;
C ;      out1. Detirmine iob command and handle write with verify
C ;
068F          C out1:
068F C6 06 0089 R 00 C      mov    iob_switch,0      ;clear the iob switch
06C4 B4 02      C      mov    ah, IOB_write
06C6 E8 079A R   C      call   doio              ; Do the write]
C ;
06C9 80 FC 00   C      cmp    ah, ve_ok          ; Was write ok
06CC 75 16   C      jne   out2              ; If not, don't bother to verify
C ;
06CE 26: 80 7F 02 09 C      cmp    es: byte ptr srh_ccd_fld[bx], dos_out_verify
06D3 75 0F   C      jne   out2
C ;
06D5 26: C6 47 02 04 C      mov    es: byte ptr srh_ccd_fld[bx], dos_read
06DA B4 01   C      mov    ah, IOB_read
06DC E8 079A R   C      call   doio
06DF 26: C6 47 02 09 C      mov    es: byte ptr srh_ccd_fld[bx], dos_out_verify
C ;
06E4          C out2:
06E4 C3          C      ret
```

```

C      page
C      ;*****
C      ;*
C      ;*   Disk Read.  Read from whichever volume has the read flag set.
C      ;*   Primary takes precedence over secondary.
C      ;*
C      ;*
C      ;*   input:
C      ;*
C      ;*   call   get_drive
C      ;*   mul    byte ptr cs:type_bpb      ; Offset in bpb table
C      ;*   mov    si,ax
C      ;*
C      ;*
C      ;*   cmp    cs:bpb_Table[si].BPriRead,ReadState  ; Read from primary?
C      ;*   jne    i1
C      ;*
C      ;*
C      ;*   mov    al, cs:bpb_table[si].BPriFS      ; Get primary file server
C      ;*   mov    ah, ve_bad_machine              ; If we're not talking
C      ;*   or     al,al                            ; Are we talking?
C      ;*   je     i5
C      ;*
C      ;*
C      ;*   mov    io_fs, al                        ; Set up global stn adr
C      ;*   push  si
C      ;*   call  inl                               ; Do it.
C      ;*   pop   si
C      ;*
C      ;*
C      ;*   cmp    ah, ve_no_drive                 ;
C      ;*   jne    i5
C      ;*   cmp    cs:bpb_table[si].BSecFS, 0
C      ;*   jne    i5
C      ;*   mov    cs:bpb_table[si].BFileType, NotMountedType
C      ;*
C      ;*
C      ;*   i5:
C      ;*   mov    cs:bpb_table[si].BPriErr, ah    ; Save error code
C      ;*   jmp    i2                               ; Off we go.
C      ;*
C      ;*
C      ;*   i1:
C      ;*   cmp    cs:bpb_Table[si].BSecRead,ReadState  ; Read here?
C      ;*   jne    i3                               ; Nope, no reads
C      ;*
C      ;*
C      ;*   mov    al, cs:bpb_table[si].BSecFS      ; Get secondary file server
C      ;*   mov    ah, ve_bad_machine              ; If we're not talking
C      ;*   or     al,al                            ; Are we talking?
C      ;*   je     i6
C      ;*
C      ;*
C      ;*   mov    io_fs, al                        ; Set up global stn adr
C      ;*   push  si
C      ;*   call  inl                               ; Do it.
C      ;*   pop   si
C      ;*
C      ;*
C      ;*   i6:
C      ;*   mov    cs:bpb_table[si].BSecErr, ah    ; Save error code
C      ;*   jmp    i2                               ; Off we go.
C      ;*
C      ;*
C      ;*   i3:
C      ;*   mov    ah, ve_no_read                  ; Come here if no reads allowed
C      ;*   mov    cs:bpb_table[si].BPriErr, ah    ; No error on read

```

```
074F 2E 88 A4 00F6 R    C      mov     cs:bbp_table[si].BSecErr, ah
0754 BA 0000           C      mov     dx, 0                      ; 0 bytes read
0757                   C      i2:
0757 80 FC 00           C      cmp     ah, ve_ok                  ; is everything OK?
075A 74 21             C      je     i4                        ; Yes
                                C      ;
075C 26 29 57 12       C      sub     es: word ptr [bx].count, dx ; Adjust count to show work done
0760 80 00             C      mov     al, 0
0762 86 E0             C      xchg    ah, al                    ; Convert error code to word
0764 8B F0             C      mov     si, ax
0766 8A 84 04CF R     C      mov     al, BIOS_error[si]        ; translate from IOB error
                                C      status done, error, ax
077A E9 0588 R         C      jmp     exit
                                C      ;
077D                   C      i4:
                                C      status done, noerror, 0
0789 E9 0588 R         C      jmp     exit
                                C      ;
                                C      ; Figure out proper iob command and pass it on to doio
                                C      ;
                                C      ;
078C                   C      i1:
078C B4 01             C      mov     ah, IOB_read              ;assume normal read
078E 80 3E 0089 R 00   C      cmp     iob_switch, 0            ;special ?
0793 74 02             C      je     normal_input            ;jump if not special
0795 B4 03             C      mov     ah, IOB_special
0797                   C      normal_input:
0797 EB 01 90         C      jmp     doio
```

```
C      page
C      ;*****
C      ;
C      ; doio. Doio is the command code for input and output. It windows
C      ; the request to less then 128 blocks (due to sign problems in
C      ; virt_disk_io). It expects the IOB command in ah and the file
C      ; server station to be stored in the variable io_fs. It returns
C      ; the error code in ah and the blocks actually done in dx
C      ;
C      ; doio:
C      ; call    get_drive
C      ;
C      ; mov    dx,es:count[bx]      ; Number of sectors
C      ; cmp    dx,0                 ; Anything to do?
C      ; je    nothing_to_do
C      ; mov    cx,es:ssn[bx]       ; Start sector number
C      ; les   bx,es:[bx].BPBTempBuffer ; Pointer to data in es:bx
C      ;
C      ; See if we need to window
C      ;
C      ; window:
C      ; cmp    dx,io_limit
C      ; jbe   in_limit
C      ;
C      ; push   ax
C      ; push   bx
C      ; push   cx
C      ; push   dx
C      ; push   es
C      ; call  get_file_server      ; Returned in dh
C      ; mov   di,io_limit
C      ; lcall vdisk_io
C      ; bnz  window_error
C      ; pop   es
C      ; pop   dx
C      ; pop   cx
C      ; pop   bx
C      ; pop   ax
C      ; sub   dx,io_limit
C      ; add   cx,io_limit          ; Update code
C      ; add   bx,io_limit*200H    ; and hope we don't wrap around
C      ; jmp  window
C      ;
C      ; window_error:
C      ; pop   es
C      ; pop   dx
C      ; pop   cx
C      ; pop   bx
C      ; pop   bx                  ; Dump old ax
C      ; jmp  io_return
C      ;
C      ; Come here if less then our limit
C      ;
C      ; in_limit:
C      ;
079A
079A EB 0C66 R
079D 26: 8B 57 12
07A1 83 FA 00
07A4 74 42
07A6 26: 8B 4F 14
07AA 26: C4 5F 0E
07AE
07AE 83 FA 20
07B1 76 2C
07B3 50
07B4 53
07B5 51
07B6 52
07B7 06
07B8 E8 0C61 R
07BB B2 20
07C6 07
07C7 5A
07C8 59
07C9 5B
07CA 58
07CB 83 EA 20
07CE 83 C1 20
07D1 81 C3 4000
07D5 EB 07
07D7
07D7 07
07D8 5A
07D9 59
07DA 5B
07DB 5B
07DC EB 0A 90
07DF
```

```
07DF 52          C      push  dx
07E0 EB 0C61 R   C      call  get_file_server
          C      lcall vdisk_io      ; Off we go...
07E7 5A          C      pop   dx          ; Restore size of read
          C      ;
07E8          C      nothing_to_do:
07E8          C      io_return:
07E8 2E: 8B 1E 0085 R C      mov  bx,cs:rh_off
07ED 2E: 8E 06 0087 R C      mov  es,cs:rh_seg  ; Get back request header
07F2 C3          C      ret
          C
          C      vsub      endp
```

```

C      page
C      ;*****
C      ;*
C      ;*   Real_build_bpb
C      ;*
C      ;*   Do the actual work of building a bpb.  ES:BX is the pointer
C      ;*   to a dos style request header.
C      ;*
C      ;*
C      real_build_bpb proc near
07F3      call    get_drive
07F3 E8 0C66 R   write    'drive '
C      writebyte    al
C      write    ' '
C      ;
07F6 2E: F6 26 00AB R   mul     byte ptr cs: type_bpb      ; Convert to index in bpb table
07FB 8B F0             mov     si,ax
C      ;
07FD 2E: C6 84 00F5 R 04   mov     cs:bpb_table[si].BPriErr, ve_no_read
0803 2E: C6 84 00F6 R 04   mov     cs:bpb_table[si].BSecErr, ve_no_read
C      ;
0809 2E: 80 BC 00F1 R 2D   cmp     cs:bpb_table[si].BPriRead, NotUsedState
080F 75 08             jne     rbb1      ; Primary in use
0811 2E: 80 BC 00F2 R 2D   cmp     cs:bpb_table[si].BPriWrite, NotUsedState
0817 74 31             je      rbb2
C      ;
0819      rbb1:
0819 2E: 8A 84 00EF R   mov     al, cs:bpb_table[si].BPriFS      ; Get file server
081E B4 03             mov     ah, ve_bad_machine
0820 0A CD             or      al,ah
0822 74 1B             jz      rbb8
0824 A2 00AA R   mov     io_fs, al      ; and set it.
0827 56             push    si
0828 E8 08FD R   call    bpb1
082B 5E             pop     si
C      write    'Returned '
C      writebyte    ah
C      write    ' '
C      ;
082C 80 FC 01             cmp     ah, ve_no_drive
082F 75 0E             jne     rbb8
0831 2E: 80 BC 00F0 R 00   cmp     cs:bpb_table[si].BSecFS, 0
0837 75 06             jne     rbb8
0839 2E: C6 84 00F7 R 20   mov     cs:bpb_table[si].BFileType, NotMountedType
C      ;
083F      rbb8:
083F 2E: 88 A4 00F5 R   mov     cs:bpb_table[si].BPriErr, ah
0844 2E: C6 84 00F6 R 00   mov     cs:bpb_table[si].BSecErr, ve_ok
C      ;
084A      rbb2:
084A 2E: 80 BC 00F3 R 2D   cmp     cs:bpb_table[si].BSecRead, NotUsedState
0850 75 08             jne     rbb3      ; Primary in use
0852 2E: 80 BC 00F4 R 2D   cmp     cs:bpb_table[si].BSecWrite, NotUsedState
0858 74 5F             je      rbb4
C      ;
085A      rbb3:
085A 2E: 80 BC 00F5 R 00   cmp     cs:bpb_table[si].BPriErr, ve_ok

```



```
0860 75 10      C      jne      rbb5      ; Don't copy, its not there
              C      ;
0862 06        C      push     es
0863 56        C      push     si
0864 51        C      push     cx      ; Save regs used
              C      ;
0865 1E        C      push     ds
0866 07        C      pop      es
0867 BF 044F R  C      mov     di, offset temp_bpb ; Stash primary bpb here
086A B9 0020   C      mov     cx, type bpb      ; this much
086D F3/ A4   C      rep     movsb      ; Shovel as fast as you can
086F 59        C      pop     cx
0870 5E        C      pop     si
0871 07        C      pop     es
              C      ;
0872          C      rbb5:
0872 2E: 8A 84 00F0 R C      mov     al, cs:bbp_table[si].BSecFS ; Get file server
0877 B4 03      C      mov     ah, ve_bad_machine
0879 0A CD     C      or      al, al
087B 74 08     C      jz     rbb9
087D A2 00AA R C      mov     io_fs, al      ; and set it.
0880 56        C      push    si
0881 E8 08FD R C      call   bpb1
0884 5E        C      pop     si
              C      ;
0885          C      rbb9:
0885 2E: 88 A4 00F6 R C      mov     cs:bbp_table[si].BSecErr, ah
              C      ;
088A 80 FC 00   C      cmp     ah, ve_ok      ; Did secondary finish?
088D 75 2A      C      jne     rbb4      ; No, don't compare
088F 2E: 80 BC 00F5 R 00 C      cmp     cs:bbp_table[si].BPriErr, ve_ok ; Did primary finish?
0895 75 22      C      jne     rbb4      ; No
              C      ;
0897 06        C      push     es
0898 56        C      push     si
0899 51        C      push     cx      ; save some regs
              C      ;
089A 1E        C      push     ds
089B 07        C      pop     es
089C BF 044F R  C      mov     di, offset temp_bpb
089F B9 000D   C      mov     cx, bpb_on_disk ; Compare only important stuff
08A2 F2/ A6   C      repne  cmpsb
08A4 59        C      pop     cx
08A5 5E        C      pop     si
08A6 07        C      pop     es
08A7 74 10     C      je     rbb4      ; Everything same
              C      ;
08A9 56        C      push     si
08AA 51        C      push     cx
08AB BF 044F R  C      mov     di, offset temp_bpb ; Restore primary
08AE B9 000D   C      mov     cx, bpb_on_disk
08B1 F3/ A4   C      rep     movsb
              C      ;
08B3 B8 0008   C      mov     ax, 8      ; Media unknown
```

```
08B6 EB 34 90          C          jmp     rbb6          ; and off we go
C          ;
C          rbb4:
08B9                C          mov     al, cs:bbp_table[si].BPriErr ; Get primary error code
08BE 2E: 8A 84 00F5 R  C          cmp     al, ve_ok
08C0 3C 00              C          jne     rbb7          ; Not ok, report it
08C2 75 1C              C          mov     al, cs:bbp_table[si].BSecErr ; Get secondary error code
08C7 2E: 8A 84 00F6 R  C          cmp     al, ve_ok
08C9 3C 00              C          jne     rbb7          ; No ok
C          ;
08CB 2E: C6 84 00EE R 01 C          mov     cs:bbp_table[si].BMediaChanged, MediaNotTouched
C          ;
C          status done, noerror, 0
08DD C3                C          ret
C          ;
C          rbb7:
08DE                C          mov     cs:bbp_table[si].BMediaChanged, MediaChanged
08E4 2E: C6 84 00EE R FF C          mov     ah, 0          ; Convert al to word
08E6 B4 00              C          mov     si, ax
08E8 8A 84 04CF R      C          mov     al, BIOS_error[si] ; Convert error code
08EC                C          rbb6:
C          status done, error, ax
08FC C3                C          ret
C          real_build_bpb endp
```

```
C      page
C      ;*****
C      ;*
C      ;*      bpb1. Build a bpb from one of the file servers. Expects
C      ;*      io_fs to contain the station address of the file server.
C      ;*      Note that on errors, the bpb table is assumed to be left
C      ;*      unchanged.
C      ;*
C      ;*
C      bpb1      proc      near
C      mov      ah,I0B_read      ;assume normal read
C      cmp      iob_switch,0      ;special ?
C      je      normal_bpb      ;jump if not special
C      mov      ah, I0B_special
C      normal_bpb:
C      call     get_drive
C      mov      cs:save_drive, al      ; Save driver number
C      call     Get_file_server      ; Get servers station in dh
C      ;
C      mov      dl,1      ; of 1 sector
C      mov      cx,0      ; from sector 0
C      les      bx,es:[bx].BPBTempBuffer ; into DOS's buffer
C      lcall    vdisk_io
C      bnz      bad_bpb
C      ;
C      cmp      cx,1      ; See if we got the right #
C      mov      ah, ve_bad_disk      ; Read error
C      bnz      bad_bpb      ; Oops, should never happen
C      ;
C      mov      ah, ve_bad_disk      ; Unknown Media
C      ;
C      mov      si,offset OEM_name      ; check primary OEM ('IBM 2.0')
C      mov      di,bx
C      add     di,3      ; es:di -> BPB.OEM_name
C      mov     cx,4      ; for 4 words
C      cld
C      repz   cmpsw
C      jz      is_20      ; compared ok
C      ;
C      mov     si,offset NIBM_OEM      ; check alternate OEM
C      mov     di,bx
C      add     di,3
C      mov     cx,4
C      repz   cmpsw
C      jnz    not_20      ; not matched either, check for 1.1
C      ;
C      is_20:
C      mov     al, cs:save_drive      ; Get back drive number
C      mov     ah,0      ; to unsigned word
C      mul    cs:type_bpb      ; Offset in bpb_table
C      mov     di,ax      ; in an index reg
C      push  ax
C      mov     si,0      ; For copy
C      mov     cx, bpb_on_disk ; Copy this many bytes
C      copy_bpb:
```

```

0963 26: 8A 40 0B      C      mov     al, es:byte ptr [bx+si].80BytesPerSect
0967 2E: 88 85 00DB R  C      mov     cs:byte ptr bpb_table[di],al
096C 46                  C      inc     si
096D 47                  C      inc     di
096E E2 F3              C      loop   copy_bpb
C      ;
0970 5E                  C      pop     si
0971 A0 00A8 R          C      mov     al,Media_desc
0974 2E: 88 84 00E5 R  C      mov     cs:bpb_table[si].BMediaDesc,a1
0979 FE CD              C      inc     al
097B 24 7F              C      and     al,7fh                    ;keep media desc < 128
097D A2 00A8 R          C      mov     Media_desc,a1
0980 56                  C      push    si
0981                C made_bpb:
0981 2E: 88 1E 0085 R  C      mov     bx, cs:rh_off              ; Get back request header pointer
0986 2E: 8E 06 0087 R  C      mov     es, cs:rh_seg
C      ;
098B 5E                  C      pop     si                        ; Offset into bpb table
098C 8D 84 00DB R        C      lea    si, cs:bpb_table[si]      ; Address of entry
0990 26: 89 77 12      C      mov     es:bpba_ptr[bx],si       ; Stash offset in request header
0994 26: 8C 4F 14      C      mov     es:bpba_ptr+2[bx],cs     ; Stash segment in request header
C      ;
0998 B4 00              C      mov     ah, ve_ok
099A C3                  C      ret
C      ;
C      ; Come here if bpb is not 2.0 or 1.0 or if we had some error.
C      ; Error code is in ah.
C      ;
099B                C bad_bpb:
099B 2E: 88 1E 0085 R  C      mov     bx, cs:rh_off              ; Get back request header pointer
09A0 2E: 8E 06 0087 R  C      mov     es, cs:rh_seg
09A5 C3                  C      ret
C      ;
C      ; Check for 1.1 virtual parameter block. If so, convert to 2.0
C      ;
09A6                C not_20:
09A6 B9 0015            C      mov     cx, ID_Len                ; Check id
09A9 BE 0000            C      mov     si, 0
09AC                C IDLoop:
09AC 8A 84 00B9 R        C      mov     al, ID[si]
09B0 26: 3A 80 01C0    C      cmp     al, es:byte ptr [bx+si].8_ID
09B5 74 03              C      jz     ID2
09B7 E9 0A46 R          C      jmp     check_FAT                  ; Not right, try the FAT
09BA                C ID2:
09BA 46                  C      inc     si
09BB E2 EF              C      loop   IDLoop
C      ;
09BD 2E: A0 00A9 R        C      mov     al, cs:save_drive
09C1 B4 00              C      mov     ah, 0                    ; To unsigned word
09C3 2E: F7 26 00AB R  C      mul    cs:type_bpb
09C8 8B F8              C      mov     di, ax
09CA 50                  C      push   ax
C      ;
C      ; It is 1.1, convert to 2.0 format.

```

```
C ;
09CB 2E: C7 85 00DB R 0200 C ; mov cs:bpb_table[di].BBytesPerSect,200h ; Always 512
09D2 2E: C7 85 00DE R 0001 C ; mov cs:bpb_table[di].BResvSect,1 ; Always 1
C ;
09D9 26: 8A 87 01D5 C ; mov al,es:[bx].B_vpb_spc ; Copy sectors per cluster
09DE FE C0 C ; inc al ; Zynar's zformat dec's it
09E0 2E: 88 85 00DD R C ; mov cs:bpb_table[di].BSectPerClust,al
C ;
09E5 26: 8A 87 01D9 C ; mov al,es:[bx].b_vpb_nfats ; # of fats
09EA 2E: 88 85 00E0 R C ; mov cs:bpb_table[di].BFATCount,al
C ;
09EF 26: 88 87 01DA C ; mov ax,es:[bx].b_vpb_nf ; # of dir entries
09F4 2E: 89 85 00E1 R C ; mov cs:bpb_table[di].BDirEntries,ax
C ;
C ;The following computation gives an incorrect value for total number of
C ; sectors. Removed 8/9/83 by Peter L. Stahl, who wants his initials
C ; immortalized in this driver somewhere or other.
C ;
C ; mov al,es:[bx].b_vpb_spc We want # of sectors
C ; inc al which is
C ; mov ah,0 spc * ndc
C ; mul es:[bx].b_vpb_ndc
C ; cmp dx,0 If too many
C ; je not_bad_bpb error
C ; mov ah,07 unknown media
C ; jmp bad_bpb
C ;
C ;Here's how it ought to be done...
C ;
C ;Total sectors on volume = ((NDC - 1) * SPC) + DATA_SS
09F9 51 C ; push cx ; we'll use this
09FA 26: 8B 8F 01DE C ; mov cx,es:[bx].b_vpb_ndc ; # of data clusters
09FF 49 C ; dec cx ; as per formula above
0A00 26: 8A 87 01D5 C ; mov al,es:[bx].b_vpb_spc ; # of sectors per cl.
0A05 FE C0 C ; inc al ; becuz Zynar dec's it
0A07 B4 00 C ; mov ah,0 ; to get a word
0A09 F7 E1 C ; mul cx
0A0B 59 C ; pop cx
0A0C 83 FA 00 C ; cmp dx,0 ; If too many sectors,
0A0F 74 04 C ; je ok_bpb_so_far ; error:
0A11 B4 08 C ; mov ah,ve_bad_disk ; unknown media
0A13 EB 86 C ; jmp bad_bpb
C ;
C ;ok_bpb_so_far:
0A15 26: 03 87 01DC C ; add ax,es:[bx].b_vpb_data_ss ; as per formula above
0A1A 73 05 C ; jnc not_bad_bpb ; If too many sectors,
0A1C B4 08 C ; mov ah,ve_bad_disk ; error:
0A1E E9 099B R C ; jmp bad_bpb ; unknown media
C ;
C ;not_bad_bpb:
0A21 50 C ; push ax
0A22 A0 00A8 R C ; mov al,Media_desc
0A25 2E: 88 85 00E5 R C ; mov cs:bpb_table[di].BMediaDesc,al
0A2A FE C0 C ; inc al
0A2C 24 7F C ; and al,7fh ; keep media desc < 128
```



```
0A92 B4 00 C mov ah,0
0A94 2E: F7 26 00AB R C mul cs:type_bpb ; Offset into bpb_table
0A99 8B F8 C mov di,ax ; Move it so we can indirect...
0A9B 50 C push ax ; Save for returning to DOS
0A9C B9 000D C mov cx, bpb_on_disk ; Copy this many bytes
0A9F C Copy_2: ; I'm too lazy to figure the movs
0A9F 2E: 8A 04 C mov al, cs:byte ptr [si] ; Get byte from our bpb
0AA2 2E: 88 85 00DB R C mov cs:byte ptr bpb_table[di],al ; Stash in table
0AA7 46 C inc si
0AA8 47 C inc di
0AA9 E2 F4 C loop Copy_2
C ;
0AAB E9 0981 R C jmp made_bpb
C bpb1 endp
```

```

C      page
C      ;*****
C      ;*
C      ;*   DIM support
C      ;*
C      ;*   These procs support command channel handling of DIMs. Write_disk_info
C      ;*   passes us a DIM, a station address and a drive number and we set
C      ;*   that driver virtual to that station. Read_disk_info returns a
C      ;*   pointer to bpb table for the drive requested.
C      ;*
C      ;*   Registers in:
C      ;*       AH = station address
C      ;*       AL = [BPriDim, BSecDim]
C      ;*       DS:SI = Pointer to DIM.
C      ;*
C      ;*       CY set on drive out of range, clear otherwise
C      ;*
C      ;*
C      ;*   public write_disk_info
OAAE   write_disk_info proc near
OAAE   52      assume ds: nothing
OAAF   57      push dx ; Save some registers
C      ;
C      ;       push ax
OAB0   50      mov al,byte ptr [si].EDDriveNum+1 ; See who we are talking about
OAB1   BA 44 03 ; Stored in 68K integer
C      ;
OAB4   2E: 3A 06 0000 E cmp al,vp_vol_unit ; allow vp mount as a special case
OAB9   75 05 ; no, normal processing
OABB   FE C8 ; scale for table
OABD   EB 2B 90 ;
C      ;
C      ; wdi0:
OAC0   FE C8 ; FS thinks A: is 1 (in 1 .. 254)
OAC2   2E: 3A 06 001B R cmp al,our_drive ; Is it one of ours
OAC7   7C 07 ;
OAC9   2E: 3A 06 0012 R cmp al,byte ptr max_drive ; is it in range
OACE   7C 1A ;
C      ; wdi2:
OADO   2E: 3A 06 0090 R cmp al,remapped1
OAD5   74 13 ; If remapped drive, then ok
OAD7   2E: 3A 06 0091 R cmp al,remapped2
OADC   74 0C ;
OADE   2E: 3A 06 0092 R cmp al,remapped3
OAE3   74 05 ;
OAE5   58 ;
OAE6   5F ;
OAE7   5A ;
OAE8   F9 ;
OAE9   C3 ;
OAEA   C3 ;
C      ; wdi3:
OAEA   B4 00 ;
OAEF   2E: F7 26 00AB R mul type_bpb ; Offset into table
OAF1   8B F8 ;
OAF3   58 ;
C      ;
C      ;       mov ah,0
C      ;       mul type_bpb ; In an index register
C      ;       mov di,ax
C      ;       pop ax

```



```

OAF4 80 3C 01      C ;
                  C ;      cmp    [si].EDCode, MountCode      ; If it's not a mount, then...
                  C ;      bnz    wdi1                      ; ignore it.
OAF8 3C 01      C ;
OAFE 74 61      C ;      cmp    al, BPriDim                ; See if we're primary dim
                  C ;      je     wdi4                      ; Yes, off we go.
O800 50      C ;
O801 2E: 88 A5 00F0 R  C ;      push   ax
                  C ;      mov    cs: bpb_table[di].BSecFS, ah      ; Set secondary fs
O806 8A 44 04      C ;
O809 2E: 38 85 00F7 R  C ;      mov    al,[si].EDFileType
O80E 75 4C      C ;      cmp    cs:bpb_table[di].BFileType,al      ; Copy file type.
                  C ;      jne    wderr
O810 8A 44 05      C ;      mov    al,[si].EDFileSubType      ; Copy file sub type
O813 2E: 38 85 00F8 R  C ;      cmp    cs:bpb_table[di].BFileSubType,al
O818 75 42      C ;      jne    wderr
O81A 8A 44 06      C ;
O81D 2E: 38 85 00F9 R  C ;      mov    al,[si].EDAccess            ; Access
O822 75 38      C ;      cmp    cs:bpb_table[di].BAccess,al
                  C ;      jne    wderr
O824 8A 44 07      C ;
O827 2E: 38 85 00FA R  C ;      mov    al,[si].EDShr              ; share
O82C 75 2E      C ;      cmp    cs:bpb_table[di].BShr,al
                  C ;      jne    wderr
O82E 52      C ;
O82F 88 54 08      C ;      push   dx                        ; Save for div
O832 86 F2      C ;      mov    dx,word ptr [si].EDSize
O834 88 44 0A      C ;      xchg  dh,dl                        ; Bytes are swaped
O837 86 E0      C ;      mov    ax,word ptr [si].EDSize+2    ; Get size from DIM
O839 2E: F7 36 00AF R  C ;      xchg  ah,al                        ; Bytes are swaped
O83E 2E: 39 85 00E3 R  C ;      div  block_size                    ; Div by 512 (always for this)
O843 5A      C ;      cmp    cs:bpb_table[di].BSectCount,ax ; Size in blocks.
O844 75 16      C ;      pop   dx
                  C ;      jne    wderr
O846 2E: C6 85 00EE R FF  C ;
O84C 58      C ;      mov    cs:bpb_table[di].BMediaChanged, MediaChanged
O84D 58      C ;      pop   ax
O853 2E: C6 85 00F3 R 2D  C ;      mov    cs:bpb_table[di].BSecRead, NotUsedState
O859 E9 0C14 R      C ;      mov    cs:bpb_table[di].BSecWrite, WriteState
                  C ;      jmp   wdi10
O85C      C ;
O85C 58      C ;      wderr: pop   ax
O85D 5F      C ;      pop   di
O85E 5A      C ;      pop   dx
O85F F9      C ;      stc
O860 C3      C ;      ret
O861      C ;
O861 50      C ;      wdi4: push  ax
O862 2E: 88 A5 00EF R  C ;      mov    cs:bpb_table[di].BPriFS,ah      ; Set station address
O867 8A 44 04      C ;      mov    al,[si].EDFileType

```



```
OC14          C wdi10:                ; All done, return
OC14 5F      C          pop    di
OC15 5A      C          pop    dx
OC16 F8      C          cld
OC17 C3      C          ret
C          write_disk_info endp
C          ;
C          ;*      read_disk_info
C          ;*
C          ;*      Registers in
C          ;*      AL = disk number (A: = 1)
C          ;*
C          ;*      Registers out
C          ;*      CY = clear if no error, set if error
C          ;*      DS:SI = pointer to bpb
C          ;*
C          public read_disk_info
OC18          C read_disk_info proc near
OC18 C7 06 04E0 R 0000 C          assume ds:cseg
OC1E 52      C          mov    rh_status,0          ; Clear status just in case
OC1F 3A 06 0000 E C          push dx
OC23 75 05   C          cmp    al,vp_vol_unit      ; special case vp unit
OC25 FE C8   C          jne   rdi0
OC27 EB 27 90 C          dec    al          ; scale unit unumber
C          jmp    rdi2
C          ;
OC2A          C rdi0:
OC2A FE C8   C          dec    al          ; Everyone else thinks A: is 1.
OC2C 3A 06 001B R C          cmp    al,our_drive
OC30 7D 15   C          jge   rdi1
C          ;
OC32 3A 06 0090 R C          cmp    al,remapped1
OC36 74 18   C          je    rdi2
OC38 3A 06 0091 R C          cmp    al,remapped2
OC3C 74 12   C          je    rdi2
OC3E 3A 06 0092 R C          cmp    al,remapped3
OC42 74 0C   C          je    rdi2
C          ;
OC44 5A      C          pop    dx
OC45 F9      C          stc
OC46 C3      C          ret          ; Not one of ours, tell caller
OC47          C rdi1:
OC47 3A 06 0012 R C          cmp    al,byte ptr max_drive ; See if above us
OC4B 7C 03   C          jl    rdi2
C          ;
OC4D 5A      C          pop    dx
OC4E F9      C          stc
OC4F C3      C          ret
C          ;
C          ; AL is disk drive with A: = 0
C          ;
C          ;
OC50          C rdi2:
OC50 50      C          push   ax
```

```
0C51 B4 00      C      mov     ah,0
0C53 F7 26 00AB R C      mul     type_bpb
0C57 8B F0      C      mov     si,ax
0C59 58          C      pop     ax          ; Get it back
C
C      :--comment out so that ?drive does not clear MediaChanged flag in BPB.
C      :
C      :   push     ax
C      :
C      :   cmp     byte ptr bpb_table[si].BMediaChanged,MediaNotTouched
C      :   jz      rdi4          ; if media not touched then bpb must be ok
C      :
C      :   push     si          ; Save our register
C      :
C      :   cmp     al,our_drive
C      :   jge     rdi5
C      :   add     al,0COH
C      :   jmp     short rdi6
C      :rdi5: sub     al,our_drive
C      :
C      :rdi6:
C      :   mov     rh_unit_code,al ; Set unit number
C      :
C      :   mov     word ptr rh_buffer,offset bpb_buffer
C      :   mov     ax,cs          ; Get segment for buffer
C      :   mov     word ptr rh_buffer+2,ax
C      :
C      :   push     es
C      :
C      :   push     cs
C      :   pop     es
C      :
C      :   push     bx
C      :
C      :   mov     bx,es          ; Set our pointer to the request header
C      :   mov     rh_seg,bx
C      :   mov     bx,offset rh_len
C      :   mov     rh_off,bx
C      :
C      :   push     ds
C      :   push     es
C      :   push     ax
C      :   push     bx
C      :   push     cx
C      :   push     dx
C      :   push     di
C      :   push     si
C      :   push     bp
C      :
C      :   call    real_build_bpb
C      :
C      :   pop     bp
C      :   pop     si          ;restore all of the registers
C      :   pop     di
C      :   pop     dx
```

```
C ;      pop    cx
C ;      pop    bx
C ;      pop    ax
C ;      pop    es
C ;      pop    ds
C ;      pop    bx
C ;      pop    es
C ;      pop    si
C ;
C ;rdi4:
C ;      pop    ax
C ;-----
OC5A 5A      pop    dx
OC5B 8D B4 00DB R      lea    si,bpb_table[si]
C ;
C ;---don't check for error since real_build_bpb wasn't called
C ;      test   rh_status,8000H      ; An error occurred
C ;      jz     rdi3
C ;
C ;      cmp    al,8
C ;      jne    rdi3
C ;      mov    [si].BFileType,' '      ; If nothing mounted then tell 'em
C ;rdi3:
C ;-----
OC5F F8      clc
OC60 C3      ret
C read_disk_info endp
```

```
C      page
C      ;*****
C      ;*
C      ;*      Get_file_server
C      ;*
C      ;*      Get the file server. Return in dh. No other regs
C      ;*      touched (except flags).
C      ;*
OC61  get_file_server proc    near
OC61  8A 36 00AA R      mov     dh, io_fs
OC65  C3                ret
C      get_file_server endp
C
C      ;*
C      ;*      get_drive
C      ;*      Convert DOS unit number to logical drive number (a=0, b=1, etc)
C      ;*      We change to floppy/hard disk look alike set up by boot program
C      ;*      to range CO+logical drive number. Unit numbers come in the range
C      ;*      0 .. n, and are relative to the variable our_drive which is
C      ;*      set at init time.
C      ;*
OC66  get_drive      proc    near
OC66  26: 8A 47 01    mov     al, es:[bx].srh_ucd_fld
OC6A  3C C0          cmp     al, 0COH
OC6C  72 04          jb     gd1
OC6E  2C C0          sub     al, 0COH
OC70  EB 04          jmp     short gd2
OC72  gd1:          add     al, our_drive
OC72  02 06 001B R    gd2:
OC76  C3                ret
C      get_drive      endp
C      ;
C
C      %OUT      .....VDISK_MISCELLANEOUS
C      include  vdmisc.asm      ;miscellaneous routines
C
C      subttl  vdisk_miscellaneous
```

```
C          page
C
C          get_tod      proc      near
OC77      50          push      ax
OC78      2E: A1 0094 R  mov      ax,cs:int_la_1      ;calculate an "int la"
OC7C      05 1E2B      add      ax,int_la_2
OC7F      D1 F8          sar      ax,1      ;int la is cd, la is lacd is
OC81      2E: A3 OCD7 R  mov      cs:int_ins,ax      ; is 6861 is (5999+7723) div 2
OC85      E8 OCD4 R      call     do_int_la          ;keep funny code a little out of sight
C          ;must have cd:la in al:ah
C          mov      cs:int_ins,int_la_2/3 ;wipe out "int la"
OC88      2E: C7 06 OCD7 R OAOE  pop      ax
OC8F      58          ret
OC90      C3          get_tod      endp
C
C          -----
C          ;
C          ; Produce a half click - changes flags.
C          ; V5
C          ;
C          -----
C
C          public      half_click
OC91      50          half_click  proc      near      ; toggles speaker port
C          push      ax
C
C          else          ; not for_z120
OC92      E4 61          in      al,spkr_port
OC94      33 06 0014 R  xor      ax,click_on      ; if off, no change to spkr_port
OC98      24 FE          and     al,0FEh          ; not timer gate
OC9A      E6 61          out     spkr_port,al
C          endif          ; for_z120
C
C          pop      ax
OC9C      58          ret
OC9D      C3          half_click  endp
C
C          ;----- old code -----
C          ;save_port  db      ?          ; Save status of port here.
C          ;
C          ;start_noise  proc      near
C          ;          push     ax          ;save needed regs
C          ;          cmp      click_on,0 ;noise or not
C          ;          je      no_click_start ;jump if no
C          ;          mov     al,10110110b ;program timer two
C          ;          out     timer_ctrl,al
C          ;          mov     ax,15000    ;divide for approx 80hz
C          ;          out     timer_two,al ;which is quite discreet
C          ;          mov     al,ah
C          ;          out     timer_two,al
C          ;          in      al,spkr_port ;remember state of i/o port
C          ;          mov     save_port,al
C          ;          or      al,3      ;enable both speaker gates
C          ;          out     spkr_port,al
C          ;no_click_start:
```

```
C ;      pop      ax
C ;      ret
C ;start_noise  endp
C ;
C ;end_noise    proc  near
C ;              push  ax
C ;              cmp   click_on,0    ;noise or not
C ;              je   no_click_stop ;jump if no
C ;              mov  al,save_port
C ;              out  spkr_port,al
C ;no_click_stop:
C ;              pop  ax
C ;              ret
C ;end_noise    endp
```



```
C      page
C      ;-----
C      ;
C      ; setiobsw enables special iobs for reading from "execute only" volumes
C      ; al:special iob function code to use
C      ; ah:drive letter (in ascii, capital letter) to permit special iob's on
C      ; cx:duration of permission in ticks of 18.2 per second
C      ;
C      ;
C      ; setiobsw      proc      far
C      ;                push     ax
C      ;                sub      ah,'A'
C      ;                sub      ah,cs:our_drive
C      ;                mov      cs:special_drive,ah
C      ;                mov      cs:iob_switch,al
C      ;                mov      cs:iob_timeout,cx
C      ;                call     set_end_special
C      ;                pop      ax
C      ;                ret
C      ;
C      ; setiobsw      endp
C      ;
C      ; set_end_special proc      near
C      ;                push     cx                ;free up some regs.
C      ;                push     dx
C      ;                call     get_tod          ;get tod in cx:dx
C      ;                add      dx,cs:iob_timeout ;calculate expiration time of
C      ;                adc      cx,0            ; special iob state
C      ;                mov      cs:end_special_lo,dx ;set low time
C      ;                mov      cs:end_special_hi,cx ;set high time
C      ;                pop      dx
C      ;                pop      cx
C      ;                ret
C      ;
C      ; set_end_special endp
C      ;
C      ; do_int_la      proc      near
C      ;                add      ah,-lah          ;convert the la in ah to zero
C      ;                int_ins   dw      ?      ;an "int la" tod call is built here
C      ;                not      ax             ;does nothing useful, just adds
C      ;                ; to the confusion
C      ;                ret
C      ;
C      ; do_int_la      endp
C
C      %OUT      .....VDISK_INITIALISATION
C      include  vdinit.asm                ;initialisation
C
C      subttl  vdisk_initialization
```

```
C                                     page
C
C ;*****
C ;
C ;   init
C ;
C ;       6/26/85      cwp      Moved allocation of additional rb's to 14_init.
C ;       10/24/85     gkn      Added conditional assembly to support Zenith 120
C ;       12/31/85     gkn      Fixed SR5 bug for setting the number of drives to
C ;                               less than the REAL number.
C ;
C
= OCDC                                C bpb_buffer      equ      $           ; Start of initialization code.
= 0000                                C Trace equ      0
C
OCDC                                  C init_vdisk:
OCDC C7 06 0098 R 0000 E              C     mov      my_end, offset driver_end      ; Init this here
C ;
C ;Here we correct a bug in the pc rom bios. The bug is that int 10h,
C ;function 3 (read cursor position & type) returns the value for a color
C ;monitor cursor regardless of whether a color or monochrome monitor is
C ;being used, unless the cursor has been previously set using int 10h,
C ;function 1. The fix, of course, is to set the cursor explicitly. So
C ;we do an equipment determination, then set the cursor accordingly.
OCE2                                  C set_curs:
C                                     C     ife      for_z120
OCE2 50                               C     push    ax
OCE3 CD 11                             C     int     11h           ;equipment determination--
C                                     C     ; takes no input parameters
C                                     C     and     al,30h       ;bits 4 & 5 on means monochrome--
OCE5 24 30                             C     cmp     al,30h       ; anything else is color.
OCE7 3C 30                             C     jnz    color_mon    ;process only if monochrome
OCE9 75 0F                             C     push   cx
OCEB 51                               C     push   si           ;these three destroyed by int 10h
OCEC 56                               C     push   di
OCEE 55                               C     push   bp
OCEF B9 0C0D                           C     mov    cx,0c0dh     ;monochrome cursor
OCF2 B4 01                             C     mov    ah,1        ;set cursor
OCF4 CD 10                             C     int   10h          ;video
OCF6 5D                               C     pop    bp
OCF7 5F                               C     pop    di
OCF8 5E                               C     pop    si
OCF9 59                               C     pop    cx
OCFA                                  C color_mon:
OCFA 58                               C     pop    ax
C                                     C     endif   ; for_z120
C
OCFB E8 0E33 R                          C     call   vdisk_init
OCFE E8 0D5A R                          C     call   FindDrive   ; Find out what outside world thinks we are.
C ;
C ;   write 'Return from find drive. Our drive is '
C ;   writebyte our_drive
C ;   writeln ' '
C ;
OD01 E8 0000 E                          C     call   14_init     ; Go forth and intilize level 4.
```



```
C      page
C      *****
C      ;
C      ; FindDrive. FindDrive first finds the offset of our drive by
C      ; looking at the drive parameter blocks for each of the drives
C      ; until we find one that returns not there (OFFH). This value
C      ; is stored in variable our_drives. We then check the int13_loaded
C      ; flag to see if we just loaded int 13. If we did, we're done.
C      ; If not, then we must remap the drives mapped by int13 from
C      ; the default drivers to our own.
C      ;
C      ; "Piece of cake, trust me."
C      ; S. Dillion, 1984
C      ;
C      FindDrive proc near
C      OD5A mov ah, DOS_VERS
C      OD5C CD 21 ; See what version we looking at
C      ;
C      OD5E cmp al, 3 ; AL contains major version
C      OD60 JB fd10 ; Not DOS 3.x, process old way
C      ;
C      OD62 push es
C      OD63 mov es, rh_seg ; Get request block
C      OD67 mov bx, rh_off
C      OD6B mov dl, es:[bx].IOurDrive ; Get unit count
C      ;
C      OD6F mov ah, GET_IN_VARS ; Get pointer to internal vars
C      OD71 int 21H ; Do it.
C      OD73 jmp short fd20
C      ;
C      fd10:
C      OD75 push es
C      OD75 mov ah, GET_IN_VARS ; Get pointer to internal vars
C      OD76 int 21H ; Do it.
C      OD78 CD 21
C      ;
C      ; es:bx now points to DOS variables. We use two fields:
C      ; last_drive, which at this point in the DOS initialization
C      ; process is the index of the last drive installed by
C      ; the previous driver; and dpb_chain which is the chain
C      ; of disk paramter blocks used by DOS to map from DOS
C      ; drive letter to driver address, driver drive number.
C      ;
C      OD7A mov dx, es:[bx].last_drive ; Number of drives in system
C      OD7E fd20:
C      OD7E mov our_drive, dl ; Stash it
C      OD7E write 'Drive at offset '
C      OD82 mov dh, 0
C      writeint dx
C      writeln ' '
C      ;
C      ; Remap DOS drivers for floppies mapped by boot program.
C      ; We need to check floppies A and B and the hard disk
C      ; whose drive we need to detirmine. This remapping is
```

```

C ; done by three steps, first setting the remapped variable
C ; to the DOS drive number (A:=0), second setting the
C ; dpb driver address to point to ourseleves, and third
C ; setting the dpb_UNIT field to the drive number + 0COH.
C ; Final values of remapped are:
C ;
C ; remapped1 = 0 if A: is mapped virtual, OFFH if not
C ; remapped2 = 1 if B: is mapped virtual, OFFH if not
C ; remapped3 = drive number for hard disk (C:=2) if mapped.
C ;
0D84 C6 06 0090 R FF      mov     remapped1,OFFH      ; Nothing remapped
0D89 C6 06 0091 R FF      mov     remapped2,OFFH      ; Nothing remapped
0D8E C6 06 0092 R FF      mov     remapped3,OFFH      ; Nothing remapped
C ;
C ; First check the floppies, if A: is not mapped, we
C ; skip B:. If A: is mapped, we remap it for the driver
C ; and check B:
C ;
0D93 B4 F1                mov     ah, 0F1H           ; Get drive mapping
0D95 80 00                mov     al, 0              ; Floppy drive 0
0D97 CD 13                int     13H                ; Do it
C ;
0D99 80 FA C0             cmp     dl,0COH            ; Is it mapped to network?
0D9C 72 40                jb     fd30                ; No
0D9E 80 FA FF             cmp     dl,OFFH           ; Is it not mapped
0DA1 74 3B                je     fd30                ; Yes
C ;
0DA3 06                  push   es
0DA4 53                  push   bx
0DA5 C6 06 0090 R 00       mov     remapped1, 0H
0DAA 26: C4 37           les     si, es:dword ptr [bx].dpb_chain ; Get pointer to entry for 0
0DAD 26: C6 44 01 C0       mov     es:[si].dpb_UNIT, 0COH
0DB2 26: 8C 4C 14         mov     es:[si].dpb_driver_addr.segp,cs
0DB6 26: C7 44 12 0000    mov     es:[si].dpb_driver_addr.off, 0
C ;
0DBC CD 11                int     11H
0DBE A8 01                test    al, 1              ; Is there a floppy in sys
0DC0 75 1A                jne    fd25                ; Yes, go on
C ;
0DC2 26: C4 74 18         les     si, es:[si].dpb_next_dpb      ; dpb for drive b:
0DC6 FE C2                inc     dl                  ; For drive b:
0DC8 C6 06 0091 R 01       mov     remapped2, 1H      ; second remapping
0DCD 26: C6 44 01 C1       mov     es:[si].dpb_UNIT, 0C1H
0DD2 26: 8C 4C 14         mov     es:[si].dpb_driver_addr.segp,cs
0DD6 26: C7 44 12 0000    mov     es:[si].dpb_driver_addr.off, 0
C ;
0DDC fd25:                pop     bx
0DDC 5B                  pop     es
0DDD 07

```

```

C      ;      page
C      ;
C      ;      Remap DOS drivers for hard disk mapped by boot program.
C      ;      We first see if drive 80 is mapped virtual.  If it is
C      ;      then we need to see what DOS drive the hard disk is mapped
C      ;      in as.  Note that we assume the IBM PC DOS ordering of
C      ;      floppies followed by hard disks.
C      ;
C      ;      fd30:
OODE   ;
OODE   84 F1      ;      writeIn 'Try drive 2'
ODE0   80 80      mov     ah,0F1H      ;      Get drive mapping
ODE2   CD 13      mov     al,80H       ;      Hard disk 0
C      ;      int     13H          ;      Do it
C      ;
C      ;      write 'returned '
C      ;      writebyte     dl
C      ;      writeIn ' '
C      ;
ODE4   80 FA FF      cmp     dl,OFFH     ;      Is it not mapped
ODE7   74 05      je      fd33       ;      Yes
ODE9   80 FA C0     cmp     dl,0C0H    ;      Is it mapped to network?
ODEC   77 03      ja      fd35       ;      No
ODEE   EB 41 90     fd33:  jmp     fd80
C      ;
C      ;      Get the number of floppies from the switches.  Note
C      ;      the special rules in the case of 0 and 1 floppies.
C      ;
C      ;      fd35:
ODF1   CD 11      int     11H        ;      Equipment detirmination
ODF1   ;      write 'Equip returns '
C      ;      writeint     ax
C      ;      writeIn ' '
C      ;
C      ;      test     al,1          ;      Is there no drive?
ODE3   A8 01      jne     fd40
ODE5   75 04      mov     ah,2       ;      DOS thinks minimum 2
ODE7   B4 02      jmp     short fd50
ODE9   EB 12      ;
ODEB   ;      fd40:
ODEB   8A E0      mov     ah,al
ODED   80 E4 C0     and     ah,0C0H    ;      Get top two bits
OE00   B1 06      mov     cl,6       ;      6 bits
OE02   D2 EC      shr     ah,cl
OE04   FE C4      inc     ah
OE06   80 FC 02     cmp     ah,2
OE09   73 02      jae     fd50
OE0B   B4 02      mov     ah,2
OE0D   ;      fd50:
OE0D   ;      write ' Floppies = '
OE0D   ;      writebyte     ah
OE0D   ;      writeIn ' '
C      ;
C      ;
C      ;      We now walk down the dpb chain to find the dpb for the
```

```
C ; hard disk. AH contains the number of floppies.
C ;
OE0D 26: C4 37 C les si, es:dword ptr [bx].dpb_chain ; Get pointer to entry for 0
OE10 8A CC C mov cl, ah
OE12 32 ED C xor ch, ch ; Convert count to 16 bits
C ;
OE14 26: C4 74 18 C fd60: les si, es:[si].dpb_next_dpb ; Get hard disk dpb
OE18 E2 FA C loop fd60
C ;
C write 'Dpb = '
C writeint es
C write ':'
C writeint si
C writeln ''
C ;
C ; Finally there, so remap it. We assume only one hard
C ; disk is mapped to be virtual. A real hard disk
C ; can still be mapped from 81H to 80H. AH still contains
C ; the number of floppies.
C ;
OE1A 8A D4 C mov dl, ah
OE1C 80 C2 C0 C add dl, 0COH ; Calculate correct unit number
C ;
OE1F 26: 88 54 01 C mov es:[si].dpb_UNIT, dl
OE23 26: 8C 4C 14 C mov es:[si].dpb_driver_addr.segp, cs
OE27 26: C7 44 12 0000 C mov es:[si].dpb_driver_addr.off, 0
OE2D 88 26 0092 R C mov remapped3, ah ; Drive number of remapped drive
C ;
OE31 fd80: C pop es
OE31 07 C ret
OE32 C3 C FindDrive
C endp
```

```
C      page
C      -----
C      This is the initialisation code for Vdisk. It is responsible for :
C      1. initialising vdisk's internal drive and address tables, and the internal
C      vdisk variables.
C      -----
C
C      vdisk_init      proc      near
C      vdisk_init_label:
C
C          push      ax
C          push      bx
C          push      cx
C          push      si
C          push      di
C          push      ds
C          push      es
C          push      cs
C          pop       ds
C          assume   ds:cseg
C
C          write    'In init '
C          writeint      cs
C          writeln    ' '
C
C      ;
C      ; Initialize the bpb table and the bpb pointer table.
C      ;
C          mov     cx, length bpb_table
C          mov     si,0
C          mov     di,0
C          ; init all bpb's
C      V5_bpb_loop:
C      ;
C          lea    ax,bpb_table[si]
C          mov    bpb_ptr_table[di],ax
C          ; Set pointer table
C
C      ;
C      ; Initlize bpb to look like a double sided floppy.
C      ;
C          mov     word ptr bpb_table[si].BBytesPerSect,200H
C          mov     byte ptr bpb_table[si].BSectPerClust,2
C          mov     word ptr bpb_table[si].BResvSect,1
C          mov     byte ptr bpb_table[si].BFAtCount,2
C          mov     word ptr bpb_table[si].BDirEntries,70H
C          mov     word ptr bpb_table[si].BSectCount,2d0H
C          mov     byte ptr bpb_table[si].BMediaDesc,0FCh
C          mov     word ptr bpb_table[si].BFATSize,2
C          mov     word ptr bpb_table[si].BSectsPerTrack,9
C          mov     word ptr bpb_table[si].BHeadCount,2
C          mov     word ptr bpb_table[si].BHiddenSects,0
C          mov     byte ptr bpb_table[si].BMediaChanged,LOW MediaChanged
C
C      0E33      50
C      0E34      53
C      0E35      51
C      0E36      56
C      0E37      57
C      0E38      1E
C      0E39      06
C      0E3A      0E
C      0E3B      1F
C
C      0E3C      89 001A
C      0E3F      BE 0000
C      0E42      BF 0000
C      0E45
C
C      0E45      8D 84 00DB R
C      0E49      89 85 041B R
C
C      0E4D      C7 84 00DB R 0200
C      0E53      C6 84 00DD R 02
C      0E58      C7 84 00DE R 0001
C      0E5E      C6 84 00E0 R 02
C      0E63      C7 84 00E1 R 0070
C      0E69      C7 84 00E3 R 02D0
C      0E6F      C6 84 00E5 R FC
C      0E74      C7 84 00E6 R 0002
C      0E7A      C7 84 00E8 R 0009
C      0E80      C7 84 00EA R 0002
C      0E86      C7 84 00EC R 0000
C      0E8C      C6 84 00EE R FF
```



```
OE91 C6 84 00EF R FE C      mov     byte ptr bpb_table[si].BPriFS, 0FEH
OE96 C6 84 00F0 R 00 C      mov     byte ptr bpb_table[si].BSecFS, 0
OE9B C6 84 00F1 R 52 C      mov     byte ptr bpb_table[si].BPriRead, ReadState
OEAO C6 84 00F2 R 57 C      mov     byte ptr bpb_table[si].BPriWrite, WriteState
OEA5 C6 84 00F3 R 2D C      mov     byte ptr bpb_table[si].BSecRead, NotUsedState
OEAA C6 84 00F4 R 2D C      mov     byte ptr bpb_table[si].BSecWrite, NotUsedState
OEA0 C6 84 00F5 R 00 C      mov     byte ptr bpb_table[si].BPriErr, ve_ok
OEB4 C6 84 00F6 R 00 C      mov     byte ptr bpb_table[si].BSecErr, ve_ok
OEB9 C6 84 00F7 R 20 C      mov     byte ptr bpb_table[si].BFileType, ' '
OEBE C6 84 00F8 R 20 C      mov     byte ptr bpb_table[si].BFileSubType, ' '
OEC3 C6 84 00F9 R 00 C      mov     byte ptr bpb_table[si].BAccess, 0
OEC8 C6 84 00FA R 00 C      mov     byte ptr bpb_table[si].BShr, 0
C      ;
OEDC 83 C6 20 C      add     si, type bpb
OEDO 83 C7 02 C      add     di, type bpb_ptr_table
OED3 49 C      dec     cx
OED4 74 03 C      jz     V5_ja
OED6 E9 0E45 R C      jmp    V5_bpb_loop
OED9 C      V5_ja:
C
C
C      writeln 'End init'
C
OED9 07 C      pop     es ;restore the original registers
OEDA 1F C      pop     ds
OEDB 5F C      pop     di
OEDC 5E C      pop     si
OEDD 59 C      pop     cx
OEDE 5B C      pop     bx
OEDF 58 C      pop     ax
C
OEE0 C3 C      ret
C
C      vdisk_init endp
C
C      endif
C
OEE1 CSEG ends
C
end
```

Macros:

Name	Lines
BNZ	3
FLIP	1
LCALL	2
STATUS	15
WRITE	9
WRITEBYTE	6
WRITEINT	6
WRITELN	9

Structures and Records:

Name	Width Shift	# fields Width Mask	Initial
BLOCK0	001E	0000	
BOJUMP	0000		
BOOEM	0003		
BOBYTESPERSECT	0008		
BOSECTPERCLUST	000D		
BORESVSECT	000E		
BOFATCOUNT	0010		
BODIRENTRIES	0011		
BOSECTCOUNT	0013		
BOMEDIADESC	0015		
BOFATSIZE	0016		
BOSECTSPERTRACK	0018		
BOHEADCOUNT	001A		
BOHIDDENSECTS	001C		
BOOT_RECORD	0200	000C	
B_CODE	0000		
B_ID	01C0		
B_VPB_SPC	01D5		
B_VPB_CSF	01D6		
B_VPB_VOL_SS	01D7		
B_VPB_NFATS	01D9		
B_VPB_NF	01DA		
B_VPB_DATA_SS	01DC		
B_VPB_NDC	01DE		
B_VPB_SPF	01E0		
B_VPB_DIR_SS	01E1		
B_FILLER	01E3		
BPB	0020	0018	
BBYTESPERSECT	0000		
BSECTPERCLUST	0002		
BRESVSECT	0003		
BFATCOUNT	0005		
BDIRENTRIES	0006		
BSECTCOUNT	0008		
BMEDIADESC	000A		
BFATSIZE	000B		

BSECTSPERTRACK	000D	
BHEADCOUNT	000F	
BHIDDENSECTS	0011	
BMEDIACHANGED	0013	
BPRIFS	0014	
BSECFs	0015	
BPRIREAD	0016	
BPRIWRITE	0017	
BSECREAD	0018	
BSECWRITE	0019	
BPRIERR	001A	
BSECERR	0018	
BFILETYPE	001C	
BFILESUBTYPE	001D	
BACCESS	001E	
BSHR	001F	
BUILD_BPb_RH	0016	0004
BPBRH	0000	
BPBMEDIADESC	0000	
BPBTEMPBUFFER	000E	
BPBPPBPOINTER	0012	
DPB	005E	0012
DPB_DRIVE	0000	
DPB_UNIT	0001	
DPB_SECTOR_SIZE	0002	
DPB_CLUSTER_MASK	0004	
DPB_CLUSTER_SHIFT	0005	
DPB_FIRST_FAT	0006	
DPB_FAT_COUNT	0008	
DPB_ROOT_ENTRIES	0009	
DPB_FIRST_SECTOR	0008	
DPB_MAX_CLUSTER	000D	
DPB_FAT_SIZE	000F	
DPB_DIR_SECTOR	0010	
DPB_DRIVER_ADDR	0012	
DPB_MEDIA	0016	
DPB_FIRST_ACCESS	0017	
DPB_NEXT_DPB	0018	
DPB_CURRENT_DIR	001C	
DPB_DIR_TEXT	001E	
ETNA_DIM	0012	0009
EDCODE	0000	
EDSUBCODE	0001	
EDDRIVENUM	0002	
EDFILETYPE	0004	
EDFILESUBTYPE	0005	
EDACCESS	0006	
EDSHR	0007	
EDSIZE	0008	
EDFILLER	000C	
INIT_RH	0017	0005
IRH	0000	
IUNITCOUNT	000D	
IDRIVEREND	000E	

IBPBARRAY	0012	
IOURDRIVE	0016	
POINTER	0004	0002
OFF	0000	
SEGP	0002	
REQUEST_HEADER	0000	0005
RHLENGTH	0000	
RHUNIT	0001	
RHCOMMANDCODE	0002	
RHSTATUS	0003	
RHDOSRESV	0005	

Segments and Groups:

Name	Size	Align	Combine	Class
CSEG	0EE1	PARA	PUBLIC	'CODE'

Symbols:

Name	Type	Value	Attr
ALLOC_MORE_RBS	L NEAR	0000	CSEG External
ALT222	L WORD	0020	CSEG Global
ATTRIBUTE	L WORD	0004	CSEG
BAD_BPB	L NEAR	099B	CSEG
BIOS_ERROR	L BYTE	04CF	CSEG
BLOCK_SIZE	L WORD	00AF	CSEG
BPB1	N PROC	08FD	CSEG Length = 01B1
BPBA_PTR	Number	0012	
BPBA_PTR_LEN	Number	0004	
BPB_BUFFER	NEAR	0CDC	CSEG
BPB_ON_DISK	Number	0000	
BPB_PTR_OFF	Number	0012	
BPB_PTR_SEG	Number	0014	
BPB_PTR_TABLE	L WORD	041B	CSEG Length = 001A
BPB_TABLE	L WORD	00DB	CSEG Length = 001A
BPRIDIM	Number	0001	
BREAK_CALL	Number	0018	
BR_ADDR_0	Number	000E	
BR_ADDR_1	Number	0010	
BR_ADDR_LEN	Number	0004	
BSECDIM	Number	0002	
BUILD_BPB	L NEAR	05E0	CSEG
BYTES_PER_SECTOR	L WORD	00AD	CSEG
CANCEL_SPECIAL	L NEAR	0573	CSEG
CHECK_FAT	L NEAR	0A46	CSEG
CLICK_ON	L WORD	0014	CSEG Global
CODE_LEN	Number	01C0	
COLOR_MON	L NEAR	0CFA	CSEG
COMPSTATE	Number	0043	
CONTROL_WORD	L WORD	009A	CSEG

COPY_2	L NEAR	0A9F	CSEG	
COPY_BPB	L NEAR	0963	CSEG	
COPY_FAT_BPB	L NEAR	0A8E	CSEG	
COUNT	Number	0012		
COUNT_LEN	Number	0002		
DB_FLAG	L BYTE	001A	CSEG	Global
DEF_MAX_DRIVE	Number	001A		
DEV_INT	L NEAR	0518	CSEG	
DEV_NAME	L BYTE	000A	CSEG	
DEV_STRATEGY	L NEAR	050D	CSEG	
DIRSTRLEN	Number	0040		
DISKIO_CALL	Number	0013		
DOTO	L NEAR	079A	CSEG	
DOS_BUILD_BPB	Number	0002		
DOS_DISK_ENTRY_SIZE	Number	005E		
DOS_INIT	Number	0000		
DOS_IN_FLUSH	Number	0007		
DOS_IN_STATUS	Number	0006		
DOS_IOCTL_IN	Number	0003		
DOS_IOCTL_OUT	Number	000C		
DOS_MEDIA_CHECK	Number	0001		
DOS_OUTPUT	Number	0008		
DOS_OUT_FLUSH	Number	000B		
DOS_OUT_STATUS	Number	000A		
DOS_OUT_VERIFY	Number	0009		
DOS_READ	Number	0004		
DOS_READ_NOWAIT	Number	0005		
DOS_VERS	Number	0030		
DOUBLE_9_BPB	L 0020	04AF	CSEG	
DD_FUNCTION	L NEAR	0578	CSEG	
DD_INT_1A	N PROC	0CD4	CSEG	Length = 0008
DPBSIZ	Number	005E		
DPB_CHAIN	Number	0000		
DRIVERS_CHAIN	Number	0017		
DRIVER_BUSY	L BYTE	0083	CSEG	Global
DRIVER_END	L NEAR	0000	CSEG	External
DTA	Number	000E		
DTA_LEN	Number	0004		
END_SPECIAL_HI	L WORD	008E	CSEG	
END_SPECIAL_LO	L WORD	008C	CSEG	
EQUIP_CALL	Number	0011		
EXIT	L NEAR	0588	CSEG	
FALSE	Number	0000		
FD10	L NEAR	0D75	CSEG	
FD20	L NEAR	0D7E	CSEG	
FD25	L NEAR	0DDC	CSEG	
FD30	L NEAR	0DDE	CSEG	
FD33	L NEAR	0DEE	CSEG	
FD35	L NEAR	0DF1	CSEG	
FD40	L NEAR	0DFB	CSEG	
FD50	L NEAR	0E0D	CSEG	

FD60	L NEAR 0E14	CSEG	
FD80	L NEAR 0E31	CSEG	
FINDDRIVE	N PROC 0D5A	CSEG	Length = 00D9
FOR_Z120	Number 0000		
FUNTAB	L BYTE 04F3	CSEG	
GD1	L NEAR 0C72	CSEG	
GD2	L NEAR 0C76	CSEG	
GET_DRIVE	N PROC 0C66	CSEG	Length = 0011
GET_FILE_SERVER	N PROC 0C61	CSEG	Length = 0005
GET_IN_VARS	Number 0052		
GET_TOD	N PROC 0C77	CSEG	Length = 001A
HALF_CLICK	N PROC 0C91	CSEG	Global Length = 000D
I1	L NEAR 0725	CSEG	
I2	L NEAR 0757	CSEG	
I3	L NEAR 0748	CSEG	
I4	L NEAR 077D	CSEG	
I5	L NEAR 071D	CSEG	
I6	L NEAR 0740	CSEG	
ID	L BYTE 00B9	CSEG	
ID2	L NEAR 09BA	CSEG	
IDLOOP	L NEAR 09AC	CSEG	
ID_LEN	Number 0015		
INI	L NEAR 078C	CSEG	
INIT_VDISK	L NEAR 0CDC	CSEG	
INPUT	L NEAR 06E5	CSEG	
INTERRUPT	L WORD 0008	CSEG	
INT_1A_1	L WORD 0094	CSEG	
INT_1A_2	Number 1E2B		
INT_INS	L WORD 0CD7	CSEG	
IN_FLUSH	L NEAR 05E5	CSEG	
IN_LIMIT	L NEAR 07DF	CSEG	
IN_STAT	L NEAR 05E5	CSEG	
IOB_INIT	Number 0004		
IOB_READ	Number 0001		
IOB_SPECIAL	Number 0003		
IOB_SWITCH	L BYTE 0089	CSEG	
IOB_TIMEOUT	L WORD 008A	CSEG	
IOB_WRITE	Number 0002		
IOCTL_IN	L NEAR 05E5	CSEG	
IOCTL_OUT	L NEAR 05E5	CSEG	
IO_FS	L BYTE 00AA	CSEG	
IO_LIMIT	Number 0020		
IO_RETURN	L NEAR 07E8	CSEG	
IS_20	L NEAR 094F	CSEG	
KBDIO_CALL	Number 0016		
L4_INIT	L NEAR 0000	CSEG	External
L4_VARS	V DWORD 0000	CSEG	External
LAST_DRIVE	Number 0010		

MADE_BPB	L NEAR 0981	CSEG	
MAP_INT	Number 00FD		
MARKER	L BYTE 00CE	CSEG	
MAX_DRIVE	L WORD 0012	CSEG	
MC1	L NEAR 05CE	CSEG	
MD	Number 000D		
MD_LEN	Number 0001		
MEDIACHANGED	Number -0001		
MEDIADONTKNOW	Number 0000		
MEDIANOTTOUCHED	Number 0001		
MEDIA_CHECK	L NEAR 05B3	CSEG	
MEDIA_DESC	L BYTE 00A8	CSEG	
MORE_RBS	L WORD 001C	CSEG	Global
MOUNTCODE	Number 0001		
MY_END	L WORD 0098	CSEG	Global
NC_HEAD	L NEAR 0000	CSEG	External
ND_INPUT	L NEAR 05E5	CSEG	
NEXT_DEV	L WORD 0000	CSEG	
NIBM_OEM	L BYTE 00D3	CSEG	
NIL	Number 0000		
NOPCODE	Number 0000		
NORMAL_BPB	L NEAR 0908	CSEG	
NORMAL_FAT	L NEAR 0A51	CSEG	
NORMAL_INPUT	L NEAR 0797	CSEG	
NOTBUSY	L NEAR 0554	CSEG	
NOTHING_TO_DO	L NEAR 07E8	CSEG	
NOTMOUNTEDTYPE	Number 002D		
NOTUSEDSTATE	Number 002D		
NOT_20	L NEAR 09A6	CSEG	
NOT_BAD_BPB	L NEAR 0A21	CSEG	
02	L NEAR 0682	CSEG	
03	L NEAR 0691	CSEG	
04	L NEAR 0680	CSEG	
05	L NEAR 0657	CSEG	
06	L NEAR 067D	CSEG	
OEM_NAME	L BYTE 00B1	CSEG	
OK_BPB_SO_FAR	L NEAR 0A15	CSEG	
OK_DR	L NEAR 0D20	CSEG	
OLD_11_VECTOR	L DWORD 00A0	CSEG	
OLD_13_VECTOR	L DWORD 009C	CSEG	
OLD_1B_VECTOR	L DWORD 00A4	CSEG	
OUR_DRIVE	L BYTE 001B	CSEG	Global
OUT1	L NEAR 06BF	CSEG	
OUT2	L NEAR 06E4	CSEG	
OUTPUT	L NEAR 060F	CSEG	
OUT_FLUSH	L NEAR 05E5	CSEG	
OUT_STAT	L NEAR 05F9	CSEG	
OUT_VERIFY	L NEAR 060F	CSEG	
PRINT_BYTE	L NEAR 0000	CSEG	External
PRINT_CHAR	L NEAR 0000	CSEG	External
PRINT_CRLF	L NEAR 0000	CSEG	External

PRINT_HEX	L NEAR 0000	CSEG	External
PRINT_STRING	L NEAR 0000	CSEG	External
PRINT_WORD	L NEAR 0000	CSEG	External
RBB1	L NEAR 0819	CSEG	
RBB2	L NEAR 084A	CSEG	
RBB3	L NEAR 085A	CSEG	
RBB4	L NEAR 08B9	CSEG	
RBB5	L NEAR 0872	CSEG	
RBB6	L NEAR 08EC	CSEG	
RBB7	L NEAR 08DE	CSEG	
RBB8	L NEAR 083F	CSEG	
RBB9	L NEAR 0885	CSEG	
RB_BUSY	L BYTE 0084	CSEG	Global
RB_PTR	V DWORD 0000	CSEG	External
RD10	L NEAR 0C2A	CSEG	
RD11	L NEAR 0C47	CSEG	
RD12	L NEAR 0C50	CSEG	
READSTATE	Number 0052		
READ_DISK_INFO	N PROC 0C18	CSEG	Global Length = 0049
REAL_BUILD_BPB	N PROC 07F3	CSEG	Length = 010A
REMAPPED1	L BYTE 0090	CSEG	Global
REMAPPED2	L BYTE 0091	CSEG	
REMAPPED3	L BYTE 0092	CSEG	
RET_BYTE	Number 000E		
RH_BPB_PTR	L DWORD 04EF	CSEG	
RH_BUFFER	L DWORD 04EB	CSEG	
RH_COMMAND_CODE	L BYTE 04DF	CSEG	
RH_LEN	L BYTE 04D0	CSEG	
RH_MEDIA_DESC	L BYTE 04EA	CSEG	
RH_OFF	L WORD 0085	CSEG	
RH_RESV	L BYTE 04E2	CSEG	Length = 0008
RH_SEG	L WORD 0087	CSEG	
RH_STATUS	L WORD 04E0	CSEG	
RH_UNIT_CODE	L BYTE 04DE	CSEG	
RTY_NUM	L WORD 001E	CSEG	Global
SAVE_DRIVE	L BYTE 00A9	CSEG	
SECRET_BIAS	Number 1776		
SETIOBSW	F PROC 0C9E	CSEG	Length = 001C
SET_CURS	L NEAR 0CE2	CSEG	
SET_END_SPECIAL	N PROC 0CBA	CSEG	Length = 001A
SHORT_BAD_BPB	L NEAR 0A8B	CSEG	
SINGLE_8_BPB	L 0020 046F	CSEG	
SINGLE_9_BPB	L 0020 048F	CSEG	
SPECIAL_DRIVE	L BYTE 0093	CSEG	
SPKR_ENABLE	Number 0002		
SPKR_PORT	Number 0061		
SP_SAVE	V WORD 0000	CSEG	External
SRH	Number 0000		
SRH_CCD_FLD	Number 0002		
SRH_LEN	Number 0000		
SRH_LEN_FLD	Alias SRH		
SRH_RES_FLD	Number 0005		

SRH_STA_FLD	Number	0003		
SRH_UCD_FLD	Number	0001		
SSN	Number	0014		
SSN_LEN	Number	0002		
SS_SAVE	V WORD	0000	CSEG	External
STACK_TOP	L NEAR	0000	CSEG	External
STACK_USE	V BYTE	0000	CSEG	External
STRATEGY	L WORD	0006	CSEG	
TEMP_BPB	L 0020	044F	CSEG	
TIMEOUT	L WORD	0022	CSEG	Global
TIMER_CTRL	Number	0043		
TIMER_TWO	Number	0042		
TIMER_ZERO	Number	0040		
TRACE	Number	0000		
TRUE	Number	FFFF		
TYPE_BPB	L WORD	00A8	CSEG	
UNITS	Number	000D		
UNITS_LEN	Number	0001		
UNMOUNTCODE	Number	0002		
V5_BPB_LOOP	L NEAR	0E45	CSEG	
V5_JA	L NEAR	0ED9	CSEG	
VDISK_INIT	N PROC	0E33	CSEG	Length = 00AE
VDISK_INIT_LABEL	L NEAR	0E33	CSEG	
VDISK_IO	L NEAR	0000	CSEG	External
VDSK	F PROC	04F3	CSEG	Length = 00C0
VD_NOTBUSY	L NEAR	060C	CSEG	
VER3	Number	0000		
VERSION	L BYTE	0024	CSEG	
VE_BAD_BLOCK	Number	0006		
VE_BAD_DISK	Number	0008		
VE_BAD_MACHINE	Number	0003		
VE_CLIENT_ABORT	Number	000C		
VE_ILLEGAL_OP	Number	0002		
VE_INTERNAL	Number	000C		
VE_LEVEL4	Number	000A		
VE_NO_DESCR_WRITE	Number	0007		
VE_NO_DRIVE	Number	0001		
VE_NO_READ	Number	0004		
VE_NO_WRITE	Number	0005		
VE_OK	Number	0000		
VE_PROTOCOL	Number	000B		
VE_RESTRICTION	Number	0009		
VE_TIMEOUT	Number	000D		
VIDEO_CALL	Number	0010		
VP_VOL_UNIT	V BYTE	0000	CSEG	External
VSUB	N PROC	0583	CSEG	Length = 0240
WDERR	L NEAR	0B5C	CSEG	
WDIO	L NEAR	0AC0	CSEG	
WDI1	L NEAR	0BD1	CSEG	
WDI10	L NEAR	0C14	CSEG	

WDI11	L NEAR	0C14	CSEG	
WDI12	L NEAR	0BFA	CSEG	
WDI2	L NEAR	0AD0	CSEG	
WDI3	L NEAR	0AEA	CSEG	
WDI4	L NEAR	0B61	CSEG	
WINDOW	L NEAR	07AE	CSEG	
WINDOW_ERROR	L NEAR	07D7	CSEG	
WRITESTATE	Number	0057		
WRITE_DISK_INFO	N PROC	0AAE	CSEG	Global Length = 016A
WRITE_TTY	Number	000E		
YOUR_END	L WORD	0096	CSEG	Global
??000C	L NEAR	07C6	CSEG	
??0015	L NEAR	0924	CSEG	
??0016	L NEAR	092E	CSEG	
??0017	L NEAR	0A66	CSEG	
??0018	L NEAR	0AFC	CSEG	
??0019	L NEAR	0BD9	CSEG	

2414 Source Lines
2974 Total Lines
431 Symbols

30488 Bytes symbol space free

0 Warning Errors
0 Severe Errors